LAYOUT TECLADO KL-318	USB							
	R0	R1	R2	R3	R4	R5	R6	R7
C1	q	TAB	a	Esc	z	VK_OEM_PA1	° VK_OEM_5	VK_1
C2	w	block mayus	S	<	X	FFh(255) reserved	F1	VK_2
C3	е	F3	d	F4	С	FFh(255) reserved	F2	VK_3
C4	r	t	f	g	v	b	VK_5	VK_4
C5	u	y	j	h	m	n	VK_6	VK_7
C6	i	}]	k	F6	, VK_OEM_COMMA	FFh(255) reserved	i¿ VK_OEM_5	VK_8
C7	0	F7	I	NADA	. VK_OEM_PERIOD	VK_APPS	F8	VK_9
C14	(´)+	C2h(194)	Enter - return	UP	VK_MEDIA_PLAY_PAUSE	LEFT	VK_HOME(inicio)	VK_END
C13	9 page up numpad	6 derecha numpad	3 pg dn numpad	. del numpad	* VK_MULTIPLY	- VK_SUBTRACK	VK_PRIOR(Page Up)	VK_NEXT
C12	8 arriba numpad	5 numpad	2 abajo numpad	0 ins numpad	/ VK_DIVIDE	RIGHT	VK_INSERT	SUSPENDER-INVERNAR
C11	7 inicio numpad	4 izquierda numpad	1 end numpad	espacio	Bloq Num VK_NUMLOCK	DOWN	VK_DELETE(Supr)	SHUTDOWN
C15	posible block num	left shift	right shift	volume down	volume up	VK_MEDIA_NEXT_TRACK	VK_MEDIA_PREV_TRACK	VK_BACK
C10	FFh(255) reserved	backspace	ç (OEM_2)	F11	Enter	F12	F9	F10
C8	p	{[ñ (OEM_3)	" OEM_7	ç (OEM_2)	- VK_OEM_MINUS	VK_OEM_4	VK_0
C9	scroll lock	0 ins numpad titilante	NADA	alt VK_L-MENU	NADA	alt VK_RMENU	0 ins numpad	VK_SNAPSHOT
C0	pause inter	shutdown	alt -1-2-8 (Ç)	sleep	VK_RCONTROL right control	NADA	VK_LCONTROL	F5
C16	launch mail	L windows izquierda	VK_BORWNSER_ forward	VK_STOPBROWSER	VK_BROWSER_BACK	VK_BROWSER_REFRESH	VK_VOLUME_MUTE	VK_BROWSER_SEARCH
C17	oem reset	browser favorites	R win derecha	VK_LAUNCHAPP_1	VK_MEDIA_STOP	VK_LAUNCHAPP_2	VK_BROWSER_HOME	FFh(255) reserved
	check	check	check	check	check	check	check	check