

Pinout & Configuration

Clock Configuration

Pro

Software Packs

Pinout

Categories

A->Z

Timers

RTC

TIM1

TIM2

TIM3

TIM4

Connectivity

CAN

I2C1

I2C2

SPI1

SPI2

USART1

USART2

USART3

USB

TIM3 Mode and Configuration

Mode

Slave Mode Disable

Trigger Source Disable

☒ Internal Clock

Channel1 Disable

Channel2 Disable

Configuration

Reset Configuration

☒ NVIC Settings☒ DMA Settings☒ Parameter Settings☒ User Constants

NVIC Interrupt Table

Enabled

Preemption Prior

TIM3 global interrupt

☒

0



File

Window

Home > STM32F103C8Tx > ioc - Pinout & Configuration.١ مجلد >

Pinout & Configuration

Clock Configuration

Pro

Software Packs

Pinout

Q [] v



Categories

A->Z

Timers

- RTC
- TIM1
- ⚠ TIM2
- ✓ TIM3
- TIM4

Connectivity

- CAN
- I2C1
- ✓ I2C2
- SPI1
- SPI2
- USART1
- ✗ USART2
- ✗ USART3
- USB

TIM3 Mode and Configuration

Mode

- Slave Mode
- Trigger Source
- ☒ Internal Clock
- Channel1
- Channel2

Configuration

Reset Configuration

- ✓ NVIC Settings
- ✓ DMA Settings
- ✓ Parameter Settings
- ✓ User Constants

Configure the below parameters :

Q Search (Ctrl+F)



Counter Settings

- Prescaler (PSC... 7999
- Counter Mode Up
- Counter Period ... 499
- Internal Clock D... No Division
- auto-reload prel... Disable

> Trigger Output (TRGO) ...

Pinout & Configuration

Clock Configuration

Pro

Software Packs

Pinout

Q [v]



Categories

A->Z

Timers

RTC
TIM1
TIM2
TIM3
TIM4

Connectivity

CAN
I2C1
I2C2
SPI1
SPI2
USART1
USART2
USART3
USB

I2C2 Mode and Configuration

Mode

I2C I2C

Configuration

Reset Configuration

DMA Settings

GPIO Settings

User Constants

NVIC Settings

Parameter Settings

Configure the below parameters :

Q Search (Ctrl+F)



Master Features

I2C Speed Mode Standard Mode

I2C Clock Spee... 100000

Slave Features

Clock No Stretc... Disabled

Primary Address... 7-bit

Dual Address A... Disabled

Primary slave a... 0

General Call ad... Disabled

 Pinout view

 System view

