```
* SPICE export by:  S-Edit 16.01
* Export time:      Sun Oct 18 19:09:18 2026
* Design:           adder
* Cell:             Cell0
* Interface:        view0
* View:             view0
* View type:        connectivity
* Export as:        top-level cell
* Export mode:      hierarchical
* Exclude empty cells: yes
* Exclude .model:   no
* Exclude .end:     no
* Exclude simulator commands:     no
* Expand paths:     yes
* Wrap lines:       no
* Root path:        C:\New folder\adder
* Exclude global pins:   no
* Exclude instance locations: no
* Control property name(s): SPICE

********* Simulation Settings - General Section *********

***** Top Level *****
MNMOS_1 N_9AGnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-4900 $y=600 $w=400
$h=600
MNMOS_2 N_13AN_1 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-2100 $y=-1300
$w=400 $h=600
MNMOS_3 N_1 B Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-2100 $y=-2200
$w=400 $h=600
MNMOS_4 N_13 N_9 N_2 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-200 $y=-1300
$w=400 $h=600
MNMOS_5 N_2 N_10 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-200 $y=-2200
$w=400 $h=600
MNMOS_6 N_10 B Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-5000 $y=-2500
$w=400 $h=600
MNMOS_7 N_11 N_13 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=5000 $y=1100
$w=400 $h=600
MNMOS_8 Sum N_13 N_3 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=7800 $y=-800
$w=400 $h=600
MNMOS_9 N_3 Cin Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=7800 $y=-1700
$w=400 $h=600
MNMOS_10 Sum N_11 N_4 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=9700 $y=-800
$w=400 $h=600
MNMOS_11 N_4 N_15 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=9700 $y=-1700
$w=400 $h=600
MNMOS_12 N_15 Cin Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=4900 $y=-2000
$w=400 $h=600
MNMOS_13 N_16 B N_5 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-1200 $y=-9600
$w=400 $h=600
MNMOS_14 N_5AGnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-1200 $y=-10500
$w=400 $h=600
MNMOS_15 N_19 N_16 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=1000 $y=-9600
$w=400 $h=600
MNMOS_16 N_17 Cin N_6 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=5300 $y=-6100
$w=400 $h=600
MNMOS_17 N_6 N_13 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=5300 $y=-7000
$w=400 $h=600
MNMOS_18 N_18 N_17 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=7500 $y=-6100
$w=400 $h=600
MNMOS_19 N_21 N_19 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=10200 $y=-8500
$w=400 $h=600
```

```
MNMOS_20 N_21 N_18 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=12100 $y=-8500
$w=400 $h=600
MNMOS_21 Cout N_21 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=15200 $y=-7500
$w=400 $h=600
MPMOS_1 N_7 N_9 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-2200 $y=1500
$w=400 $h=600
MPMOS_2 N_8AVdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-100 $y=1500
$w=400 $h=600
MPMOS_3 N_13 B N_7 Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-2200 $y=500
$w=400 $h=600
MPMOS_4 N_13 N_10 N_8 Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-100 $y=500
$w=400 $h=600
MPMOS_5 N_9AVdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-4900 $y=1400
$w=400 $h=600
MPMOS_6 N_10 B Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-5000 $y=-1700
$w=400 $h=600
MPMOS_7 N_14 N_11 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=7700 $y=2000
$w=400 $h=600
MPMOS_8 N_12 N_13 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=9800 $y=2000
$w=400 $h=600
MPMOS_9 Sum Cin N_14 Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=7700 $y=1000
$w=400 $h=600
MPMOS_10 Sum N_15 N_12 Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=9800
$y=1000 $w=400 $h=600
MPMOS_11 N_11 N_13 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=5000 $y=1900
$w=400 $h=600
MPMOS_12 N_15 Cin Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=4900 $y=-1200
$w=400 $h=600
MPMOS_13 N_16 B Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-1900 $y=-8400
$w=400 $h=600
MPMOS_14 N_16AVdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-400 $y=-8400
$w=400 $h=600
MPMOS_15 N_19 N_16 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=1000
$y=-8800 $w=400 $h=600
MPMOS_16 N_17 Cin Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=4600 $y=-4900
$w=400 $h=600
MPMOS_17 N_17 N_13 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=6100
$y=-4900 $w=400 $h=600
MPMOS_18 N_18 N_17 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=7500
$y=-5300 $w=400 $h=600
MPMOS_19 N_20 N_18 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=11000
$y=-6100 $w=400 $h=600
MPMOS_20 N_21 N_19 N_20 Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=11000
$y=-7100 $w=400 $h=600
MPMOS_21 Cout N_21 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=15200
$y=-6700 $w=400 $h=600

********* Simulation Settings -Analysis Section *********
.lib "C:\Users\mahak\Downloads\Tanner_v16\Tanner_v16\BPTM_Models files\180nm.md"
vss Vdd Gnd 1.8
VaAGnd PULSE (0 1.8 0 0.01n 0.01n 10n 20n)
Vb B Gnd PULSE (0 1.8 0 0.01n 0.01n 20n 40n)
Vc Cin Gnd PULSE (0 1.8 0 0.01n 0.01n 40n 60n)
.tran 0.1n 100n
.power Va
.power Vb
.power Vc
.print V(A) V(B) V(Cin) V(Sum) V(Cout)

********* Simulation Settings -Additional SPICE Commands *********

.end
```