```
* SPICE export by:  S-Edit 16.01
* Export time:      Sat Oct 10 16:54:27 2026
* Design:           nor
* Cell:             Cell0
* Interface:        view0
* View:             view0
* View type:        connectivity
* Export as:        top-level cell
* Export mode:      hierarchical
* Exclude empty cells: yes
* Exclude .model:   no
* Exclude .end:     no
* Exclude simulator commands:     no
* Expand paths:     yes
* Wrap lines:       no
* Root path:        C:\New folder\nor
* Exclude global pins:   no
* Exclude instance locations: no
* Control property name(s): SPICE

********* Simulation Settings - General Section *********

*****Top Level *****
MNMOS_1 Out In1 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=-1500 $y=-500
$w=400 $h=600
MNMOS_2 Out In2 Gnd 0 NMOS W=270n L=180nAS=243f PS=2.34uAD=243f PD=2.34u $ $x=800 $y=-600 $w=400
$h=600
MPMOS_1 N_1 In1 Vdd Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-400 $y=1400
$w=400 $h=600
MPMOS_2 Out In2 N_1 Vdd PMOS W=810n L=180nAS=729f PS=3.42uAD=729f PD=3.42u $ $x=-400 $y=600
$w=400 $h=600

********* Simulation Settings -Analysis Section *********
.lib "C:\Users\mahak\Downloads\Tanner_v16\Tanner_v16\BPTM_Models files\180nm.md"
vdd Vdd Gnd 1.8
Va In1 Gnd PULSE (0 1.8 0 0.01n 0.01n 10n 20n)
Vb In2 Gnd PULSE (0 1.8 0 0.01n 0.01n 20n 40n)
.power Va
.power Vb
.tran 0.01n 100n
.measure dc delay1 trig v(In1) val=0.9 rise=2 targ v(Out) val=0.9 fall=2
.measure dc delay2 trig v(In2) val=0.9 rise=2 targ v(Out) val=0.9 fall=2
.print v(In1) v(In2) v(Out)



********* Simulation Settings -Additional SPICE Commands *********

.end
```