

IMPERIAL

FIRE ENGINEERING

The Expert in Fire Protection System

FIRE SUPPRESSION SYSTEM

SEMI-ANNUAL and ANNUAL

PREVENTIVE MAINTENANCE REPORT

DATE:

TIME:

PROJECT :

CUSTOMER:

ADDRESS :

TEL :

HAZARD AREA ZONE :

LOCATION :

☐ In Warranty : ☐ YEAR(S) ครั้งที่ ☐

☐ Contact PM : ☐ YEAR(S) ครั้งที่ ☐

FIRE SUPPRESSION SYSTEM DETAIL :

Type of Agent :

☐ N2

☐ Novec1230

☐ FM200

☐ CO2

☐ Other

Hazard Area Zone	CYLINDER			WEIGHT [Kg.]				NOZZLE [Unit]	
	Unit	Size	Pressure	Cylinder Full	Cylinder Empty	Agent	Tolerable Loss	Ceiling	Raised FL.

CONTROL PANEL DETAIL :

Type of FACP :

☐ Hardwire

☐ Multiplex

MODEL :

System Power :

Primary [VAC] :

☐ 110

☐ 220

Battery Type:

☐ Seal Lead Acid

☐ Nickle Cadmium

DETECTOR :

☐ SINGLE ZONE

☐ CROSS ZONE

☐ Smoke

☐ Under Ceiling

Unit[s]

☐ Under Raised FL.

Unit[s]

☐ Heat

☐ Under Ceiling

Unit[s]

☐ Under Raised FL.

Unit[s]

☐

☐ Under Ceiling

Unit[s]

☐ Under Raised FL.

Unit[s]

☐

☐ Under Ceiling

Unit[s]

☐ Under Raised FL.

Unit[s]

FACP setting :

DELAY TIME SETTING

☐ 30 sec

☐ 60 sec

Signal to Shut Down :

☐ AHU

☐ FCU

☐

Signal to Access :

☐ FireAlarm

☐ Door

☐ Lift

☐

VISUAL CHECK

	PASS	NO	N/A		PASS	NO	N/A
1 Agent Cylinder	☐	☐	☐	13 FA Control Panel	☐	☐	☐
2 ElectroMagnetic Release	☐	☐	☐	14 FACP Circuit Wiring	☐	☐	☐
3 Manual Release	☐	☐	☐	15 Detector	☐	☐	☐
4 Pressure Gauge	☐	☐	☐	16 Bell	☐	☐	☐
5 Pressure Switch	☐	☐	☐	17 Strobe/Horn	☐	☐	☐
6 Header	☐	☐	☐	18 Manual Station	☐	☐	☐
7 Discharge & Pilot Hose	☐	☐	☐	19 Abort	☐	☐	☐
8 Cylinder Support	☐	☐	☐	20 Disable Switch	☐	☐	☐
9 Piping	☐	☐	☐	21 Gravity Damper	☐	☐	☐
10 Nozzle	☐	☐	☐	22 Motorized Damper	☐	☐	☐
11 Electric Cable	☐	☐	☐	23 Battery	☐	☐	☐
12 Conduit	☐	☐	☐	24 Monitoring	☐	☐	☐

SYSTEM OPERATION

AUTO FUNCTION

ALARM FUNCTION : Active Detector ZONE 1

1 "BUZZER" sound until press "ACK/STEP" button

2 "ALARM " LED activated

3 "ALARM BELL" activated

4 "ALARM AUDIBLE" activated until press "ALARM SILENCE" button

☐ Pass ☐ NO

☐ Pass ☐ NO

☐ Pass ☐ NO

☐ Pass ☐ NO

SYSTEM OPERATION [continue]

AUTO FUNCTION

ALARM FUNCTION : Active Detector ZONE 2

- 1 "BUZZER" sound until press "ACK/STEP" button
- 2 "ALARM " LED activated
- 3 "ALARM BELL" activated
- 4 "ALARM AUDIBLE" activated until press "ALARM SILENCE" button

☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO

DISCHARGE FUNCTION : Active Detector ZONE 1 and Detecor ZONE 2 - Function Counting down Completed : Not push "ABORT SWITCH"

- 1 "BUZZER" sound until press "ACK/STEP" button
- 2 "ALARM " LED activated
- 3 "ALARM BELL" activated
- 4 "PREDISCHARGE " LED activated
- 5 "ALARM STROBE/HORN" activated
- 6 "PREDISCHARGE RELAY" activated [Shut off AHU/FCU] [Link FA]
- 7 "PREDISCHARGE AUDIBLE" activated until press "ALARM SILENCE" button
- 8 "TIME DELAY RELEASE " count down
- 9 "SOLENOID VALVE" activated
- 10 "SELECTOR VALVE" activated

☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO

☐ N/A

ABORT SWITCH FUNCTION

PUSH and HOLD "ABORT SWITCH" after PREDISCHARGE FUNCTION Activated

- 1 "TIME DELAY RELEASE " count down
- 2 "SOLENOID VALVE" activated
- 3 "SELECTOR VALVE" activated

☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO

☐ N/A

MANUAL RELEASE FUNCTION

PUSH and PULL "MANUAL STATION"

- 1 "MANUAL RELEASE " LED activated
- 2 "ALARM BELL and STROBE/HORN" activated
- 3 "ALARM RELAY" activated [Shut off AHU/FCU] [Link FA]
- 4 "SOLENOID VALVE" activated
- 5 "SELECTOR VALVE" activated

☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO
☐ Pass ☐ NO

☐ N/A

RESET SWITCH FUNCTION

PUSH "RESET SWITCH"

System reset to "SYSTEM ALL NORMAL " again

☐ Pass ☐ NO

BATTERY BACKUP TEST FUNCTION

ALARM FUNCTION : Active Detector ZONE 1 and ZONE 2

System reset to "SYSTEM ALL NORMAL " again

☐ Pass ☐ NO

CLEANING

- 1 Agent Cylinder ☐ YES ☐ N/A
- 2 Solinoid Valve ☐ YES ☐ N/A
- 3 Control Panel ☐ YES ☐ N/A
- 4 Detector ☐ YES ☐ N/A

- 5 Bell ☐ YES ☐ N/A
- 6 Strobe / Horn ☐ YES ☐ N/A
- 7 Manual Station ☐ YES ☐ N/A
- 8 Abort Switch ☐ YES ☐ N/A

- 9 Disable Switch ☐ YES ☐ N/A
- 10 ☐ YES ☐ N/A
- 11 ☐ YES ☐ N/A
- 12 ☐ YES ☐ N/A

COMMENT

PM Performed By

Customer's Acceptance

IMPERIAL FIRE ENGINEERING Co.,Ltd.

DATE

DATE