OPNAV 3100/6 (9-75) BACK

INSTRUCTIONS FOR FIRE CONTROL LOG

1. This log provides for recording fire control data for an individual contact.
2. Standard Instructions for Operational Data Logs (OPNAV 3100/1) apply.
3. Start a new page at the beginning of a new day.
4. Make entries as required to describe fire control data for the contact. Enter master contact number assigned at the bottom of the page, and visual, sonar, and ESM contact numbers where applicable.
5. Entry is required whenever a firing, actual or simulated, occurs. Make entry at the time of weapon launch, and indicate in REMARKS whether firing was actual or simulated, type of weapon and settings, outcome of attack, and any other information that describes the attack.

BOX	DATA ENTRY
18-21	TIME: Enter the time associated with this line entry. If significant, use the last two columns to record seconds.
23-24	SOURCE: Enter source from Code A. If needed, enter two codes to describe source of data. If only one code is entered, enter it in column 23, unless the code is "Z" (Other) If entry "Z" is used, always enter it in column 24 and explain data source in REMARKS. (A "Z" in column 23 signifies a narrative entry.)
25-28	BEARING: Enter bearing in degrees in columns 25-27, and enter "T" (true) or "R" (relative) in column 28.
29	MOVEMENT: Enter contact movement from Code A.
30-35	RANGE: Enter contact range in yards whenever measured or determined. If source of range data is not obvious from source code, clarify range data source in REMARKS.
36-39	ANGLE ON BOW: Enter "P" (port) or "S" (starboard) in column 36, and enter the absolute value of the angle on bow in columns 37-39.
40-42	COURSE: Enter estimated contact course in degrees. Clarify method of determination in REMARKS, if needed.
43-45	SPEED: Enter estimated contact speed in knots in columns 43-44. Use column 45 to record tenths of knot, if needed. Clarify method of determination in REMARKS, if needed.
46	UPDATE: Enter "X" to indicate that the data were used to update the fire control computer.
47-73	REMARKS: Enter clarifying remarks needed or other comments pertinent to data entry. Remarks related to a previous line entry, but occurring at a different time, shall be recorded on a separate line. Include contact classification changes here. If REMARKS section is not long enough, enter "Z" in column 23 and use the rest of the line for remarks, ignoring column markings.
74-77	CONTACT NUMBER Enter contact number assigned. Enter the same number in the appropriate space at the bottom of the log.

CODE A - SOURCE

C Conformal/LF array	8 PNB Tracker
A Cylindrical array	9 Active tracker
S Spherical array	0 Data tracker
G PUFFS	B Spectrum analyzer
U Under ice (active)	W DIMUS
Y Under ice (passive)	L Active ping
J Towed array	M Ping steal
I Acoustic intercept	N UQC check
R Radar	D DRT
E ESM	F Fire control
V Visual	K Eklund
2 Aural	P Pacing
3 B/T recorder	X Sonar estimate
4 PPI	Q Signal path
5 CRT	H Bottom bounce
6 PBB analog tracker	T Plots
7 PBB digital tracker	Z Other (Explain in REMARKS)

CODE - MOVEMENT

A At CPA	(Subs only)
C Closing	
D Dead in water	B Broached
F Faded	E Deep
G Gain/regain	N Surfaced
H Stopped/shut down	P Periscope depth
I In baffles	S Shallow
J Merging	U Submerged (depth unknown)
K Masking	X Snorkeling
L Left drift	Y Changing depth
M Constant bearing	
O Opening	
R Right drift	
T Terminated	
V Increased speed	
W Decreased speed	
Z Zig	