

Service Request Number _____

Quarterly PM Checklist



Site Name: _____

Planned Maintenance Checklist

3200 NW 27th Ave Ste. 100
Pompano Beach, FL
33069
Office: 888-400-3979
aisserv.com

FE Name: _____

Month: _____

Procedure

Print Form

Reset Form

OK

Cleaned

Adjusted

Needs
Correction

PM Checklist

Talk With Technologist About System Operation.....	☐	☐	☐	☐
Look at Image Quality of Previous Exams.....	☐	☐	☐	☐
Check and Set System Date and Time.....	☐	☐	☐	☐

SAFETY AND REGULATORY

CONSOLE – Check e-stops(4-gantry, 1on PDU, 1 on SCIM).....	☐	☐	☐	☐
CONSOLE- Check Audio system, from console to Gantry.....	☐	☐	☐	☐

Clean, Test and Check

CONSOLE -Clean and Vacuum inside and out of console.....	☐	☐	☐	☐
CONSOLE -Clean and Vacuum CPU (open it up).....	☐	☐	☐	☐
CONSOLE -Check all fans.....	☐	☐	☐	☐
CONSOLE -Clean/ Vacuum MOD Tower.....	☐	☐	☐	☐
CONSOLE -Clean and check Keyboard, mouse, and SCIM.....	☐	☐	☐	☐
TABLE -Clean and vacuum Table	☐	☐	☐	☐
TABLE -Check and verify safety switches are good and working.....	☐	☐	☐	☐
TABLE -Check covers, make sure they're mounted properly.....	☐	☐	☐	☐
TABLE -Check to make sure cradle is not riding on covers.....	☐	☐	☐	☐
TABLE-Clean rollers on cradle drive.....	☐	☐	☐	☐
TABLE -Clean bottom of cradle, make sure no tape is on.....	☐	☐	☐	☐
GANTRY -Check covers are on good, locked in.....	☐	☐	☐	☐
GANTRY -Check top fans.....	☐	☐	☐	☐
GANTRY -Take off covers and check power switches, are they properly working.....	☐	☐	☐	☐
GANTRY -Disable 120, axial, and H,V, switches- make sure gantry is off.....	☐	☐	☐	☐
GANTRY -Turn on 120 switch, does gantry brake turn off?.....	☐	☐	☐	☐
GANTRY -Take off front cover.....	☐	☐	☐	☐
GANTRY -Take off mylar window clean and check for damage.....	☐	☐	☐	☐
GANTRY -Make sure power is off and vacuum inside front half of gantry.....	☐	☐	☐	☐
GANTRY -Clean and vacuum DAS filters.....	☐	☐	☐	☐
GANTRY -Turn 120 on and check for fans working properly.....	☐	☐	☐	☐
GANTRY -Remove slip ring covers. Clean covers and slip ring block.....	☐	☐	☐	☐
GANTRY -Check brushes for wear, replace any as needed.....	☐	☐	☐	☐
GANTRY -Grease gantry as needed(2,000,000 revolutions).....	☐	☐	☐	☐
Last Lubed _____				
GANTRY -Replace covers and check gantry rotation.....	☐	☐	☐	☐
PDU -Check fans.....	☐	☐	☐	☐
PDU -Clean and vacuum.....	☐	☐	☐	☐

Service Request Number _____

Quarterly PM Checklist



Site Name: _____

Planned Maintenance Checklist

3200 NW 27th Ave Ste. 100
Pompano Beach, FL
33069
Office: 888-400-3979
aisserv.com

FE Name: _____

Month: _____

Procedure

FINAL CHECKS

	OK	Cleaned	Adjusted	Needs Correction
Check Error Message Log.....	☐	☐	☐	☐
Do Save State.....	☐	☐	☐	☐
RESTORATION - Do scout, helical, & axial scan, Remove Test Scans, and Covers.....	☐	☐	☐	☐
RESTORATION - Shut down system pre-site procedure.....	☐	☐	☐	☐
RESTORATION - Update site log book, E-mail update with any follow up's and status.....	☐	☐	☐	☐

Notes:

Service Request Number _____

Quarterly PM Checklist



Site Name: _____

Planned Maintenance Checklist

3200 NW 27th Ave Ste. 100
Pompano Beach, FL
33069
Office: 888-400-3979
aisserv.com

FE Name: _____

Quarterly Check _____

Procedure

1st Quarter Checks

	OK	Cleaned	Adjusted	Needs Correction
TABLE -Vacuum power supplies inside table.....	☐	☐	☐	☐
TABLE- MEASURE TABLE POWER SUPPLY VALUE.....	☐	☐	☐	☐
TABLE -Check fans inside table.....	☐	☐	☐	☐
TABLE -Check clutch on cradle asm.....	☐	☐	☐	☐
TABLE -Grease IS.....	☐	☐	☐	☐

2nd Quarter Checks

GANTRY -Check to make sure heat exchange pump is working.....	☐	☐	☐	☐
GANTRY -Turn axial and check belt for any damage.....	☐	☐	☐	☐
GANTRY -Check Thermistor.....	☐	☐	☐	☐
GANTRY -Clean and check for pitting or arch marks.....	☐	☐	☐	☐

3rd Quarter Checks

GANTRY -Check Tilt functions.....	☐	☐	☐	☐
GANTRY -Check speed of Tilt.....	☐	☐	☐	☐
GANTRY -Clean Tube Heat Exchange and Heat Exchange Pump.....	☐	☐	☐	☐
GANTRY -HV Tank feedback Resistor.....	☐	☐	☐	☐
GANTRY -Meter Verification.....	☐	☐	☐	☐

4th Quarter Checks

GANTRY -Check bolts for proper torque.....	☐	☐	☐	☐
GANTRY -Check oil inside wells, any carbon tracks, discolor.....	☐	☐	☐	☐
GANTRY -Check HV cables, pins, sleeve.....	☐	☐	☐	☐
GANTRY -Clean Collimator.....	☐	☐	☐	☐
GANTRY -Clean wells and fill with clean oil	☐	☐	☐	☐
GANTRY -Check alignment lights.....	☐	☐	☐	☐

Notes: