



Technical Safety Concept Lane Assistance

Document Version: [Version]
Template Version 1.0, Released on 2017-06-21



Document history

[Instructions: Fill in the date, version and description fields. You can fill out the Editor field with your name if you want to do so. Keep track of your editing as if this were a real world project.

For example, if this were your first draft or first submission, you might say version 1.0. If this is a second submission attempt, then you'd add a second line with a new date and version 2.0]

| Date | Version | Editor | Description |
|-------------|---------|----------------|---------------|
| Apr. 30, 19 | 1.0 | Norihito Tohge | First Attempt |
| | | | |
| | | | |
| | | | |
| | | | |

Table of Contents

[Instructions: We have provided a table of contents. If the table of contents is not showing up correctly in your word processor of choice, please update it. The table of contents should show each section of the document and page numbers or links. Most word processors can do this for you. In Google Docs, you can use headings for each section and then go to Insert > Table of Contents. Microsoft Word has similar capabilities]

Document history

Table of Contents

Purpose of the Technical Safety Concept

Inputs to the Technical Safety Concept

Functional Safety Requirements

Refined System Architecture from Functional Safety Concept

Functional overview of architecture elements

Technical Safety Concept

Technical Safety Requirements

Refinement of the System Architecture

Allocation of Technical Safety Requirements to Architecture Elements

Warning and Degradation Concept

Purpose of the Technical Safety Concept

[Instructions: Answer what is the purpose of a technical safety concept?]

Inputs to the Technical Safety Concept


Functional Safety Requirements

[Instructions: Provide the functional safety requirements derived in the functional safety concept]

| ID | Functional Safety Requirement | A S I L | Fault Tolerant Time Interval | Safe State |
|--|---|------------------|---------------------------------------|---------------------------|
| Functional Safety Requirement 01-01 | The Lane Assistance item shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude. | С | 50 ms | The system is turned off. |
| Functional Safety Requirement 01-02 | The Lane Assistance item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency. | С | 50 ms | The system is turned off. |
| Functional Safety Requirement 02-01 | The Electronic Power Steering ECU shall ensure that the Lane Keeping Assistance torque is applied for only Max_Duration. | В | 500 ms | The system is turned off. |

Refined System Architecture from Functional Safety Concept

[Instructions: Provide the refined system architecture from the functional safety concept]



Functional overview of architecture elements

[Instructions: Provide a description for each functional safety element; what is each element's purpose in the lane assistance item?]

| Element | Description |
|---|--|
| Camera Sensor | Camera Sensor captures images in front of the vehicle. |
| Camera Sensor ECU - Lane Sensing | It reads images from the Camera Sensor and detects lanes in the images. |
| Camera Sensor ECU - Torque request generator | Based on Lane Sensing results, it outputs Torque Request to Electronic Power Steering ECU. |
| Car Display | Car Display shows status of and warnings from Lane Assistance system. |
| Car Display ECU - Lane Assistance On/Off Status | It displays a telltale if Lane Assistance is enabled. |

| Car Display ECU - Lane Assistant Active/Inactive | It displays an telltale if Lane Assistance is activated. |
|--|--|
| Car Display ECU - Lane Assistance malfunction warning | It displays a warning if malfunctions are detected in Lane Assistance system. |
| Driver Steering Torque Sensor | Driver Steering Torque Sensor senses steering torque applied by the driver. |
| Electronic Power Steering (EPS) ECU - Driver Steering Torque | EPS ECU reads driver steering torque from Driver Steering Torque Sensor. |
| EPS ECU - Normal Lane Assistance Functionality | Based on Torque Request from Camera Sensor ECU, it outputs torque to perform LDW and LKA. |
| EPS ECU - Lane Departure Warning Safety Functionality | It checks if amplitude and frequency of output torque request is in safe ranges. |
| EPS ECU - Lane Keeping Assistant Safety Functionality | It checks if the duration of LKA torque request is below maximum acceptable duration. |
| EPS ECU - Final Torque | It inputs driver steering torque and LDW/LKA torque requests and calculate the final torque based on inputs and output the result to the motor |
| Motor | It receives torque request from EPS ECU and apply torque to the steering wheel. |

Technical Safety Concept

Technical Safety Requirements

[Instructions: Fill in the technical safety requirements for the lane departure warning first functional safety requirement. We have provided the associated functional safety requirement in the first table below. Hint: The technical safety requirements were discussed in the lesson videos. The architecture allocation column should contain element names such as LDW Safety block, Data Transmission Integrity Check, etc. Allocating the technical safety requirements to the "EPS ECU" does not provide enough detail for a technical safety concept.]

Lane Departure Warning (LDW) Requirements:

Functional Safety Requirement 01-01 with its associated system elements

(derived in the functional safety concept)

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|--|---|--|---------------|--------------------|
| Functional Safety Requirement 01-01 | The lane keeping item shall ensure that the lane departure oscillating torque amplitude is below Max_Torque_Amplitude | Х | | |

Technical Safety Requirements related to Functional Safety Requirement 01-01 are:

| ID | Technical Safety Requirement | A S L L | Fault Tolerant Time Interval | Architecture Allocation | Safe State |
|--|---|---------|---------------------------------------|--|--|
| Technical Safety Requirem ent 01 | The LDW safety component shall ensure that the amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Amplitude. | C | 50 ms | LDW Safety | LDW torque request shall be set to zero. |
| Technical Safety Requirem ent 02 | As soon as the LDW function deactivates the LDW feature, the 'LDW Safety' software block shall send a signal to the car display ECU to turn on a warning light. | С | 50 ms | LDW Safety | LDW torque request shall be set to zero. |
| Technical Safety Requirem ent 03 | As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the 'LDW_Torque_Request' shall be set to zero. | С | 50 ms | LDW Safety | LDW torque request shall be set to zero. |
| Technical Safety Requirem ent 04 | The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured. | С | 50 ms | Data Transmission Integrity Check | LDW torque request shall be set to zero. |
| Technical Safety | Memory test shall be conducted at startup of the EPS ECU to | Α | Ignition cycle | Safety Startup | LDW torque request shall |

| Requirem ent | check for any faults in memory. | | be set to zero. |
|--------------|---------------------------------|--|-----------------|
| 05 | | | |

[Instructions: Fill in the technical safety requirements for the lane departure warning second functional safety requirement. We have provided the associated functional safety requirement in the table below. Hint:. Most of the technical safety requirements will be the same. At least one technical safety requirement will have to be slightly modified because we are talking about frequency instead of amplitude. These requirements were not given in the lessons]

Functional Safety Requirement 01-2 with its associated system elements (derived in the functional safety concept)

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|--|---|--|---------------|--------------------|
| Functional Safety Requirement 01-02 | The lane keeping item shall ensure that the lane departure oscillating torque frequency is below Max_Torque_Frequency | X | | |

Technical Safety Requirements related to Functional Safety Requirement 01-02 are:

| ID | Technical Safety Requirement | A S I L | Fault Tolerant Time Interval | Architecture Allocation | Safe State |
|--|---|---------|---------------------------------------|----------------------------|---|
| Technical Safety Requirement 01 | The LDW safety component shall ensure that the amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Frequency. | С | 50 ms | LDW Safety | LDW torque request shall be set to zero. |
| Technical | As soon as the LDW function | С | 50 ms | LDW Safety | LDW |

| Safety Requirement 02 | deactivates the LDW feature, the 'LDW Safety' software block shall send a signal to the car display ECU to turn on a warning light. | | | | torque request shall be set to zero. |
|--|--|---|-------------------|--|---|
| Technical Safety Requirement 03 | As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the 'LDW_Torque_Request' shall be set to zero. | С | 50 ms | LDW Safety | LDW torque request shall be set to zero. |
| Technical Safety Requirement 04 | The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured. | С | 50 ms | Data Transmission Integrity Check | LDW torque request shall be set to zero. |
| Technical Safety Requirement 05 | Memory test shall be conducted at startup of the EPS ECU to check for any faults in memory. | А | Ignition cycle | Safety Startup | LDW torque request shall be set to zero. |

Lane Departure Warning (LDW) Verification and Validation Acceptance Criteria:

[OPTIONAL: For each technical safety requirement, identify both the verification and validation acceptance criteria. "Validation" asks whether or not you chose the appropriate parameters. "Verification" involves testing to make sure the vehicle behaves as expected when the parameter value is crossed. There is not necessarily one right answer. Look at your verification and validation acceptance criteria from the functional safety concept for inspiration.]

Lane Keeping Assistance (LKA) Requirements:

[Instructions: Fill in the technical safety requirements for the lane keeping assistance functional safety requirement 02-01. We have provided the associated functional safety requirement in the table below. Hint:. You can reuse the technical safety requirements

from functional safety requirement 01-01. But you need to change the language because we are now looking at a different system. The ASIL and Fault Tolerant Time Interval are different as well.]

Functional Safety Requirement 02-1 with its associated system elements (derived in the functional safety concept)

| ID | Functional Safety Requirement | Electronic Power Steering ECU | Camera ECU | Car Display ECU |
|--|---|--|---------------|--------------------|
| Functional Safety Requirement 02-01 | The lane keeping item shall ensure that the lane keeping assistance torque is applied for only Max_Duration | X | | |

Technical Safety Requirements related to Functional Safety Requirement 02-01 are:

| ID | Technical Safety Requirement | ASIL | Fault Tolerant Time Interval | Allocation to Architecture | Safe State |
|--|--|------|---------------------------------------|---|---|
| Technical Safety Requireme nt 01 | The LKA safety component shall ensure that the duration of the 'LKA_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Duration. | В | 500 ms | LKA Safety | LKA torque request shall be set to zero. |
| Technical Safety Requireme nt 02 | As soon as the LKA function deactivates the LKA feature, the 'LKA Safety' software block shall send a signal to the car display ECU to turn on a warning light. | В | 500 ms | LKA Safety | LKA torque request shall be set to zero. |
| Technical Safety Requireme nt 03 | As soon as a failure is detected by the LKA function, it shall deactivate the LKA feature and the 'LKA_Torque_Request' shall be set to zero. | В | 500 ms | LKA Safety | LKA torque request shall be set to zero. |
| Technical Safety Requireme | The validity and integrity of the data transmission for 'LKA_Torque_Request' signal | В | 500 ms | Data Transmission Integrity Check | LKA torque request shall be set |


| nt 04 | shall be ensured. | | | | to zero. |
|--|---|---|-------------------|----------------|---|
| Technical Safety Requireme nt 05 | Memory test shall be conducted at startup of the EPS ECU to check for any faults in memory. | Α | Ignition cycle | Safety Startup | LKA torque request shall be set to zero. |

Lane Keeping Assistance (LKA) Verification and Validation Acceptance Criteria:

[OPTIONAL: For each technical safety requirement, identify both the verification and validation acceptance criteria. "Validation" asks whether or not you chose the appropriate parameters. "Verification" involves testing to make sure the vehicle behaves as expected when the parameter value is crossed. There is not necessarily one right answer. Look at your verification and validation acceptance criteria from the functional safety concept for inspiration.]

Refinement of the System Architecture

[Instructions: Include the refined system architecture. Hint: The refined system architecture should include the system architecture from the end of the technical safety lesson, including all of the ASIL labels.]



Allocation of Technical Safety Requirements to Architecture Elements

[Instructions: We already included the allocation as part of the technical requirement tables. Here you can state that for this particular item, all technical safety requirements are allocated to the Electronic Power Steering ECU]

As described in tables in <u>Technical Safety Requirements</u>, all the technical safety requirements are allocated to blocks in Electronic Power Steering ECU.

Warning and Degradation Concept

[Instructions: We've already identified that for any system malfunction, the lane assistance functions will be turned off and the driver will receive a warning light indication. The technical safety requirements have not changed how functionality will be degraded or what the warning will be.

So in this case, the warning and degradation concept is the same for the technical safety requirements as for the functional safety requirements. You can copy the functional safety warning and degradation concept here.

Oftentimes, a technical safety analysis will lead to a more detailed warning and degradation concept.]

| ID | Degradation Mode | Trigger for Degradation Mode | Safe State invoked? | Driver Warning |
|--------|------------------------|--|---------------------|---|
| WDC-01 | Turning off the system | The lane departure oscillating torque exceeds Max_Torque_A mplitude or the lane departure oscillating frequency exceeds Max_Torque_Fr equency. | Yes | A warning message is shown on Car Display. |
| WDC-02 | Turning off the system | The Lane Keeping Assistance torque is applied | Yes | A warning message is shown on Car Display. |

| | for more than Max_Duration. | | |
|--|-----------------------------|--|--|
|--|-----------------------------|--|--|