

## **SMART FACULTY MANAGEMENT PTE LTD**

15, Bukit Batok St 22, #06-00, Propell Building, Singapore 659586 Tel : 62822822 Fax : 62820300 Reg No : 199903182D E-Mail : info@propell.com.sg

M & EINSPECTION FORM - Electrical(Quarterly)

ANNEX D7\_2

SITE: HDB Project1 15 Cedar Avenue, Singapore-349700

Month: March 2021	
Remarks	

S/N	ITEM	DONE? (Yor Nor NA)	Date Done	Remarks
1	FAN SYSTEM			
1	Check fan speeds are operated according to the fan regulator setting, replace regulator if faulty.	Yes No No NA	01/06/2021	
2	Check for wobbling & speed. The condition of the fan blades, motor holding bolt, and plastic sleeve. If found any of the mentioned parts that are not in-order, isolate fan and replace with new spare part.	Yes No NA	01/06/2021	
2	LIGHT SYSTEM			
1	Check cover/housing has no discoloration or cracks and supports are secured, replace if necessary.	✓ Yes No NA	01/06/2021	
2	Check and all bulbs/tubes including LED drivers and lights are in working conditions, rectify or replace if necessary. To report to School any non-functioning lights.	Yes No NA	01/06/2021	
3	UNDER FLOOR / RAISED FLOOR TRUNKING			
1	Check the cover and internal free from obstruction. Replace cover when necessary.	✓ Yes ☐ No ☐ N/A	01/06/2021	
2	Check all connections and cabling condition.	Yes No NA	01/06/2021	
3	Check and replace seal when necessary	✓ Yes No NA	01/06/2021	
4	HAND DRYERS/BLOWERS/ HAIR DRYERS/WATER HEATERS			
1	Check and ensure that the systems are working.	Yes No NA	01/06/2021	
2	Check and tighten all the mechanical mounting.	✓ Yes No No NA	01/06/2021	
5	SERVICING AND INSPECTION OF LIGHTNING PROTECTION SYST			ı
1	Contractor to refill earth pit with sand to brim of pit if the As and when level of sand is found to be below brim.	✓ Yes 🗆 No 🗀 N/A	01/06/2021	
2	To check and verify that the Pit Cover is easily open and close neatly	✓ Yes □ No □ N/A	01/06/2021	
3	To check and verify Earth Pit Assembly is flushed with the surrounding surface	✓ Yes No NA	01/06/2021	
6	SERVICING, INSPECTION AND TESTING OF STAGE LIGHTING SY:	I STEM		
	The servicing and maintenance work of the stage lighting and system			
1	i. Maintenance (including cleaning, repair and replacement) of the system including all bulbs, console unit (control panel), dimmers, fixture & fittings etc.	Yes No NA	01/06/2021	
2	ii. Response to faults as directed.	✓ Yes No No NA	01/06/2021	
3	iii. Replacement of damaged, blown or faulty bulbs complete with wires and fuses, holders where necessary.	✓ Yes No NA	01/06/2021	
4	iv. Rectify unusual noise or vibration.	✓ Yes □ No □ N/A	01/06/2021	
7	SERVICING, INSPECTION AND TESTING OF MATV SYSTEM	163 160 1471	0 17 0 07 2 0 2 1	
1	To check antenna in good condition, no damage or defective parts	✓ Yes No NA	01/06/2021	
2	To check connectivity within the Site.	Yes No NA	01/06/2021	
8	SERVICING, INSPECTION AND TESTING OF SOLAR HEATERS			7
1	Wash the glass cover of the collector with clean water	Yes No No NA	01/06/2021	
2	Check heater element in working condition	Yes No No NA	01/06/2021	
3	Inspect storage tank and ensure cover for electrical booster is properly fixed to ensure no rainwater enters into the electrical component	Yes No NA	01/06/2021	
4	release will return to normal position and no leakage of water from the valve	▼ Yes □ No □ N/A	01/06/2021	
5	General inspection of pipes, valves to ensure that there is no leakage		01/06/2021	
9	QUARTERLY SERVICING, INSPECTION AND TESTING OF HIGH TE	NSION ELECTRICAL INSTALLATIONS		
1	Vacuuming and cleaning of the switch rooms and transformer rooms including removing accumulated water from cable chambers, trenches, etc.	Yes No NA	01/06/2021	
2	Inspect faulty lighting and power points.	▼ Yes □ No □ N/A	01/06/2021	
3	Inspect for leakage and cracks in floors, walls and ceilings.	▼ Yes □ No □ N/A	01/06/2021	
4	Inspect operation of dehumidifiers and room ventilation.	✓ Yes □ No □ NA	01/06/2021	
5	Replace defaced, damaged or missing "DANGER" signs.	✓ Yes No NA	01/06/2021	
6	Check all switch room and transformer room doors and locks.	Yes No NA	01/06/2021	
F-0		LALES I INO I INVA	01/00/2021	
7	Check condition of meter box and rectify as necessary a. Voltage of incoming breakers and all outgoing breakers for outgoing breakers with voltmeters b. Current of incoming breakers and all outgoing breakers for outgoing breakers with ammeters.	▼ Yes □ No □ N/A	01/06/2021	
8	Check the status of all the incoming and outgoing breakers.	✓ Yes No No NA	01/06/2021	

S/N	ITEM	DONE? (Yor Nor NA)	Date Done	Remarks
9	Conduct checks for the following: a. Signs of corrosion of switchboards and transformers. b. Unusual smell which indicates overheating. c. Unusual noise indicating wong discharge. d. Replace any blown indicating bulbs and to replace other small parts on the switchboards which are faulty. e. Replace rubber mats which are tom or in a deteriorated condition.		01/06/2021	
10	Inspect the DC supply system for the HT switchgears for the following (where applicable): a. Top up the electrolyte level of the battery cells b. Check and record the charging current and voltages of the battery charger. c. Record temperature of individual cell electrolyte. d. Check battery cell, plates, etc. for any abnormality, etc. e. Cean battery terminals thoroughly and apply fresh petroleum jelly.	▼ Yes □ No □ N/A	01/06/2021	
11	Inspect the following for the transformers a. Record the readings of the oil temperature and level. b. Record the readings of the oil pressure gauge. c. Tank, radiators, auxiliary equipment and other metal parts for corrosion, abnormalities, etc.	▼ Yes  No  NA	01/06/2021	
10	SERVICING & INSPECTION OF CCTV SYSTEM (MK and KCARE)			
	Camera Lens	F., F., F.,	0.4.10.0.10.0.1	
1	Check the camera lens is focused and adjusted properly.	Yes No No NA	01/06/2021	
2	Check the camera view hasn't been knocked off path and you can see your property perimeter clearly	✓ Yes No No NA	01/06/2021	
3	Clean any dust or marks off the camera lens with a can of compressed air and wipe down the camera casing with a microfibre doth	Yes No No NA	01/06/2021	
4	Check that the motion detection sensors are working, if you have them	✓ Yes ☐ No ☐ N/A	01/06/2021	
5	Use your controller to check that the camera's functions, such as zoom land pan are working correctly	Yes No NA	01/06/2021	
6	Trim back any foliage that may be obscuring the view	Yes No NA	01/06/2021	
7	Check that the cameras are securely attached to the wall	Yes No NA	01/06/2021	
	Wiring			
8	Check wiring for any wear and tear or exposed wires	✓ Yes No No NA	01/06/2021	
9	Check for loose wires	Yes No NA	01/06/2021	
10	Check that you're getting a clear transmission of sound (where applicable) and picture with no distortion	✓ Yes ☐ No ☐ N/A	01/06/2021	
	Monitors and recording equipment			
11	Check that the monitors are showing a clear picture and that the brightness and contrast settings are correctly adjusted	Yes No NA	01/06/2021	
12	Check all switches and individual equipment are functioning fully	✓ Yes ☐ No ☐ N/A	01/06/2021	
13	Clean all monitors and equipment of dust and grime with a microfibre cloth and a weak cleaning solution	Yes No NA	01/06/2021	
14	Check cables leading from the equipment are in good condition and that there are no weak connections	Yes No NA	01/06/2021	
15	Check that the correct time and date stamp is set	Yes No NA	01/06/2021	
	•	•		

Checked By Endorsed By Verified By

(Anandh)

THE CONTRACTOR

Date: 01/06/2021

Remarks: done

(OM) USER

Date: 01/06/2021 Remarks: ok (Mani)

MANAGEMENT AGENT

Date: 02/06/2021 Remarks: done