

TASKCARD

A/C TYPE	Effectivity	DESCRIPTION							WORK ORDER NO.	
		737NG - DAILY CHECK.								
A/C REG.	A/C MSN.	ACCESS							TASKCARD NO.	
									B789-05-INT-02-01-IDN	
A/C TSN.	A/C CSN.	192G	413AL	414AR	423AL	424AR			THRESHOLD	INTERVAL
:										
OPERATOR	PLACE	ZONE							TASK	REVISION
		211	212	414	424	531	532	631	DET	39
		632	713	734	744					
START DATE	FINISH DATE	NOTE							ATA	SKILL
		☐ ETOPS ☐ RVSM ☐ RNP10 ☐ RII ☐ CDCCL							05	

REFERENCE			
Doc No.	Doc Description	Doc No.	Doc Description
AMM 12-13-21-200-801	IDG Oil Level Check	AMM 12-13-21-600-801	IDG Servicing (Oil Fill)
AMM 12-15-21-210-801	Crew Oxygen Cylinder Dispatch Pressure Check	AMM 12-15-51-610-802	Add Nitrogen or Air to the Tire
AMM 32-00-01-480-801	Landing Gear Downlock Pins Installation	EA B737NG-EI-34-226	PITOT PROBE COVER
AMM 24-34-00-710-801	The Operational Test of the Standby Power System	SRM 51-10-06	TAP TEST INSPECTION
AMM 30-41-41	Window/Pitot Heat Test	AMM 32-42-00-720-801	ANTISKID/AUTOBRAKE CONTROL UNIT OPERATIONAL TEST
AMM 34-43-00-860-145-002	WEATHER RADAR OPERATIONAL TEST	AMM 34-45-00-710-801	TCAS - OPERATIONAL TEST
AMM 73-21-00-740-803-F00	EEC BITE TEST - RECENT FAULTS	EA B737NG-EA-11-001R11	Installation Tire Pacard Servicing
EI GEN-E-35-083R1	LIMITATION PRESSURE OF PORTABLE OXYGEN BOTTLE MUST BE REMOVE FROM AIRCRAFT	FIM 31-62 TASK 801	BITE Procedure
FIM 32-09 TASK 801	PSEU BITE TEST	AMM 24-22-00-860-811	Supply Electrical Power
AMM 23-51-00-710-801	Flight Interphone System - Operational Test	AMM 23-12-00-710-801	VHF Communication System Operational Test
AMM 23-11-00-710-801	HF Communication System Operational Test	AMM 12-13-31-200-801	APU Oil Level Inspection
AMM 12-11-00-680-801	Fuel System Sumping	AMM 27-41-71-700-801	Stabilizer Trim Motor Test

TOOLS REQUIRED		
PART NUMBER	DESCRIPTION	QUANTITY
06-5022-6800	FLUID SERVICING UNIT, CAPACITY 2 GALLON, MAX. PRESS. 200 PSI FOR MINERAL BASE	1
1001089-1	COVER - PROBE, PITOT STATIC	1
14-6806-6011	TYRE PRESSURE GAUGE	1
3001331-1	TAP TEST TOOL	1
C32026-6	EQUIPMENT - DOWNLOCK, NLG AND MLG (FLYAWAY KIT)	1
F70199-1	TIRE INFLATION TOOL	1
F80201-1	DRAIN TL	1
H3310	HEADPHONE - 600 OHM, WITH 1/4 INCH MONO RCAAUDIO PLUG / GROUND HEAD SET	1
SPC-101	STATIC PORT COVER	1
SPC-102	STATIC PORT COVER	1

BARCODE:  B789-05-INT-02-01-IDN

TASKCARD

WORK ORDER NO.	A/C REG.	A/C MSN.	A/C Effectivity	OPERATOR	TASK CARD NO.
					B789-05-INT-02-01-IDN

TOOLS REQUIRED		
PART NUMBER	DESCRIPTION	QUANTITY
SPL-1880	EQUIPMENT - DOWNLOCK, NLG AND MLG (FLYAWAY KIT)	1
STD-1056	CONTAINER - SOLVENT RESISTANT, 5 GALLON (19 LITERS)	1

MATERIAL REQUIRED		
PART NUMBER	DESCRIPTION	QUANTITY
141A6076-3	PIN - GUIDE ARM, FORWARD ENTRY DOOR	1
141A6077-2	WASHER	1
44250	HIGH PURITY 44 MARKER, COLOR BASED ON PART NUMBER	1
AEROSHELL GREASE 33	AIRCRAFT GENERAL PURPOSE GREASE, PASTEBMS3-33 TYPE 1	1
AEROSHELL-FLUID-41	FLUID - LANDING GEAR SHOCK STRUT	1
ALCOHOL-70	ISOPROPYL ALCOHOL, REAGENT GRADE	1
BACS12ER08K6	SCREW	1
CP2442	OIL	1
G00018	NITROGEN BOTTLE	1
LOCTITE 242	THREADLOCKING ADHESIVE - MEDIUM STRENGTH	1
LOCTITE 7649	SOLVENT-BASED PRIMER	1
MAJUN	CLOTH - CLEAN, DRY, LINT-FREE, WHITE, COTTON	1
MJOILII	OIL	1
NASM20995	OXIDIZED INCONEL LOCKWIRE DIA 0.032 INCH	.2
SKYDROL PE-5	FLUID - HYDRAULIC, EROSION ARRESTING, FIRE RESISTANT	1

ACCOMPLISHMENT			
NO.	INSTRUCTION	PERFORMED BY	INSPECTED BY
1	APPLICABLE FOR: MLI, ETJ and GEF - ALL The 36 Hour Check (elapsed clock hours – ECH) or known as Daily Check is more comprehensive than the Preflight Check. The Daily Check shall be performed once per calendar day (Accomplishment not to exceed 36 calendar hours).		
2	JOBSET-UP : (1) Ensure that aircraft arrival and parking areas are cleared of debris and obstructions. (2) Supply electrical power source 115 V (+5 V), 400 Hz (+20 Hz). Do this task: Supply Electrical Power AMM TASK 24-22-00-860-811. (if required). Source From APU [.....] or GPU [.....] (3) Install nose and main landing gear ground lock pins. Do this task : Landing Gear Downlock Pins Installation. AMM TASK 32-00-01-480-801	A/P	
3	PROCEDURE. A. Aircraft Maintenance Logs. (1) Review AFML, CML, NSRDI, DBC, DBCS (2) Review deferred maintenance items, log and correct as necessary	A/P	
4	B.Fuselagelnspections	A/P	

BARCODE:  B789-05-INT-02-01-IDN

TASKCARD

WORK ORDER NO.	A/C REG.	A/C MSN.	A/C Effectivity	OPERATOR	TASK CARD NO.
					B789-05-INT-02-01-IDN

ACCOMPLISHMENT							
NO.	INSTRUCTION	PERFORMED BY	INSPECTED BY				
	(1) Check fuselage access / service panels, cabin windows, hatches, navigation / communication antennas and radome from ground level for obvious damage and security. (2) Do general visual inspection of the FWD Cargo Compartment & AFT Cargo Compartment (3) Check (Crew) oxygen blowout disk (green) for security. (4) Perform walk-around visual check of airframe, wings and tail for condition, security and evidence of fluid leaks (5) Check landing gear, gear doors, wheel-wells and installations for general condition and security (6) Check pitot tubes and static ports for damage or obstructions (7) Check static dischargers for condition and security (8) Check exterior lights and lens for condition, security, or burned out bulbs (9) Check all external required placards. Replace or install any damaged or missing required placards. (10) Extend LH & RH trailing edge flaps to the 40-unit position. RESULT:						
5	C.FlightCompartmentInspections. (1) CrewOxygen Cylinder Dispatch PressureCheck RESULT: (2) Do an APU Oil Level Inspection by using APU BITE Procedure (3) Record APUhours and cyclesfromAPUDMMviaCDU. <table><tr><th>APU Hours</th><th>APU Cycles</th></tr><tr><td></td><td></td></tr></table> (4) Check all circuit breakers, switches, guards with safety wire and controls for normal position prior to leave the cockpit. (5) Check all cockpit lights (6) Check flight compartment and windows for condition and cleanliness RESULT: (7) Check IDG disconnect switch for condition and security guarded and wired). (8) Check emergency, safety equipment and Medical / Doctor's Kit onboard for condition, security and validity (9) Check emergency exit windows and F/O emergency exit handles for condition and security (10) Operational test all exterior lights (11) These tasks below require IRS alignment. (12) Do the BITE procedure for maintenance messages in CURRENT STATUS on the CDS RESULT: (13) Stabilizer Trim Motor Test (14) Check all circuit breakers, switches, guards and controls for normal position prior to leave the cockpit. (15) Do general visual inspection Captain & First Officer seat for condition and security. (16) GRAY WATER / DRAIN SYSTEM CLEANING	APU Hours	APU Cycles			A/P	
APU Hours	APU Cycles						
6	D.PassengerCabinandGalleyInspection. (1) Visually check that all emergency exit hatches are secured and that handles are properly stowed. (2) Check passenger and emergency doors for condition and security RESULT: (3) Check aircraft emergency equipment for condition, proper pressure, safeties and security, including the following:	A/P					

BARCODE:

B789-05-INT-02-01-IDN

TASKCARD

WORK ORDER NO.	A/C REG.	A/C MSN.	A/C Effectivity	OPERATOR	TASK CARD NO.
					B789-05-INT-02-01-IDN

ACCOMPLISHMENT							
NO.	INSTRUCTION				PERFORMED BY	INSPECTED BY	
	a) Flight Compartment						
	Description	QTY	POS#	Available [YES/NO]	Valid Until		
	Halon Firext	1 ea	Cockpit				
	PBE	1 ea	Cockpit				
	Medical Kit	1 Box	Cockpit				
	b) Door						
	Description	QTY	POS#	Available [YES/NO]	Valid Until		
	Escape Slide	1 ea	Main Entry				
	Escape Slide	1 ea	Service Door FWD Service Door Aft R/H Service Door Aft L/H				
	Escape Slide	1 ea	MID Door L/H MID Door R/H				
7	c) Passenger Cabin					A/P	
	Description	QTY	POS#	Available [YES/NO]	Valid Until		
	Halon Firext	1 ea 2 ea	FWD AFT				
	Oxygen Bottle 5LB	1 ea	FWD				
	Oxygen Bottle 5LB	1 ea	FWD				
	Oxygen Bottle 5LB	1 ea	AFT				
	Oxygen Bottle 5LB	1 ea	AFT				
	Oxygen Bottle 5LB	1 ea	AFT				
	PBE	1 ea 1 ea 2 ea	FWD FWD AFT				
	H2O Firext	1 ea 1 ea	FWD AFT				
	First Aid Kit	1 ea 1 ea 1 ea	FWD AFT L/H AFT R/H				
	d) Lavatory						
	Description	QTY	POS#	Available [YES/NO]	Valid Until		
	Fire Extinguisher	1 ea 1 ea 1 ea	FWD AFT R/H AFT L/H				
	(4) Check all emergency exits for condition, security and proper operation						
	(5) Check evacuation slides (passenger entrance and galley service doors) for security, proper installation, air bottle pressure, proper instruction placards installed and validity.						
	(6) Check lavatories for general condition and operation. Lavatory water heater for proper operation. And waste bin door for proper operation						
	(7) Check lavatory temperature indicators for condition. Replace lavatory fire extinguisher bottles, if temperature indicators change color (white to black)						
	(8) LAVATORY DOOR HINGE PIN INSPECTION						
	(9) Check First Aid Kit (FAK) for sealing, damage and validity.						
	(10) Operational check of the Emergency Light (Ref. AMM 33-51-00-710).						
8	E.PowerPlantInspection					A/P	
	(1) Check engine cowling, inlet cowls, nose domes and visible fan blades for Obvious damage.						
	Engine Position	Engine #1		Engine #2			
	Platform Finding (please state if there is finding)						

BARCODE:

B789-05-INT-02-01-IDN

TASKCARD

WORK ORDER NO.	A/C REG.	A/C MSN.	A/C Effectivity	OPERATOR	TASK CARD NO.
					B789-05-INT-02-01-IDN

ACCOMPLISHMENT																																																														
NO.	INSTRUCTION				PERFORMED BY	INSPECTED BY																																																								
	or no, and state the platform position) (2) Check left and right engine oil quantity and service as required. (3) Detailed Inspection of IDG, delta P indicator, oil level and service as require																																																													
9	F.Wheel-WellInspections. (1) Clean exposed surfaces of the nose, left and right main landing gear shockstrut (MP Task 32-010-01, 32-010-02 and 32-060-00) (2) Inspect (General Visual) nose and main landing gear tires and wheels for condition and wear. (MP Task 32-360-00) (3) Visually check the left and right brake wear pins for minimum extension. (MP Task 32-270-01 and 32-270-02) (4) Measure the remaining indicator pin length for all brake assemblies and make record for the measurement <table border="1"> <thead> <tr> <th colspan="4">BRAKE WEAR PINS RECORD (in mm)</th> </tr> <tr> <th>#1</th><th>#2</th><th>#3</th><th>#4</th></tr> </thead> <tbody> <tr> <td></td><td></td><td></td><td></td></tr> </tbody> </table> (5) Check nose and main landing gear tires for proper inflation (MP 32-350-00). Service asrequired and record the pressure. (B737NG-EA-11-001R11) <table border="1"> <thead> <tr> <th colspan="4">NOSE TIRES PRESSURE</th> </tr> <tr> <th colspan="2">LEFT</th><th colspan="2">RIGHT</th> </tr> <tr> <th>Before Top- Up</th><th>After Top-Up</th><th>Before Top- Up</th><th>After Top-Up</th></tr> </thead> <tbody> <tr> <td></td><td></td><td></td><td></td></tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="4">MAIN TIRES PRESSURE</th> </tr> <tr> <th colspan="2">LH #1</th><th colspan="2">RH #1</th> </tr> <tr> <th>Before Top- Up</th><th>After Top-Up</th><th>Before Top- Up</th><th>After Top-Up</th></tr> </thead> <tbody> <tr> <td></td><td></td><td></td><td></td></tr> </tbody> </table> <table border="1"> <thead> <tr> <th colspan="2">LH #2</th><th colspan="2">RH #2</th> </tr> <tr> <th>Before Top- Up</th><th>After Top-Up</th><th>Before Top- Up</th><th>After Top-Up</th></tr> </thead> <tbody> <tr> <td></td><td></td><td></td><td></td></tr> </tbody> </table>				BRAKE WEAR PINS RECORD (in mm)				#1	#2	#3	#4					NOSE TIRES PRESSURE				LEFT		RIGHT		Before Top- Up	After Top-Up	Before Top- Up	After Top-Up					MAIN TIRES PRESSURE				LH #1		RH #1		Before Top- Up	After Top-Up	Before Top- Up	After Top-Up					LH #2		RH #2		Before Top- Up	After Top-Up	Before Top- Up	After Top-Up					A/P	
BRAKE WEAR PINS RECORD (in mm)																																																														
#1	#2	#3	#4																																																											
NOSE TIRES PRESSURE																																																														
LEFT		RIGHT																																																												
Before Top- Up	After Top-Up	Before Top- Up	After Top-Up																																																											
MAIN TIRES PRESSURE																																																														
LH #1		RH #1																																																												
Before Top- Up	After Top-Up	Before Top- Up	After Top-Up																																																											
LH #2		RH #2																																																												
Before Top- Up	After Top-Up	Before Top- Up	After Top-Up																																																											
10	G.WingsandBodyFairingInspections. (1) Drain fuel from sump drain to prevent water contamination (AMM 12-11-00-680)				A/P																																																									
11	H.Window/PitotHeatModule(P5-9)InstallationTest (1) Remove the safety tags and close these circuit breakers (2) On the captain's main instrument panel, P1, set the switch for the master dim and test lights to TEST. (3) On the captain's main instrument panel, P1, set the switch for the master dim and test lights to BRT. (4) Put the PITOT & PROBE HEAT switches to the ON position 2-5 minute. (5) Put the PITOT & PROBE HEAT switches to the OFF position.				A/P																																																									

BARCODE:

B789-05-INT-02-01-IDN

TASKCARD

WORK ORDER NO.	A/C REG.	A/C MSN.	A/C Effectivity	OPERATOR	TASK CARD NO.
					B789-05-INT-02-01-IDN

ACCOMPLISHMENT			
NO.	INSTRUCTION	PERFORMED BY	INSPECTED BY
	(6) Put the PITOT & PROBE HEAT switches to the AUTO position. (7) Make sure the pitot heat indications on the module come on. (8) Put the WINDOW HEAT switches to the ON position. (9) Select the OVERHEAT position on the POWER AND OVERHEAT TEST switch, S7. (10) Set the WINDOW HEAT and POWER AND OVERHEAT TEST switches to the off position. (11) Install all cover pitot probe, static port P/N : S/N :		
12	-----END OF TASK-----		

START TIME(UTC)	FINISH TIME(UTC)	TOTAL MAN HOUR		DEFECT FOUND M.D.R.R. No:	Y	N
		EST.	ACTUAL			
		2.75				

TASK CARD RELEASE

DATE (UTC) : TIME (UTC) : SIGNATURE : AUTHORIZATION NO. :

BARCODE:



B789-05-INT-02-01-IDN