Task	Task Description – DURING THE SCHEDULING OF THIS	ОК	Not OK (If Not	Completed By
No.	TRUCK IF YOU ARE UNSURE OF ANY OF THE CHECKS		OK, Rectify Or	
	YOU MUST REFER TO THE SERVICE MANUAL FOR		Notify M.E	
	CLARIFICATION			
	Dotto			
1	Check condition of battery / all terminals and tank			П
2	Check condition and operation of emergency			
	disconnect			
3	Check condition and security of battery cables and plug			
4	Check security and operation of electrolyte level blinkie			
5	Check condition of top up system			
6	Check condition of air circulating pipework			
	Drive Unit/Axlo	е		
7	Check for any oil leaks			
8	Check security.			
9	Check security of drive wheels LHS & RHS			
10	Check condition of tyres (min of 10mm from wear line)			
11	Check security of drive motors (2off).			
12	Check condition and security of motor brushes.			
13	Check condition of armature			
14	Blow out motor using dry compressed air			
15	Check oil level.			
16	Check security and condition of all power cables			
	Brakes			
17	Measure the brake lining wear (refer to service manual)			
18	Check security and operation of all brake linkages			
19	Check brake pedal travel and adjust if required (refer to			
20	service manual)			
20	Check condition / operation and security of footbrake switch			
21	Check condition / security and operation of hand brake			
22	Check the hand brake is set correctly (refer to service			
	manual)			
23	Check condition and security of handbrake cable.			
24	Lubricate all handbrake linkages			
25	Check for correct stopping distance when footbrake is			
	operated (approx. 2.1M max) Steering			
26	Check the steering hydraulic system for leaks and			
20	security			
27	Check condition / operation and security of steering			
20	Charles and division / apparation and apparity of atomics			
28	Check condition / operation and security of steering wheel			
29	Check condition, operation and security of steer			
	encoder			
30	Check steer drive unit for leaks.			
31	Check security of steer drive unit.			

Task No.	Task Description – DURING THE SCHEDULING OF THIS TRUCK IF YOU ARE UNSURE OF ANY OF THE CHECKS YOU MUST REFER TO THE SERVICE MANUAL FOR	ОК	Not OK (If Not OK, Rectify Or Notify M.E	Completed By
	CLARIFICATION		Notify Wile	
	Steering Continu	ed		
32	Check security operation and condition of steer			
22	potentiometer Charles a surity and association of standard and a surity and a sociation of standard and a surity as a s			
33	Check security and condition of steer axle			
34	Check condition and security of steer axle wheel bearings		Ш	
35	Check security of wheels.			
36	Check condition of tyres (min of 10mm from wear line)			
	Hydraulics	T		
37	Check pump for security and leaks			
38	Check security of motor			
39	Check condition and security of motor brushes			
40	Check condition of armature			
41	Blow out motor using dry air			
42	Check condition and security of all cables			
43	Check security / condition and operation of all hydraulic levers.			
44	Check all associated pipework security / condition and for leaks.			
45	Check for leaks and security of valve control block			
	Mast/Carriage			
46	Check condition of mast channels			
47	Clean mast channels and re grease			
48	Check condition / security and performance of mast rollers			
49	Check for any movement or play on mast pivot points			
50	Check for leaks / performance and security of tilt cylinders			
51	Grease tilt cylinder pivot points			
52	Check for leaks / performance and security of lift cylinders			
53	Check security of mast to chassis mounting bolts.			
54	Grease mast pivots (2off)			
55	Check condition / security and operation of all chain and hose pulleys			
56	Clean carriage and re grease			
57	Check security / condition and operation of carriage			
58	Check condition / security and performance of carriage rollers			
59	Check for leaks / performance and security of side shift cylinder			
60	Grease side shift (2off)			
61	Check free movement of carriage forks when adjusting position			

Task	Task Description – DURING THE SCHEDULING OF THIS	ОК	Not OK (If Not	Completed By
No.	TRUCK IF YOU ARE UNSURE OF ANY OF THE CHECKS		OK, Rectify Or	
	YOU MUST REFER TO THE SERVICE MANUAL FOR CLARIFICATION		Notify M.E	
	Lift Chains - Check chain stretch using	chain s	zauge MTI 0268	
	Elit Cham's Check Cham's Cretch asing	, criairi e	Guage Willedzoo	
Chai	n wear at 2% new chains should be ordered immediately.	Chains	worn at 3% chains sh	ould be ordered and
	truck removed form service. If in doubt fo	llow cha	in gauge instruction	<u> </u>
62	Clean chain to ensure efficient inspection			
63	Check security and condition of chain anchor points			
64	Check chain links for easy movement			
65	Check lift chains are equally tensioned when taking the			
	weight of the carriage			
66	Chain gauge Calibration check			
67	Chain check points:			
	Section over chain sheave percentage wear			
68	Chain check points:			
60	Section above carriage percentage wear			
69	Chain check points: Section midway on chain percentage wear			
70	Lubricate chain			
70	Forks			
71	Clean chain to ensure efficient inspection			
72	Check security and condition of chain anchor points			
73	Check chain links for easy movement			
74	Check lift chains are equally tensioned when taking the			
	weight of the carriage			
75	Check security and condition of load guard			
76	Check each fork for damage and distortion			
77	Check condition and operation of each fork locking pin			
78	Check fork wear by measuring the thickness of the fork			
	shank and then approx. 100mm in from the front shank			
	face measure the thickness of the fork blade if the			
	difference between the shank and blade measurement			
	is more than 10% the forks must be replaced. Percentage fork wear:			
	Control Panel			
79	Clean control panel using dry air			
80	Check security of all terminals			
81	Check condition of all cables & control wiring			
82	Check security and condition of all contacts / contactors			
83	Check security of control unit and associated plugs			
84	Check condition and security of controllers and plugs			
85	Check security and condition of all fuses			
	Electrical			
86	Check security and operation of mast lift limit switch			
	when fitted.			
87	Check security & operation of tilt ram switches when			
	fitted			

Task	Task Description – DURING THE SCHEDULING OF THIS	ОК	Not OK (If Not	Completed By	
No.	TRUCK IF YOU ARE UNSURE OF ANY OF THE CHECKS		OK, Rectify Or		
	YOU MUST REFER TO THE SERVICE MANUAL FOR		Notify M.E		
	CLARIFICATION				
	Electrical Contin	ued			
88	Check condition, security and operation of BDI. Take				
	hours run reading :			<u> </u>	
89	Check condition, security and operation of FWD / REV				
- 00	selector.				
90	Check condition & operation of brake override plug				
91	Check horn is functioning and audible				
92	Check operation and condition of beacon & lights				
General					
93	Check all decal is readable and in place		<u> </u>	<u> </u>	
94	Check the capacity plate is in place and readable				
95	Check condition and security overhead guard				
96	Check all covers for security and damage				
97	Check condition and operation of battery hood				
98	Check operation, condition and security of seat				
99	Check security, operation and condition of seatbelt				
100	Truck is clean and ready for service				
101	Check condition and security of floor plates				
Comments, Note Mask Number Adjacent To Any Issues Found					