



QUOTE

Advance Insulation Canada

PO BOX 48158 RPO Uptown
 Victoria, BC V8Z 7H6
 TF: 855-531-3626
 D: 778-229-4739
 info@advanceinsulation.ca

DATE: 01/08/2026
QUOTE # 15620R
BILL TO: Richard Fremmerlid
 1517 San Juan Ave
 Victoria, BC
 (250) 885-7003

Spray Foam Insulation Services at 1517 San Juan Ave, Victoria, BC

DESCRIPTION	AMOUNT
Mobe and demobe crew and equipment to site	
Install pylons, flag, and tag the work area	
Erect barriers and necessary hoardings to prevent overspray	
Isolate work area and post warning signs to advise anyone entering that they must be wearing proper respiratory masks during and 24 hours after all spray foaming is installed. Applicator will advise all parties with written notice when it is safe to enter area without respiratory equipment	
Perform adhesion and cohesion tests as necessary	
AIC will wait appropriate times between passes	
Extract attic insulation in entire attic space total 1680 SF with extractor vacuum disposing product into extraction bags	
Remove existing baffles at eaves and dispose	
Remove existing 3ml vapour barrier and dispose	
Install new Cora vent baffles at the eaves (doubles) in every truss opening X80	
Install ROXUL insulation directly below the baffles to act as an insulation stop and substrate for the spray foam to adhere to	
Install ROXUL insulation around kitchen range hood vent (spray foam to cover)	
Install ROXUL insulation above all ceiling lights (spray foam to cover)	
Install 2" foil back foam board insulation above the bathroom fan base (spray foam to cover)	
Install 2lb closed cell spray foam insulation on attic floor total 1680 SF to 2" (blow-in insulation to cover)	
Remove existing bathroom fan duct and replace with new 4" ducting with insulated wrap	
Seal, tape and attach at base	
Connect to existing outtake vent where currently located	
Install fiberglass batt insulation below lower intake vents	
Install fiberglass blow in attic insulation total 1680 SF to R40 above the spray foam insulation on the attic floor (Product to be used OC Pro Pink) Combined product will achieve overall R50	
Build up attic hatch framing to 18" with conventional lumber	

DESCRIPTION	AMOUNT
Install new weather-stripping on attic hatch	
Install 6" rigid foam on attic hatch	
Install R28 batt insulation above attic hatch	
Full site clean up of work area	
<i>A/C will not be held liable for any ventilation issues re intake/outtake that may arise in the future</i>	
Recommendations:	
<i>Certified Roofer to inspect all roof surfaces and report to client</i>	
<i>Certified Roofer to inspect roof for ventilation and report to client</i>	
Disclaimer	
<i>We warrant our product for a term of one year from date of completion. This includes, only the installation of our product and we are not responsible for any faulty workmanship of other companies involved or previously involved in the building/renovation of your property. We guarantee our product and the install of our product and ensure every precaution is taken to ensure no issues arise in the future. We are not liable for any water damage to the interior or exterior building or premises upon or in which such work is done; or any damage to said work cause by settlement, shifting, expansion, moving, warping, distortion, or failure of any structure, roof deck, walls, floors, ceilings, or foundations of said building. Full terms and conditions can be viewed at www.advanceinsulation.ca</i>	
Quote is valid for 30 days	SUBTOTAL \$10,480.00
Contractor to ensure surfaces to receive spray foam are free from oil, dirt, and any other foreign substance that may inhibit bonding. Owner is to ensure electrical power, clean water, lighting are provided. Area is to be vacated during and 24 hours after foam has been sprayed. We arrive with a self sufficient system, the spray rig carries 40KV generator which constantly makes 90-100 DB sound. Make all cheques payable to Advance Insulation Canada.	TAX RATE 5.00%
	SALES TAX \$ 524.00
	TOTAL \$ 11,004.00
	
GST #773780085RT0001	WCB# 075381