SERNEM HEALTH & SAFETY RESOURCES	METHOD STATEMENT WORKING AT HEIGHT	Document No	SRN-MS-001
		Revision	1.0
		Date	2026-10-21

PROJECT	İ ı Ş ş Ğ ğ Ç ç Ö ö Ü ü — P11 Fixture	COMPANY	-
LOCATION	-	ACTIVITY	**Working at Height**

1. SCOPE OF WORK

This Method Statement defines the safe method for planning work at height, providing safe access, preparing the work area, selecting appropriate fall-prevention or fall-arrest systems, performing the work under controlled conditions and leaving the area safe after completion.

2. RESPONSIBILITIES

Site Supervisor: Plans the work, verifies the work area and access method, confirms worker competency and supervises implementation.
HSE Personnel: Supports risk assessment, field verification and implementation of safety requirements.
Workers: Follow the approved work method, inspect equipment before use and immediately report changing or unsafe conditions.

3. COMPETENCY & TRAINING

Personnel performing work at height shall have suitable training, knowledge and experience for the task. Workers using fall-protection equipment shall understand its correct use, inspection and limitations. Supervisors shall understand the work method and rescue arrangements.

4. PPE

- Safety helmet
- Safety footwear
- Work gloves
- Suitable work clothing
- Task-appropriate eye protection
- Full-body harness and suitable lanyard / fall-arrest connection where required by the risk assessment

5. TOOLS & EQUIPMENT

- Suitable work platform / scaffold / MEWP or other safe access system
- Guardrails and edge-protection systems
- Approved anchorage points
- Full-body harness and suitable connecting equipment
- Tool lanyards / dropped-object prevention equipment
- Barricades and warning signs
- Required rescue equipment

6. PERMITS / PTW

Any permits required by site or project procedures shall be obtained and verified before work starts. The risk assessment, applicable work-at-height authorization and simultaneous activities shall be reviewed.

7. PRE-WORK REQUIREMENTS

- Determine whether work at height can reasonably be avoided.
- Review the task-specific risk assessment.
- Inspect the work area, work height, surface conditions and access.
- Consider collective fall-prevention measures first.
- Verify the suitability of scaffold, platform, MEWP or other access equipment.
- Identify open edges, openings and fragile surfaces.
- Control dropped-object exposure below and establish an exclusion zone where required.
- Inspect fall-protection equipment and anchorage points before use.
- Confirm weather conditions are suitable for safe work.
- Verify the rescue plan and rescue equipment are ready.

8. PRE-TASK RISK CONTROLS

Critical Hazard	Required Control	Verification
Fall from height	Suitable work platform, guardrail system or approved personal fall-protection system shall be available as required by the risk assessment.	Supervisor field verification
Dropped objects	The area below shall be barricaded where required, loose materials secured and tool lanyards used where appropriate.	Exclusion-zone / housekeeping check
Unsafe access or platform	Scaffold, platform, MEWP or other access system used for the task shall be checked for suitability before work starts.	Competent-person / equipment check
Adverse weather	Wind, precipitation, visibility and surface conditions shall be confirmed suitable for safe work.	Pre-work site assessment
Rescue requirement	Where suspension following a fall is possible, a suitable rescue method, equipment and responsible personnel shall be identified in advance.	Rescue plan available

9. METHOD / SEQUENCE OF WORK

No	Work Sequence	Hazards	Control Measures	Responsible
01	Plan the task and determine whether work at height is necessary.	Unnecessary work at height, inadequate planning, unsuitable access method.	Perform the task from ground level where reasonably practicable. Where work at height is necessary, select suitable access and fall-prevention measures based on the risk assessment.	Site Supervisor / HSE
02	Prepare the work area and safe access route.	Slip, trip, open edge, floor opening, fragile surface and unsafe access.	Keep access routes clear. Protect open edges and openings using suitable guardrails or secure covers. Identify fragile surfaces and control access.	Site Supervisor

No	Work Sequence	Hazards	Control Measures	Responsible
03	Inspect the work platform and work-at-height equipment.	Damaged platform, unsuitable scaffold, equipment failure or loss of stability.	Confirm equipment is suitable, stable, appropriate for the working conditions and has received the required inspections. Remove defective equipment from service.	Competent Person / Supervisor
04	Establish fall-prevention and, where required, personal fall-protection systems.	Fall from height, unsuitable anchorage, inadequate fall clearance or swing fall.	Prioritise guardrails, safe platforms and other collective protection. Where personal protection is necessary, use suitable anchorage, full-body harness and task-appropriate connecting equipment. Assess fall clearance and swing-fall exposure.	Supervisor / Worker
05	Control dropped-object risk and secure the area below.	Tools or materials falling to a lower level and striking personnel.	Keep tools and materials away from edges and secure them where required. Use tool lanyards. Barricade the danger area below and coordinate simultaneous activities.	Supervisor / Worker
06	Perform the work in accordance with the approved method.	Loss of control, unsafe behaviour, changing site conditions or failure of protection systems.	Remain within the designated work area. Do not remove or alter protective systems. Stop work and reassess the method if conditions change.	All Workers / Supervisor
07	Close out the work area safely after completion.	Materials left behind, exposed edges, uncontrolled access or dropped objects during dismantling.	Remove tools and materials. Temporary protection shall only be removed in a controlled manner after the area has been left permanently safe. Conduct a final inspection.	Supervisor

10. EMERGENCY ARRANGEMENTS

A pre-planned rescue method shall be available for any person suspended following a fall. Rescue equipment shall be accessible at the work area and the responsibilities of rescue personnel shall be defined. In an emergency, stop work, secure the area and follow the site emergency procedure.

11. ENVIRONMENTAL CONTROLS

Prevent materials and waste from falling from height. Secure loose materials against wind. Remove waste to designated areas after work. Prevent uncontrolled release of oils, chemicals or other substances to ground or drainage systems.

12. REFERENCES

- SERNEM task-specific risk assessment
- HSE – Working at Height guidance
- HSE – Assessing all work at height
- Project / site HSE procedures
- Manufacturer instructions for equipment used

13. APPROVAL

Prepared By	Reviewed By	Approved By
- Signature / Date	**-** Signature / Date	**-** Signature / Date