

January 23, 2014

To whom this may concern,

SolarRoofHook is committed to excellence. All of our parts were tested by a third party test facility for the following.

- Uplift test
- 2. Downward load test
- 3. Water Proof QuickBOLT only

AME Research facility had a current engineer license per the State of California in 2012 and 2013. Terrapin Testing had a current engineer license per the State of California in 2011.

The following is an excerpt from:

CALIFORNIA BOARD FOR PROFESSIONAL ENGINEERS AND LAND SURVEYORS g u i d e to Engineering & Land Surveying for City and County Officials

Page 12. Line 27

27. If the license has expired between the time the engineering documents were prepared and the time when the local agency's review is performed, do the documents need to be re-sealed by a licensee with a current license? (B&P Code §§ 6735, 6735.3, 6735.4)

As long as the license was current at the time the engineering documents were prepared, the documents do <u>not</u> need to be re-sealed prior to review by the local agency. However, any changes (updates or modifications) to the documents that are made following the review by the local agency would have to be prepared by a licensed engineer with a current license and those changes would have to be signed and sealed.

We trust the information provided will alleviate any respect for the test reports submitted to have a stamp from the current year.

Respectfully,

Rick Gentry

V.P. of Sales & Marketing

5830 Las Positas Rd | Livermore, CA 94551 Phone: (844)-671-6045 | Fax: (800)-689-7975 www.solarroofhook.com









QUICKBOLT INSTALLATION INSTRUCTIONS











RECOMMENDED MATERIALS

- Rafter locater
- Chalk or crayon
- 3/16" Drill Bit
- Sealant

INSTALLATION INSTRUCTIONS

- 1. Locate and mark the rafters.
- 2. Predrill the hole with the 3/16" Drill Bit.
- 3. Fill the predrilled hole & make a circle around the hole with sealant.
- Place the EPDM Washer & drive the Bolt until the Washer compresses to the roof.
- Secure the L-Foot using the two Flange Nuts.

WHERE IS MY FLASHING?

The Stainless Steel backed EPDM Washer is fully Code-Complaint and does not require additional Sheet Metal Flashing. The collar on the QuickBOLT compresses the washer down onto the roof, forming a watertight seal.

INSTALLATION VIDEOS, SPEC SHEETS, & TEST RESULTS AVAILABLE ON

WWW.SOLARROOFHOOK.COM

MOUNT SHEET