

The screenshot displays the MATLAB environment with the following components:

- Figure Window:** A bar chart titled "5G NR Subcarrier Spacing for Different Numerologies". The y-axis is labeled "Subcarrier Spacing (kHz)" and ranges from 0 to 250. The x-axis is labeled "Numerology Index (μ)" and ranges from 0 to 4. The bars represent the subcarrier spacing for each index: Index 0 is approximately 15 kHz, Index 1 is 30 kHz, Index 2 is 60 kHz, Index 3 is 120 kHz, and Index 4 is 240 kHz.
- Editor Window:** Shows the MATLAB script for the figure. The code is as follows:

```
4  
5 % 5G NR Numerology  
6 scs = [15 30 60 120 240]; % Subcarrier Spacing (kHz)  
7 mu = 0:4; % Numerology Index  
8  
9 % Bar graph  
10 bar(mu, scs)  
11 grid on  
12  
13 % Labels and title  
14 xlabel('Numerology Index (\mu)')  
15 ylabel('Subcarrier Spacing (kHz)')  
16 title('5G NR Subcarrier Spacing for Different Numerologies')  
17  
18 % X-axis ticks
```
- Command Window:** Shows the prompt ">>" and a message: "New to MATLAB? See resources for [Getting Started](#)."
- Workspace:** A table showing the variables defined in the script:

Name	Value	Size	Class
mu	[0,1,2,3,4]	1x5	double
scs	[15,30,60,120,240]	1x5	double

MATLAB

sriyukthesh100-5G6GLab/5G-6

MIMO Simulation Fix

+

Ask Gemini

matlab.mathworks.com

HOMEPLOTSAPPSFIGUREFORMATTOOLS

Search (Ctrl+Shift+Space)

Save AsCopy FigurePrintShow Code

FILE

TITLESubTitleX-LabelY-LabelZ-LabelLegendColorbarGridX-GridY-Grid

LABELS AND ANNOTATIONS

MATLAB Drive

Files

Name

SlotC_Exp2b.m

SlotC_Exp2c.m

SlotC_Exp3.m

SlotC_Exp4a.m

SlotC_Exp4b.m

SlotC_Exp4c.m

SlotC_Exp5a.m

SlotC_Exp5b.m

SlotC_Exp5c.m

SlotC_Exp6a.m

SlotC_Exp6b.m

Workspace

Name	Value	Size	Class
scs	[15,30,60,120...	1×5	double
slot	[1,0.5000,0.2...	1×5	double

SlotC_Exp6b.m

```
close all;

% 5G NR Subcarrier Spacing (kHz)
scs = [15 30 60 120 240];

% Slot Duration (ms)
slot = [1 0.5 0.25 0.125 0.0625];

% Plot
plot(scs, slot, 'o-', 'LineWidth', 2)

grid on

xlabel('Subcarrier Spacing (kHz)')
ylabel('Slot Duration (ms)')
```

Figure 1

5G NR Slot Duration for Different Subcarrier Spacing

Subcarrier Spacing (kHz)	Slot Duration (ms)
15	1.0
30	0.5
60	0.25
120	0.125
240	0.0625

Command Window

New to MATLAB? See resources for [Getting Started](#).

>>

32°C
Light rain

Search

ENG
IN

10:16
13-08-2026