cse321-project-3

Timothy Erckert

This markdown file is included in my repository. Some external file links and images may not work if not viewed from outside of the repo.

Table of Contents

- cse321-project-3
 - Table of Contents
 - About
 - Program Overview
 - Features
 - Required Materials
 - Getting Started
 - Resources and References
 - External References
 - Files
 - lcd1602.cpp | lcd1602.h
 - Declarations (Global Variables)
 - APIs and Peripherals
 - Interruptin
 - DigitalIn
 - Watchdog
 - Mutex
 - EventQueue
 - Thread
 - DigitalOut
 - Keypad
 - LCD
 - LEDs
 - Tilt Sensors
 - Buzzer
 - Custom functions
 - Program flowchart
 - Schematic

About

This project is a prototype of a device that will "save the world!" It's purpose is to help someone hone their fine motor skills. A simple digital level with LED and sound alarms to alter a user when it has begun tipping to far foward, backward, left, or right. They can use these indicators to bring it back to level.

Program Overview

Program will use 4 tilt sensors bent towards the four cardinal directions (with relation to the whiteboard, not magnetic) to detect whether what it has been placed on is level or not. LED's will be lit by default and will dim when skewed in that direction. This will also sound an alarm from the onboard buzzer. When the board has been brought back to level state, all lights will be lit once more and alarm will turn off.

The user has the option to silence the alarm feature by pressing 2 on the keypad, and can reactivate it by pressing 1. These options are displayed on the LCD screen.

Features

- 1. LCD screen menu
- 2. Visual and auditory alerts
- 3. Keypad input
- 4. Detects tilt when placed on a carried obect

Required Materials

Quantity	Item
1	Nucleo STM32L4R5ZI
1	1602 LCD
4	100ohm resistors
4	LEDs
1	4x4 Membrane Keypad
1	Solderless breadboard
4	Gikfun Metal Ball Tilt Shaking Position Switches
1	Arceli Passive Low Level Trigger Buzzer Alarm, 3.3-5v
	Female-to-male jumper wires
	Male-to-male jumper wires

Getting Started

To use the program the circuit must be built as detailed in the schematic section or by following pinout tables in peripheral sections.

It is **important** that when you are adding the tilt sensors they should be bent in the direction that they are going to be checking. I found the easiest way is inserting them into the breadboard and then pushing them outwards. Through testing, I have found an angle of 30-40 degrees works best, but you can bend them to whatever angle words best for you.

Build

- 1. Create a new project in Mbed Studio and include the following files:
 - o lcd1602.cpp
 - o lcd1602.h

- CSE321_project2_terckert_main.cpp
- 2. Attach Nucleo to PC and build project or build binary and manually add to Nucleo memory.
- 3. Enjoy!

Resources and References

External References

- Project Repository
- Nucleo API documentation
- Nucleo Reference Manual

Files

lcd1602.cpp | lcd1602.h

• Contains all the logic and functions necessary to use the LCD

Declarations (Global Variables)

APIs and Peripherals

Interruptin

Sets a pin as an interrupt. Program uses the following functions:

1. rise

Sets the rising edge callback function.

2. fall

Sets the falling edge callback function.

DigitalIn

Sets a pin to read in a high or low signal. These pins are used to detect input from the tilt sensors. They transmit a 1 when level and a 0 when skewed.

Variable Name	Pin
tilt_sensor_1	PA_7
tilt_sensor_2	PD_14
tilt_sensor_3	PD_15
tilt_sensor_4	PF_12

Watchdog

An internal timer that resets the microcontroller when a timer reaches 0.

1. get_instance

Initializes watchdog timer.

2. start

Starts the watchdog timer with the specified timeout period.

3. kick

Resets the watchdog timers timout period.

Mutex

Controls access to critical regions. A program will spin until it is able to acquire the lock, preventing it from continuing.

1. lock

Locks the mutex, preventing another thread from acquiring it and progressing.

2. unlock

Unlocks the mutex, allowing another thread to acquire it.

EventQueue

A function queue that allows multiple interrupts or threads to add to it. It is executed sequentially in a first in, first out style. It helps to control access to critical regions and also allows interrupts the ability to call blocking functions or functions could otherwise be corrupted.

1. call

Calls an event from the queue.

Thread

Allows for parallel execution of tasks.

1. start Starts a new thread. Calls a function and passes in parameters relevant to its execution.

DigitalOut

Allows writing high or low to a Nucleo pin.

Keypad

The keypad row pin is constantly energized to capture input. When pressed, 1 and 2 will send an interrupt signal to queue a function to change sound modes.

Row output	pin	Nucleo pin

Row: 1,2,3,A

F13

Column input pin	Nucleo pin
Column: 1,4,7,*	E13
Column: 2,5,8,0	F15

LCD

1602 LCD Datasheet

LCD controller class header file

Control logic for the LCD screen. Program uses the following functions:

1. begin

Setup logic for the LCD. Sets needed registers to get the LCD to display text.

2. clear

Clears the LCD screen.

3. setCursor

Sets the cursor to the designated spot on the LCD screen.

4. print

Prints the desired string to the LED.

LCD pin	Nucleo pin
SDA	FO
SCL	F1
VCC	F2
GRD	GRD

LEDs

LEDs are on by default when the tilt sensor is level. They turn off when the sensor detects tilt.

Tilt Sensors

Tilt sensors are simple switches controlled by a ball that is free to move inside the casing. They transmit high when the ball is seated at the base and low otherwise.

Sensor	Nucleo Pin
Tilt Sensor 1	A7
Tilt Sensor 2	D14

Sensor	Nucleo Pin
Tilt Sensor 3	D15
Tilt Sensor 4	F12

Buzzer

The buzzer is active low, meaning it sounds when the I/O pin is set to low. The buzzer is controlled by software which checks the inputs of all 4 tilt sensors. If any sensor input is low, buzzer sounds. When all are high, alarm is off.

Buzzer Pin	Nucleo Pin
VCC	E12
I/O	E14
GRD	GRD

Custom functions

Custom functions can be found here

1. initialize 1602

Provides power to the lcd and calls the LCD begin function, which initialize the LCD for use.

2. debounce_falling_edge

Debounces on the falling edge by waiting. Wait time is determined by physically testing thekeypad and a different keypad may have a different sweet spot.

3. process_column_one_interrupt

Rising edge interrupt for column one. Debounces rising edge with a wait. Queues function to change sound mode with a sound_on parameter

4. process_column_two_interrupt

Rising edge interrupt for column one. Debounces rising edge with a wait. Queues function to change sound mode with a sound_off parameter.

5. change_sound_mode


Added to an EventQueue by the keypad interrupts, this function will change the currentsound mode, allowing or restricting use of the buzzer as an auditory alert.

6. check_tilt_sensors

The main loop of the buzzer peripheral. Polls the inputs from the tilt sensors every10ms to determine if a sensor has detected tilt. This function also handles the watchdogtimer logic. If unable to aquire the buzzer_lock mutex within 120ms, it will restart theprogram. This value was chosen based on the

scenario that both a rising and falling edgeinterrupt paused the program for 50ms each at the start of a pole cycle.

Program flowchart



Schematic

