

NORMAL PROCEDURES CHECKLIST

Aircraft: _____

Cessna 172N | For Training Use Only | Ref: POH Section 4

FLIGHT INFORMATION

PIC Name		Student / SIC Name	
Aircraft Reg.		Date / Time	

⚠ WARNING: This checklist is for training use only. Always refer to the current approved POH/AFM for actual flight operations.

PREFLIGHT INSPECTION		TAXI		DESCENT	
☐ Fuel quantity (both tanks)	CHECK / QUANTITY	☐ Brakes — initial test	CHECK	☐ ATIS / current weather	OBTAIN
☐ Fuel caps	SECURE	☐ Turns — controls / AI	CHECK	☐ Altimeter	RESET (QNH)
☐ Fuel type (Avgas 100LL)	VERIFY	☐ Taxi speed	SLOW WALKING PACE	☐ Mixture	RICH (below 3,000 ft)
☐ Oil level	CHECK (min 4 qt, max 8 qt)	RUNUP [Completed Before Takeoff]		☐ Carb heat	ON (if icing conditions)
☐ Oil filler cap	SECURE	☐ Parking brake	SET	☐ Power	REDUCE GRADUALLY
☐ Engine compartment — leaks/debris	CHECK CLEAR	☐ Seats / belts	SECURE	BEFORE LANDING	
☐ Air intake / filter	CHECK CLEAR	☐ Doors / windows	CLOSED / LATCHED	☐ Fuel Selector	BOTH
☐ Propeller	NO NICKS / CRACKS	☐ Flight controls — free and correct	CHECK	☐ Mixture	RICH
☐ Spinner	SECURE	☐ Instruments	CHECK / SET	☐ Carb heat	ON
☐ Landing gear / tyres	CONDITION / INFLATION	☐ Fuel — sufficient / correct tank	BOTH / CHECK	☐ Seat belts / shoulder harness	SECURE
☐ Brake fluid	CHECK	☐ Mixture	RICH (below 3,000 ft)	☐ Landing lights	ON
☐ Nosewheel shimmy damper	CHECK CONDITION	☐ Throttle to 1,700 RPM	SET	☐ Airspeed (downwind)	90 KIAS
☐ Static port (both sides)	UNOBSTRUCTED	☐ Magnetos — L / R check (max 125 RPM drop, max 50 RPM diff)	CHECK	NORMAL LANDING	
☐ Pitot tube / cover removed	CLEAR	☐ Carb heat — note RPM drop	CHECK	☐ Final approach speed	65–75 KIAS
☐ Fuel drains (sump / strainer)	SAMPLE CLEAR	☐ Engine instruments	ALL GREEN	☐ Flaps	FULL (40°) as required
☐ Control surfaces — free / correct	CHECK	☐ Throttle (idle check)	RPM < 700	☐ Throttle (short final)	IDLE
☐ Flaps — travel and condition	CHECK	☐ Throttle	1,000 RPM	☐ Touchdown (main wheels first)	SMOOTH
☐ Antennas	SECURE / NO DAMAGE	☐ Radios / transponder	SET	☐ Nose wheel	HOLD OFF / LOWER GENTLY
☐ Stall warning vane	CHECK	☐ Lights (landing / strobes)	ON	☐ Braking	MODERATE
☐ Lights (nav/strobes/landing)	CHECK	☐ Flaps	SET FOR TAKEOFF	☐ Carb heat	OFF
☐ Windshield	CLEAN / UNOBSTRUCTED	☐ Brakes	HOLD FIRM	SHORT-FIELD LANDING	
BEFORE ENGINE START		☐ Takeoff clearance	OBTAINED	☐ Flaps	40°
☐ Aircraft documents (ARROW)	ON BOARD	NORMAL TAKEOFF		☐ Approach speed	61 KIAS
☐ Seat, seat belts, shoulder harness	ADJUST / SECURE	☐ Throttle	FULL SMOOTH	☐ Throttle	IDLE over threshold
☐ Doors / windows	CLOSED & LATCHED	☐ Mixture	RICH	☐ Braking (full)	MAXIMUM
☐ Brakes	TEST / HOLD	☐ Airspeed indicator	ALIVE (check)	SOFT-FIELD LANDING	
☐ Circuit breakers	IN	☐ Lift-off (Vr)	55 KIAS	☐ Flaps	40° (full)

☐ Avionics Master Switch	OFF
☐ Fuel Selector Valve	BOTH
☐ Master Switch (ALT & BAT)	ON
☐ Fuel quantity indicators	CHECK
☐ Lights — nav / beacon	ON
☐ Master Switch	OFF
ENGINE START	
☐ Throttle	OPEN 1/4 inch
☐ Mixture	RICH (below 3,000 ft)
☐ Fuel selector	BOTH
☐ Primer	AS REQUIRED / IN & LOCKED
☐ Master Switch	ON
☐ PROPELLER AREA	△ CLEAR
☐ Ignition switch	START
☐ Oil pressure	CHECK within 30 sec
☐ Throttle (warm up)	1,000 RPM
☐ Avionics Master	ON
☐ Amps/Volts	CHECK
BEFORE TAXI	
☐ ATIS / Weather	OBTAIN
☐ Altimeter	SET (QNH)
☐ Heading indicator	ALIGN WITH COMPASS
☐ Gyros / Attitude Indicator	ERECT
☐ Nav lights	AS REQUIRED
☐ Transponder	ALT / SQUAWK
☐ Radios / GPS	SET
☐ Taxi clearance / ATC contact	OBTAINED

☐ Initial climb speed	65 KIAS
☐ Flaps	RETRACT ABOVE 200 ft AGL
SHORT-FIELD TAKEOFF	
☐ Flaps	10°
☐ Brakes	HOLD FIRM
☐ Throttle	FULL POWER
☐ Brakes	RELEASE
☐ Lift-off	53 KIAS
☐ Obstacle clearance speed	56 KIAS
☐ Flaps	RETRACT ABOVE 200 ft AGL
SOFT-FIELD TAKEOFF	
☐ Flaps	10°
☐ Throttle	FULL SMOOTH (Immediately)
☐ Nose-high attitude	MAINTAIN
☐ Lift-off (as soon as possible)	MINIMUM SPEED
☐ Accelerate in ground effect	VX / VY
☐ Flaps	RETRACT ABOVE 200 ft AGL
CLIMB	
☐ Airspeed	74 KIAS
☐ Throttle	FULL / AS REQUIRED
☐ Mixture	ADJUST above 3,000 ft
☐ Engine instruments	MONITOR
CRUISE	
☐ Power setting	SET (55%–75%)
☐ Mixture	LEAN (cruise power)
☐ Altimeter	CHECK / RESET
☐ Instruments	MONITOR
☐ ATIS/AWOS	MONITOR

☐ Approach speed	63 KIAS
☐ Throttle	ADD POWER — keep nose high
☐ Touchdown	MAIN WHEELS ONLY
☐ Back-pressure	MAINTAIN — avoid nosing over
BALKED LANDING / GO-AROUND	
☐ Throttle	FULL POWER
☐ Carb heat	OFF
☐ Flaps	20° (retract to 10°, then retract above 200 ft)
☐ Airspeed	55 KIAS initially / 65 KIAS climb
AFTER LANDING	
☐ Flaps	RETRACT
☐ Carb heat	OFF
☐ Transponder	STBY
☐ Landing lights	OFF
ENGINE SHUTDOWN & SECURING	
☐ Throttle	1,000 RPM — 1 min cool
☐ Avionics Master	OFF
☐ All other switches	OFF
☐ Mixture	IDLE CUT-OFF (pull full out)
☐ Ignition switch (after prop stops)	OFF
☐ Master Switch	OFF
☐ Fuel Selector	BOTH
☐ Control lock	INSTALL
☐ Logbook	COMPLETE