

NORMAL PROCEDURES CHECKLIST Aircraft: _____

Cessna 172 Series | For Training Use Only | Ref: POH Section 4

FLIGHT INFORMATION

PIC Name		Student / SIC Name	
Aircraft Reg.		Date / Time	

⚠ WARNING: This checklist is for training use only. Always refer to the current approved POH/AFM for actual flight operations.

PREFLIGHT INSPECTION	
☐ Fuel quantity (both tanks)	CHECK / QUANTITY
☐ Fuel caps	SECURE
☐ Fuel type (Avgas 100LL)	VERIFY
☐ Oil level	CHECK (min 4 qt, max 8 qt)
☐ Oil filler cap	SECURE
☐ Engine compartment — leaks/debris	CHECK CLEAR
☐ Air intake / filter	CHECK CLEAR
☐ Propeller	NO NICKS / CRACKS
☐ Spinner	SECURE
☐ Landing gear / tyres	CONDITION / INFLATION
☐ Brake fluid	CHECK
☐ Nosewheel shimmy damper	CHECK CONDITION
☐ Static port (both sides)	UNOBSTRUCTED
☐ Pitot tube / cover removed	CLEAR
☐ Fuel drains (sump / strainer)	SAMPLE CLEAR
☐ Control surfaces — free / correct	CHECK
☐ Flaps — travel and condition	CHECK
☐ Antennas	SECURE / NO DAMAGE
☐ Stall warning vane	CHECK
☐ Lights (nav/strobes/landing)	CHECK
☐ Windshield	CLEAN / UNOBSTRUCTED
BEFORE ENGINE START	
☐ Aircraft documents (ARROW)	ON BOARD
☐ Seat, seat belts, shoulder harness	ADJUST / SECURE
☐ Doors / windows	CLOSED & LATCHED
☐ Brakes	TEST / HOLD
☐ Circuit breakers	IN
☐ Avionics Master Switch	OFF
☐ Fuel Selector Valve	BOTH
☐ Master Switch (ALT & BAT)	ON
☐ Fuel quantity indicators	CHECK
☐ Fuel pump (AUX BOOST PUMP)	ON — check pressure then OFF
☐ Lights — nav / beacon	ON
☐ Master Switch	OFF
ENGINE START	
☐ Throttle	OPEN 1/4 inch
☐ Mixture	RICH (below 3,000 ft)

SHORT-FIELD TAKEOFF	
☐ Flaps	10°
☐ Brakes	HOLD FIRM
☐ Throttle	FULL POWER
☐ Brakes	RELEASE
☐ Lift-off	53 KIAS
☐ Obstacle clearance speed	56 KIAS
☐ Flaps	RETRACT ABOVE 200 ft AGL
SOFT-FIELD TAKEOFF	
☐ Flaps	10°
☐ Throttle	FULL SMOOTH (immediately)
☐ Nose-high attitude	MAINTAIN
☐ Lift-off (as soon as possible)	MINIMUM SPEED
☐ Accelerate in ground effect	VX / VY
☐ Flaps	RETRACT ABOVE 200 ft AGL
CLIMB	
☐ Airspeed	74 KIAS
☐ Throttle	FULL / AS REQUIRED
☐ Mixture	ADJUST above 3,000 ft
☐ Engine instruments	MONITOR
☐ Fuel pump	OFF (cruise climb only)
CRUISE	
☐ Power setting	SET (55%–75%)
☐ Mixture	LEAN (cruise power)
☐ Altimeter	CHECK / RESET
☐ Instruments	MONITOR
☐ ATIS/AWOS	MONITOR
DESCENT	
☐ ATIS / current weather	OBTAIN
☐ Altimeter	RESET (QNH)
☐ Mixture	RICH (below 3,000 ft)
☐ Fuel pump (AUX)	ON
☐ Carb heat	ON (if icing conditions)
☐ Power	REDUCE GRADUALLY
BEFORE LANDING	
☐ Fuel Selector	BOTH
☐ Fuel pump (AUX)	ON
☐ Mixture	RICH

☐ Fuel selector	BOTH
☐ Primer	AS REQUIRED / IN & LOCKED
☐ Master Switch	ON
☐ Aux fuel pump	ON — check fuel pressure
☐ PROPELLER AREA	⚠ CLEAR
☐ Ignition switch	START
☐ Oil pressure	CHECK within 30 sec
☐ Throttle (warm up)	1,000 RPM
☐ Avionics Master	ON
☐ Amps/Volts	CHECK
BEFORE TAXI	
☐ ATIS / Weather	OBTAIN
☐ Altimeter	SET (QNH)
☐ Heading indicator	ALIGN WITH COMPASS
☐ Gyros / Attitude Indicator	ERECT
☐ Nav lights	AS REQUIRED
☐ Transponder	ALT / SQUAWK
☐ Radios / GPS	SET
☐ Taxi clearance / ATC contact	OBTAINED
TAXI	
☐ Brakes — initial test	CHECK
☐ Turns — controls / AI	CHECK
☐ Taxi speed	SLOW WALKING PACE
BEFORE TAKEOFF (RUNUP)	
☐ Parking brake	SET
☐ Seats / belts	SECURE
☐ Doors / windows	CLOSED / LATCHED
☐ Flight controls — free and correct	CHECK
☐ Instruments	CHECK / SET
☐ Fuel — sufficient / correct tank	BOTH / CHECK
☐ Fuel pump (AUX)	ON
☐ Mixture	RICH (below 3,000 ft)
☐ Throttle to 1,800 RPM	SET
☐ Magnetos — L / R check (max 125 RPM drop, max 50 RPM diff)	CHECK
☐ Carb heat — note RPM drop	CHECK
☐ Engine instruments	ALL GREEN
☐ Throttle (idle check)	RPM < 700
☐ Throttle	1,000 RPM
☐ Radios / transponder	SET
☐ Lights (landing / strobes)	ON
☐ Flaps	SET FOR TAKEOFF
☐ Brakes	HOLD FIRM
☐ Takeoff clearance	OBTAINED
NORMAL TAKEOFF	

☐ Carb heat	ON
☐ Seat belts / shoulder harness	SECURE
☐ Landing lights	ON
☐ Airspeed (downwind)	90 KIAS
NORMAL LANDING	
☐ Final approach speed	65–75 KIAS
☐ Flaps	FULL (40°) as required
☐ Throttle (short final)	IDLE
☐ Touchdown (main wheels first)	SMOOTH
☐ Nose wheel	HOLD OFF / LOWER GENTLY
☐ Braking	MODERATE
☐ Carb heat	OFF
SHORT-FIELD LANDING	
☐ Flaps	40°
☐ Approach speed	61 KIAS
☐ Throttle	IDLE over threshold
☐ Braking (full)	MAXIMUM
SOFT-FIELD LANDING	
☐ Flaps	40° (full)
☐ Approach speed	63 KIAS
☐ Throttle	ADD POWER — keep nose high
☐ Touchdown	MAIN WHEELS ONLY
☐ Back-pressure	MAINTAIN — avoid nosing over
BALKED LANDING / GO-AROUND	
☐ Throttle	FULL POWER
☐ Carb heat	OFF
☐ Flaps	20° (retract to 10°, then retract above 200 ft)
☐ Airspeed	55 KIAS initially / 65 KIAS climb
☐ Fuel pump	ON
AFTER LANDING	
☐ Flaps	RETRACT
☐ Carb heat	OFF
☐ Transponder	STBY
☐ Landing lights	OFF
☐ Fuel pump	OFF
ENGINE SHUTDOWN & SECURING	
☐ Throttle	1,000 RPM — 1 min cool
☐ Avionics Master	OFF
☐ All other switches	OFF
☐ Mixture	IDLE CUT-OFF (pull full out)
☐ Ignition switch (after prop stops)	OFF
☐ Master Switch	OFF
☐ Fuel Selector	BOTH
☐ Control lock	INSTALL

☐ Throttle	FULL SMOOTH
☐ Mixture	RICH
☐ Airspeed indicator	ALIVE (check)
☐ Lift-off (Vr)	55 KIAS
☐ Initial climb speed	65 KIAS
☐ Flaps	RETRACT ABOVE 200 ft AGL
☐ Fuel pump (AUX)	OFF (after positive rate)

☐ Logbook	COMPLETE
----------------------------------	----------