

<u>Help</u>





<u>Course</u> <u>Progress</u> <u>Dates</u> <u>Discussion</u> <u>Course Notes</u>

★ Course / Assignment 4 (due Nov 7) / Lab 4: 32-bit ALU

()

Next >

Design Problem: 32-bit ALU

□ Bookmark this page

< Previous</pre>


■ Calculator

Lab due Nov 7, 2016 21:59 -02 Past due Design Problem: 32-bit ALU

0.0/10.0 points (graded)

Click to open Instructions in another window. This will allow you to have the instructions open and enter your design at the same time.

Use the Jade instance below to enter your design. To complete this design problem, select the /lab3/alu module and click ✓ in the Jade toolbar and the built-in tester will either report any discrepencies between the expected and actual outputs, or, if your design is correct, it will record the test passed so that clicking **Check & Save**



Topic: Assignment 4 (due Nov 7) / Design Problem: 32-bit ALU

≺ All Posts Passed Lab! Here's some tips: discussion posted 7 years ago by **SohanFernando** Hi All. Eureka! I passed this Lab just now. Had several areas of confusion, largely due to my having some lack of clarity re some Jade related issues. Below, here are some hints/tips/my experiences, in case they help any of you - I assume there might be another half hour or so of the grace period remaining. 1. Firstly, you might find some help in https://courses.edx.org/asset- v1:MITx+6.004.1x_3+3T2016+type@asset+block/pdfs_course_jadefaq.pdf and of course VERY carefully follow the advice of https://courses.edx.org/asset- v1:MITx+6.004.1x_3+3T2016+type@asset+block/labs_lab4_1_instructions.html

2. I found that a JUMPER is needed to be used when trying to "tap" the value of something like S[31].

⊞ Calculator

I.e., sometimes, things would not work if I try to label a wire as S[31] and then directly connect that wire to a gate's input; instead, needed a jumper between that wire and the gate's input. [edited: above is not quite correct, as Silvina and srijal point out in response. It was mainly when having trouble in connecting a individual bit like S[31] directly to an output, that I found the use of a jumper would solve the problem.]

3. In SHIFT module. I found some errors coming, when I used something like A[31:1],GND or BLAH[31:2],GND#2. (that might not be the exact example, but anyway I am illustrating just the problem, here). I found that things DID work for me when I replaced my uses of "GND" or "GND#2" (etc) with something like:

"0'1" and "0'2".


E.g,: BLAH[31:2],0'2

- 4. less clear to me, in my other post I have a clumsy set of updates written as I solved some errors; i can't write it succinctly now but if you're really stuck then go see if anythign there gives you any ideas.
- 5. Having trouble with the 32-NOR gate? I made my own module for that (and just specified the inputs as A[31:0] in its icon, rather than drawing 32 inputs). BUT when I dragged that gate into my main Arith unit, I was having various errors when I tried to connect my S[31:0] to the 32-NOR's input.

I don't yet necessarily fully understand what nuances of Jade make that all happen, but anyhow; those helped me. Also thanks to several of you all's comments, Silvina firstly; and several others of you seemed to have a very good grasp of what's going on and your comments in other posts helped to make see the need to do the above.

This post is visible to everyone.

different from using a jumper;



and that the only reason to use a jumper HEDEZ is due to some Indo-related shortcomings/features

⊞ Calculator

 I also assume that the buffer solution WOULD have real life application in situations where our output signal is driving some load (or potentially might later need to drive a load) which draws a higher current than OUR

and that the only reason to use a jumper meren is due to some sade-related shortcomings/reatdres.

• I'm not sure how this'd be done exactly: but gut feeling is that if multiple other devices all wanted to use "N" as an input, then too using an intermediate buffer(s?) would be helpful.

All tentative thoughts only, though.

output device can safely produce.


(I've been dabbling with some microcontroller stuff recently: Raspberry Pi and mainly Arduino/PIC; and I have come across cases where either due to the 20mA output limitation of the Arduino outputs, or due to simply wanting to isolate (for protection) the Pi's or Arduino's pins from my external device, it is better to use a buffer like you have done.

Something I am EVEN less sure about: I have also read about, but not yet used, cases where a buffer is used to change the LOGIC voltage between devices: e.g., if the R.Pi uses 3.3V logic, but I want to connect its output pins to some device whose logic voltage is 5V and which ideally requires a High to stay close to 5V. Rather hazy about the issues and advantages/etc so won't even try to suggest anything more about that example.)

posted 7 years ago by **SohanFernando**

Previous

Add a comment



Next >

© All Rights Reserved



edX

About Affiliates edX for Business Open edX

Careers



<u>News</u>

Legal

Terms of Service & Honor Code

Privacy Policy

Accessibility Policy

<u>Trademark Policy</u>

<u>Sitemap</u>

Cookie Policy

Your Privacy Choices

Connect

<u>Idea Hub</u>

Contact Us

Help Center

<u>Security</u>

Media Kit















© 2024 edX LLC. All rights reserved.

深圳市恒宇博科技有限公司 <u>粤ICP备17044299号-2</u>