

Modbus TCP Server Device Parâmetros**Parâmetros:**

Nome:	Tipo:	Valor:	Valor Padrão:	Unidade:	Descrição:
Timeout	DINT(500..200000)	0	0		Configuration of the TimeOut
InputAssemblySize	UINT(2..4096)	3	10		Configure the size of the loscanner register
OutputAssemblySize	UINT(2..4096)	9	10		Configure the size of the loscanner register
Port	UINT	502	502		Port where the Server is listening for requests
BindPort	BOOL	FALSE	FALSE		Bind Mdobus port to IP address of specified ethernet adaper
OptimizationOn	BOOL	TRUE	TRUE		the driver optimizes the io update
UpdateableHolding	BOOL	FALSE	FALSE		Holding Registers as %Q-data for local update by application
DistinctBitAreas	BOOL	TRUE	FALSE		Coils and Discrete Inputs data blocks get their own IO-Mapping
Coils Size	UINT	56	0		Number of Coils
Discrete Inputs Size	UINT	1	0		Number of Discrete Inputs
StartAddresses					Start Addresses of Modbus Data Areas
Coils	UINT	0	0		
DiscreteInputs	UINT	0	0		
HoldingRegister	UINT	0	0		
InputRegister	UINT	0	0		
Data Model Options	UDINT	0	0		0 = default, 1 = Holding-and Input-Register Data Areas overlay
CloseTCPsocketAtTimeout	BOOL	TRUE	TRUE		Close TCP-socket at timeout
SerialGatewayEnabled	BOOL	FALSE	FALSE		
ComPort	USINT	1	1		COM port number to use for the serial communication
Baudrate	Enumeration of UDINT	9600	9600		Baudrate of the serial port.
Status					Device's status information
Version	UDINT	1	1		
Connections	UDINT				Number of active TCP-Client Connections
TCP-Port Status	Enumeration of UDINT				Current State of TCP Port
Request Counter	UDINT				Total number of incomming client requests
Modbus Exception Counter	UDINT				Number of Request that have been rejected with Exception Code
Serial Gateway Active	BOOL				TCP/Serial gateway function is enabled
align	BYTE				

align	BYTE			
align	BYTE			
COM-Port Status	Enumeration of UDINT			Current State of COM-Port
Request Counter	UDINT			Number of forwarded requests
Error Counter	UDINT			Number of failed forwarded requests
Timeout	DINT(500..200000)	2000	2000	Actual value of the TimeOut configured
InputAssemblySize	UINT(2..4096)	10	10	Actual value of the size of the assembly
OutputAssemblySize	UINT(2..4096)	10	10	Actual value of the size of the assembly
Port	UINT	502	502	Current Port where the Server is listening for requests
Unit-ID	BYTE	0	0	Current Unit-ID of the Server (optional)
ConfigVersion	UDINT	16#03051000	16#03051000	

Modbus TCP Server Device Mapeamento de E/S**Parâmetros de entrada:**

Mapeamento:	Canal:	Endereço:	Tipo:	Unidade:	Descrição:
Application.PLC_PRG.sensor_ph_t1	Entradas[0]		WORD		
Application.PLC_PRG.sensor_ph_t2	Entradas[1]		WORD		
Application.PLC_PRG.sensor_ph_t3	Entradas[2]		WORD		
Application.PLC_PRG.start	Bit0		BOOL		
Application.PLC_PRG.emergencia	Bit1		BOOL		
Application.PLC_PRG.comando_val_t1	Bobinas[1]		BYTE		
Application.PLC_PRG.comando_sens_t1	Bobinas[2]		BYTE		
Application.PLC_PRG.comando_val_t2	Bobinas[3]		BYTE		
Application.PLC_PRG.comando_sens_t2	Bobinas[4]		BYTE		
Application.PLC_PRG.comando_val_t3	Bobinas[5]		BYTE		
Application.PLC_PRG.comando_sens_t3	Bobinas[6]		BYTE		

Parâmetro de saída:

Mapeamento:	Canal:	Endereço:	Tipo:	Unidade:	Descrição:
Application.PLC_PRG.status_clp_t1	Saídas[0]		WORD		
Application.PLC_PRG.progresso_mistura_t1	Saídas[1]		WORD		
Application.PLC_PRG.valor_ph_t1	Saídas[2]		WORD		
Application.PLC_PRG.status_clp_t2	Saídas[3]		WORD		
Application.PLC_PRG.progresso_mistura_t2	Saídas[4]		WORD		
Application.PLC_PRG.valor_ph_t2	Saídas[5]		WORD		
Application.PLC_PRG.status_clp_t3	Saídas[6]		WORD		
Application.PLC_PRG.progresso_mistura_t3	Saídas[7]		WORD		
Application.PLC_PRG.valor_ph_t3	Saídas[8]		WORD		
Application.PLC_PRG.selo_start	Bit0		BOOL		

Objetos Comissão Eletrotécnica Internacional:

Variável:	Tipo:
ModbusTCP_Server_Device	IoDrvModbusTCPSlave

Informações

Nome: ModbusTCP Server Device
Fornecedor: CODESYS
Categorias: Dispositivo servidor TCP Modbus
Tipo: 115
ID: 0000 0002
Versão: 4.5.0.0
Número da ordem: -
Descrição: A device that works as a Modbus TCP Server.
Versão da configuração: 3.5.16.0