

Introduction

Baroid Core Homework 19

Assessment Feedback

Congratulations, you passed.

Total score: 49 out of 49, 100%

Question Feedback

Question

1 of 30

Reservoir fluids can be defined as Fluids we expose to the reservoir, that help prepare, repair, cleanout and complete the wellbore

- ☐ True
☒ False

1 out of 1

Question

2 of 30

The goal of completion fluids is to allow a controlled production of the well, maximizing both the flow of hydrocarbons and safety

- ☒ True
☐ False

1 out of 1

Question

3 of 30

Completions fluids need to provide overbalance to control pressures from the wellbore, and transport solids into the reservoir

- ☐ True
☒ False

1 out of 1

Question

4 of 30

The displacement from drilling fluid to completion fluid is done by using a series of specially designed spacers

- ☒ True
☐ False

1 out of 1

Question

5 of 30

During the completion process, the lower completion assembly is run into the well to the payzone

- ☒ True
☐ False

1 out of 1

Question

6 of 30

Hydrocarbons will flow to surface during a cased and perforated production within the last casing cemented in the wellbore

- ☒ True
☐ False

1 out of 1

Question

7 of 30

The **packer** anchors the tubing, and seals the space between the tubing and the casing

1 out of 1

Question

8 of 30

Select the types of completions mentioned in class

- ☒ Sand control screen

- ☒ Uncemented liner
- ☒ Cased and perforated
- ☒ Gravel pack
- ☐ Floating collar
- ☐ Bareleg completion

4 out of 4

Question

9 of 30

Cased and perforated is the most common type of completion for oil wells

- ☒ True
- ☐ False

1 out of 1

Question

10 of 30

Brines can be classified based on their source. Provide examples of each type of them

- | | |
|------------------------------------|---------------------|
| Naturally occurring | NaCl, NaBr ▼ |
| By-product of commercial processes | CaCl ₂ ▼ |
| Made from natural minerals | CsCOOH ▼ |

3 out of 3

Question

11 of 30

In general, monovalent salts are usually mixed from sacks

- ☒ Yes
- ☐ No

1 out of 1

Question

12 of 30

In general, divalent salts are usually mixed from sacks

- ☐ True
- ☒ False

1 out of 1

Question

13 of 30

The is used to measure the density of clear brine with no viscosity

1 out of 1

Question

14 of 30

The Turbidimeter (NTU) provides a value that can be used as reference to establish how cline a brine is

- ☒ True
- ☐ False

1 out of 1

Question

15 of 30

The higher the NTU reading from the turbidity meter, the cleaner the brine will be

- ☐ True
- ☒ False

1 out of 1

Question

16 of 30

The results from a NTU meter can be used to calculate the concentration of solids in suspension in the brine.

- ☐ True
- ☒ False

1 out of 1

Question

17 of 30

All brines are the same and can be handled using the basic PPE

- ☐ True

☐ False

1 out of 1

Question

18 of 30

The "Process of removing from the wellbore one fluid (usually a drilling fluid), and replacing it with another (usually a clean completion fluid)" is called:

- ☐ Completion
- ☒ Displacement
- ☐ Dewatering
- ☐ Stimulation

1 out of 1

Question

19 of 30

Select all the applicable drilling fluid displacement objectives:

- ☐ Oil wet all well surfaces
- ☒ Establish a clean, non damaging environment for completion
- ☒ Water wet all well surfaces
- ☒ Maximizing the recovery of drilling fluid;
- ☐ Maximize the production of fluid waste
- ☐ Minimize the volume of fluid recovered

3 out of 3

Question

20 of 30

What are the five main requirements to plan a successful completion job?

- ☒ Lab data
- ☒ Hydraulic data
- ☒ Well data
- ☐ Financial data
- ☒ Installation data
- ☐ Logistic data
- ☒ Fluid data
- ☐ All of the above
- ☐ None of the above

Question

21 of 30

What are the two types of displacement available? _____

- ☐ Bypassed and indirect
- ☒ Direct and indirect
- ☐ Tandem and indirect
- ☐ Direct and tandem
- ☐ Direct and bypassed

1 out of 1

Question

22 of 30

In order to maximize the success of a displacement, completion tools are used _____

- ☒ True
- ☐ False

1 out of 1

Question

23 of 30

What are the main applications for completion tools? _____

- ☐ Spudding the well
- ☒ Displacing of the well
- ☒ Post perforation runs
- ☒ Fishing applications
- ☐ All of the above
- ☐ None of the above

3 out of 3

Question

24 of 30

Select from the following list, the main four categories of completion tools using during the displacement for completion

- ☒ Other specialty tools
- ☐ Casing milling and bypass tools
- ☒ Casing and riser cleaning tools
- ☐ Hole openers and reamers
- ☒ Jetting and bypass tools
- ☐ Perforating and bypass tools
- ☒ Debris extraction tools

4 out of 4

Question

25 of 30

The consists of a series of pills and spacers that are pumped in a clearly defined sequence, and under-controlled flowrate

1 out of 1

Question

26 of 30

The use of a base fluid pill is a requirement exclusive for the displacement of:

- ☐ High density brines
- ☐ High performance water based fluids
- ☐ Conventional water based fluids
- ☒ Non Aqueous fluids

1 out of 1

Question

27 of 30

Push pill characteristics are:

- ☐ Low density, low viscosity
- ☐ High density, low viscosity
- ☒ High density, high viscosity
- ☐ Low density, high viscosity

1 out of 1

Question

28 of 30

Wash pill characteristics are:

- ☐ High density, low viscosity
- ☒ Low density, low viscosity
- ☐ Low density, high viscosity
- ☐ High density, high viscosity

1 out of 1

Question

29 of 30

Select all the displacement success metrics

- ☒ Time
- ☐ Number of samples
- ☒ Cost
- ☐ Torque
- ☐ Final volumes
- ☒ Cleanliness
- ☒ HSE

4 out of 4

Question

30 of 30

Current well cleaners are using surfactants that are more compatible with environmental regulations and have a lower impact than solvent cleaners

- ☒ True
- ☐ False

1 out of 1