

RENO COMPASS BLUEPRINT PLAN

Dossier ID: reno_s_30a6afd8d81ab5670bbb05ba40e5b330

Generated At: 2026-07-06 22:46:49 UTC

Schema Version: 1.0.0

1. Project Summary

Project: Bathroom Remodel (bathroom_remodel)

Goal: replace current tub with an heavy cast iron tub, install GFCI outlet, install a wall mirror

Property: Zip 95120, independent house, 120 sqft

Chosen design: preferred (est. \$75,000-\$95,000)

2. Safety & Permit (review this first)

- Installation of a Heavy Freestanding Cast Iron Tub: TIER 1 PROFESSIONAL (source: IRC (Structural Load, Two-Gate Structural Trigger))

Requires a licensed professional. Verify with your AHJ.

- Installation of a Heavy Freestanding Cast Iron Tub: TIER 2 PERMITTED (source: IRC (Plumbing permit triggers))

- Installation of a New Walk-in Shower: TIER 2 PERMITTED (source: IRC (Plumbing permit triggers) and (Waterproofing))

- Installation of a New Double Vanity and Toilet: TIER 2 PERMITTED (source: IRC (Plumbing permit triggers))

- Installation of a New GFCI Outlet: TIER 2 PERMITTED (source: NEC (National Electrical Code) 210.8(A)(1) (GFCI requirement), 210.11(C)(3) (20A circuit), 210.52(D) (receptacle placement), and IRC (Electrical permit triggers))

- Installation of a Wall Mirror: TIER 3 PROCEED (source: Not explicitly covered by IRC/NEC as a permit-triggering item.)

Permits are required. Confirm the full scope with your local AHJ.

3. Budget

Target: \$80,000 Ceiling: \$125,000

Ballpark: \$33,480-\$52,080 (+ contingency \$5,189-\$8,072)

Reality check: plausible

All costs are estimated ranges - verify locally with real quotes.

4. Logistics & Displacement

Can live through it: True

Feasibility verdict: proceed

6. Your DIY Plan

- Installation of a Wall Mirror (tier 3 proceed)

1. Plan Location and Height. With the help of a second person, hold the mirror up to the wall to determine the ideal placement and height. Consider aesthetics, functionality (e.g., vanity height), and any surrounding elements. Use a pencil to lightly mark the top and side edges of the mirror's desired position. Use a level to ensure your marks are straight.

2. Determine Mounting Method. For Framed Mirrors with Hanging Wire/D-Rings: Measure the distance from the top of the mirror to the point where the wire or D-rings will be attached to the wall. Mark this point on your wall where you want the hook(s) to go. For Unframed Mirrors with Clips/J-Channel: Mark the positions for the top, bottom, and side clips/channels according to the mirror's dimensions and manufacturer's instructions. For Heavy Mirrors: Use a stud finder to locate wall studs if possible, as mounting directly into studs provides the most secure hold. If studs are not available or not in the desired location, you will need to use appropriate wall anchors (e.g., heavy-duty drywall anchors or toggle bolts).

3. Install Wall Anchors/Hooks. For Screws into Studs: Drill a pilot hole slightly smaller than your screw, then drive the screw in, leaving enough exposed to hang the mirror. For Wall Anchors: Drill holes at your marked locations, following the anchor manufacturer's instructions for drill bit size. Insert the wall anchors, then drive the screws into the anchors. For Picture Hanging Hooks: Install the appropriate picture hanging hooks at your marked locations. For Mirror Clips/J-Channel: Install the bottom J-channel first (if using), ensuring it is level. Then install the top and side clips/channels, leaving enough space for the mirror to fit.

4. Hang the Mirror. With the assistance of a second person, carefully lift the mirror and attach it to the installed anchors, hooks, or clips. For Framed Mirrors: Hook the wire or D-rings onto the installed screws or hooks. For Unframed Mirrors: Gently slide the mirror into the bottom J-channel (if used), then secure the top and side clips.

5. Final Adjustments. Once the mirror is securely hung, make any final adjustments to ensure it is level and centered as desired. Clean any smudges or marks from the mirror and wall.

Tool: Tape measure - Measuring & Marking

Tool: pencil - Measuring & Marking

Tool: painter's tape or masking tape - Measuring & Marking

Tool: level - Measuring & Marking

Tool: stud finder - Measuring & Marking

Tool: Drill/driver - Mounting

Tool: appropriate drill bits for wall material - Mounting

Tool: screwdriver set - Mounting

Tool: Wall anchors - Fasteners (depends on mirror and wall type)

Tool: screws appropriate for anchors - Fasteners (depends on mirror and wall type)

Tool: picture hanging wire and hooks - Fasteners (depends on mirror and wall type)

Tool: mirror clips or J-channels - Fasteners (depends on mirror and wall type)

Tool: Gloves - Safety Gear

Tool: safety glasses - Safety Gear

Tool: a second person - Safety Gear

Tool: Heavy-duty moving straps or furniture dollies - For Safe Movement

Tool: Adequate assistance (multiple strong individuals or professional movers) - For Safe Movement

Tool: Adjustable wrenches - Plumbing Tools

Tool: Pipe wrench - Plumbing Tools

Tool: Basin wrench - Plumbing Tools

Tool: Plumber's putty - Plumbing Tools

Tool: Teflon tape or pipe thread sealant - Plumbing Tools

Tool: Silicone sealant (bathroom grade) - Plumbing Tools

Tool: Caulk gun - Plumbing Tools

Tool: Tape measure - Measuring & Leveling

Tool: Carpenter's level (long and short) - Measuring & Leveling

Tool: Pencil or marker - Measuring & Leveling

Tool: Drop cloths or protective sheeting - General

Tool: Rags - General

Tool: Buckets - General

Tool: Flashlight - General

Tool: Utility knife - General

Tool: Gloves - Safety Gear

Tool: Safety glasses - Safety Gear

6b. Add to Your Contractor's Scope

Eligible work you chose to hand to a professional:

- Installation of a Heavy Freestanding Cast Iron Tub (tier 2 permitted)
- Installation of a New Walk-in Shower (tier 2 permitted)
- Installation of a New Double Vanity and Toilet (tier 2 permitted)
- Installation of a New GFCI Outlet (tier 2 permitted)

7. Advisory Checklist

- Itemized Bid
- Multiple Bids
- Verify Credentials
- "Invisible" Inclusions
- Final Payment

8. Phase Checklists

Before demolition:

- Order long-lead materials first.
- Confirm permits filed.

After demolition:

- Inspect for hidden conditions before closing walls.

While in progress:

- Keep waterproofing before tile.
- Hit inspection milestones.

Wrap-up:

- Final inspection sign-off before final payment.