

```
***** * * ***** ***** *** ***** ** ***** *** ***
* ***** * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * *
* * * * * * * * * * * * * * * * * * * * * * * * * * * *
***** * * * * * * * * * * * * * * * * * * * * * * * * *
```

citroen corp. with *your company* patnership
 boost converter supervision module interface. Enter help to know the
 supported commands

```
boost:~# help
eth          start ethernet mode and stop wifi mode
wifi         start wifi mode and stop ethernet mode
ip           update ip value for ethernet module
netmask      update netmask value for ethernet module
config       print ip informations for running mode
list         print informations about connected boost modules
help         print supported commands
```

```
boost:~# eth
ethernet mode is running
boost:~# ip
update ip value for ethernet module (?.?.?.?) :
172.24.123.13
ip value is updated
boost:~# ip
update ip value for ethernet module (?.?.?.?) :
172.24.123.13azerty
error: failed value
boost:~# netmask
update netmask value for ethernet module (?.?.?.?) :
255.255.0.0
netmask value is updated
boost:~#
```

```
boost:~#
update netmask value for ethernet module (?.?.?.?) :
255.255.0.0
error: failed value
boost:~# config
ethernet module ip configuration :
ip          172.24.123.13
netmask     255.255.0.0
you can print other importants config !
tcp port    5151
udp port    1414
boost:~# wifi
wifi mode is running
boost:~# config
ethernet module ip configuration :
mode        ad hoc
ip          192.168.92.1
netmask     255.255.255.0
you can print other importants config !
tcp port    5151
udp port    1414
boost:~# list
boost0      Vi=12.1V Il=1.5A Pi=18.15W Vo=24.0V Io=750mA (rendement#1)
Boost1      Vi=11.4V Il=1.2A Pi=13.68W Vo=24.0V Io=570mA (rendement#1)
boost:~# azerty
error: enter help to know the supported commands
boost:~#
```

```
boost:~# netmask
update netmask value for ethernet module (?.?.?.?) :
255.255.0.0azerty
error: failed value
boost:~# config
ethernet module ip configuration :
ip          172.24.123.13
netmask     255.255.0.0
you can print other importants config !
tcp port    5151
udp port    1414
boost:~# wifi
wifi mode is running
boost:~# config
ethernet module ip configuration :
mode        ad hoc
ip          192.168.92.1
netmask     255.255.255.0
you can print other importants config !
tcp port    5151
udp port    1414
boost:~# list
boost0      Vi=12.1V Il=1.5A Pi=18.15W Vo=24.0V Io=750mA (rendement#1)
Boost1      Vi=11.4V Il=1.2A Pi=13.68W Vo=24.0V Io=570mA (rendement#1)
boost:~# azerty
error: enter help to know the supported commands
boost:~#
```

```
boost:~#
error: enter help to know the supported commands
boost:~# azerty
boost:~#
```