

Audio Input Signal Vector					
TDM #	MSB	LSB	Channel	BusTap	Group
TDM1	23	0	1	audio_input[23..0]	XLR 1-8
TDM2	47	24	9	audio_input[47..24]	XLR 9-16
TDM3	71	48	17	audio_input[71..48]	XLR 17-24
TDM4	95	72	25	audio_input[95..72]	XLR 25-32
TDM5	119	96	33	audio_input[119..96]	CARD 1-8
TDM6	143	120	41	audio_input[143..120]	CARD 9-16
TDM7	167	144	49	audio_input[167..144]	CARD 17-24
TDM8	191	168	57	audio_input[191..168]	CARD 25-32
TDM9	215	192	65	audio_input[215..192]	AUX 1-8
TDM10	239	216	73	audio_input[239..216]	DSP 1-8
TDM11	263	240	81	audio_input[263..240]	DSP 9-16
TDM12	287	264	89	audio_input[287..264]	DSP 17-24
TDM13	311	288	97	audio_input[311..288]	DSP 25-32
TDM14	335	312	105	audio_input[335..312]	DSP AUX 1-8
TDM15	359	336	113	audio_input[359..336]	AES50A 1-8
TDM16	383	360	121	audio_input[383..360]	AES50A 9-16
TDM17	407	384	129	audio_input[407..384]	AES50A 17-24
TDM18	431	408	137	audio_input[431..408]	AES50A 25-32
TDM19	455	432	145	audio_input[455..432]	AES50A 33-40
TDM20	479	456	153	audio_input[479..456]	AES50A 41-48
TDM21	503	480	161	audio_input[503..480]	AES50B 1-8
TDM22	527	504	169	audio_input[527..504]	AES50B 9-16
TDM23	551	528	177	audio_input[551..528]	AES50B 17-24
TDM24	575	552	185	audio_input[575..552]	AES50B 25-32
TDM25	599	576	193	audio_input[599..576]	AES50B 33-40
TDM26	623	600	201	audio_input[623..600]	AES50B 41-48

Audio Output Signal Vector					
TDM #	MSB	LSB	Channel	BusTap	Group
TDM1	23	0	1	audio_output[23..0]	XLR 1-8
TDM2	47	24	9	audio_output[47..24]	XLR 9-16
TDM3	71	48	17	audio_output[71..48]	UltraNet 1-8
TDM4	95	72	25	audio_output[95..72]	UltraNet 9-16
TDM5	119	96	33	audio_output[119..96]	CARD 1-8
TDM6	143	120	41	audio_output[143..120]	CARD 9-16
TDM7	167	144	49	audio_output[167..144]	CARD 17-24
TDM8	191	168	57	audio_output[191..168]	CARD 25-32
TDM9	215	192	65	audio_output[215..192]	AUX 1-8
TDM10	239	216	73	audio_output[239..216]	DSP 1-8
TDM11	263	240	81	audio_output[263..240]	DSP 9-16
TDM12	287	264	89	audio_output[287..264]	DSP 17-24
TDM13	311	288	97	audio_output[311..288]	DSP 25-32
TDM14	335	312	105	audio_output[335..312]	DSP AUX 1-8
TDM15	359	336	113	audio_output[359..336]	AES50A 1-8
TDM16	383	360	121	audio_output[383..360]	AES50A 9-16
TDM17	407	384	129	audio_output[407..384]	AES50A 17-24
TDM18	431	408	137	audio_output[431..408]	AES50A 25-32
TDM19	455	432	145	audio_output[455..432]	AES50A 33-40
TDM20	479	456	153	audio_output[479..456]	AES50A 41-48
TDM21	503	480	161	audio_output[503..480]	AES50B 1-8
TDM22	527	504	169	audio_output[527..504]	AES50B 9-16
TDM23	551	528	177	audio_output[551..528]	AES50B 17-24
TDM24	575	552	185	audio_output[575..552]	AES50B 25-32
TDM25	599	576	193	audio_output[599..576]	AES50B 33-40
TDM26	623	600	201	audio_output[623..600]	AES50B 41-48