

All phone reset codes

All China

default user code: 1122, 3344, 1234, 5678

#66# Set Factory Mode CONFIRMED

*#8375# Show Software Version CONFIRMED

*#1234# A2DP ACP Mode CONFIRMED

*#1234# A2DP INT Mode CONFIRMED

*#0000# + Send : Set Default Language CONFIRMED

*#0007# + Send : Set Language to Russian CONFIRMED

*#0033# + Send : Set Language to French CONFIRMED

*#0034# + Send : Set Language to Spanish CONFIRMED

*#0039# + Send : Set Language to Italian CONFIRMED

*#0044# + Send : Set Language to English CONFIRMED

*#0049# + Send : Set Language to German CONFIRMED

*#0066# + Send : Set Language to Thai CONFIRMED

*#0084# + Send : Set Language to Vietnamese CONFIRMED

*#0966# + Send : Set Language to Arabic CONFIRMED

*#800# make Etel E10 model displaying message BT power on. But on display it dont resemble the bluetooth power on icon.(actually t makes BT stuck, but after restarting t becomes normal <tested by me>)

More codes to reset chinese mobile phone

*#77218114#

*#881188#

*#94267357#

*#9426*357#

*#19912006#

*#118811#

*#3646633#

also found these

Service codes Konka:

C926 software version: *320# Send

C926 set default language: *#0000# Send

C926 set English language: *#0044# Send

Service codes GStar:

GM208 (Chinese Nokea 6230+) engineering menu: *#66*#

Set language to English: *#0044#

Set language to Russian: *#0007#

ZTE Mobile:>1- *938*737381#

2- PHONE WILL DIPLAYED DONE

3- POWER OFF YOUR PHONE AND POWER ON AGAIN

alcatel:>E205

unlocking phone code,only press***847# without simcard

E900 software version: *#5002*8376263#

E900 full reset: *2767*3855#

Service codes Spice:

S404 enable COM port: *#42253646633# -> Device -> Set UART -> PS -> UART1/115200

S410 engineer mode: *#3646633#

S900 software version: *#8375#

S900 serial no: *#33778#

Service codes Philips:

S200 enable COM port: *#3338913# -> Device -> Set UART -> PS -> UART1/115200

Service codes "Chinese" models:

default user code: 1122, 3344, 1234, 5678

Engineer mode: *#110*01#

Factory mode: *#987#

Enable COM port: *#110*01# -> Device -> Set UART -> PS Config -> UART1/115200

Restore factory settings: *#987*99#

LCD contrast: *#369#
software version: *#800#
software version: *#900#

Service codes BenQ:

software version: *#300#
test mode: *#302*20040615#

Service codes Pantech:

software version: *01763*79837#
service menu: *01763*476#
reset defaults (phone/user code reset to default): *01763*737381#

Service codes VK-Mobile **x, 5xx:

software version: *#79#
software version: *#837#
service menu: *#85*364# (hold #)

Service codes VK200, VK2000, VK2010, VK2020, VK4000:

software version: *#79#
service menu: *#9998*8336# (hold #)
reset defaults (phone/user code reset to default): *#9998*7328# (hold #)

Service codes LG:

software version: 2945##
KG300 NVRAM format: 2945## -> menu 15

Service codes Sony-Ericsson:

J100 software version: #82#

Service codes Fly:

M100 software version: #####0000#
2040(i) reset defaults: *#987*99# Send
MX200 reset defaults: *#987*99# Send
MX200 software version: *#900# Send
SL300m reset defaults: *#987*99# Send
SL300m software version: *#900# Send
SL500m reset defaults: *#987*99# Send
SL500m software version: *#900# Send
MP500 reset defaults: *#987*99# Send
MP500 software version: *#900# Send
Set language to English: *#0044#

Set language to Russian: *#0007#

Service codes Konka:

C926 software version: *320# Send
C926 set default language: *#0000# Send
C926 set English language: *#0044# Send

Service codes GStar:

GM208 (Chinese Nokea 6230+) engineering menu: *#66*#
Set language to English: *#0044#
Set language to Russian: *#0007#

Service codes Motofone-F3:

Motofone F3 software version: **9999* Send
***300* Set SIM Pin
***310* / ***311* SIM Pin ON | OFF
***000* Reset Factory settings
***644* Set Voicemail number
***260* / ***261* Auto keypad lock ON | OFF
***510* / ***511* Voice Prompts ON | OFF
***160* / ***161* Restricted Calling (Phonebook only) ON | OFF
***200608* Send: software version
***200606* Send: software version
***200806* Send: flex version

***250* / ***251* Keypad tones ON | OFF
***470* Select time format
***500* / ***501* Prepaid Balance Display ON | OFF
***520* Change language

Service codes Motorola:

C113, C114, C115, C115i, C116, C117, C118 software version: #02#*
C138, C139, C140 software version: #02#*
C155, C156, C157 software version: #02#*
C257, C261 software version: #02#*
V171, V172, V173 software version: #02#*
V175, V176, V176 software version: #02#*
C168, W220 software version: *#*837#
W208, W375 software version: #02#*
and "yes""

I-mobile Inno30, 55, 89, 90, 99, 100, A10, A20, P10, Vk200

- Set full factory *741*737381#
- Set full factory *741*7373868#
- Set full factory *741*2878#
- Set Engineer Mode *888*888#
- Check software version *888*837#

I-mobile 100 ,200 , 313

- Check software version #*888#

I-mobile 309, 310

- Check software version *0*4636#
- Test Mode *0*6268#

I-mobile 311

- Check software version #*878#

I-mobile 511

- Check software version *1222*1#

I-mobile 301, 302,308, 508, 601, 602, 603, 604, 606, 611, 901, 902

- Check software version *#159#
- Set Factory Mode *#32787#
- Set Engineer Mode *#3646633#

I-mobile 503, 506, 605, 600, 607, 608

- Set Engineer Mode ***503#
- Set Factory Mode ***504#
- Set Auto Test ***505#

I-mobile 509, 612

- Set Factory Mode *#66*#

I-mobile 504, 505, 803

- Check software version *68*48#
- Set full factory *789#
- Test Mode *#789#

I-mobile 305, 306, 315, 510, 609, 609i,516

- Check software version *#8375#
- Set Factory Mode 878

I-mobile 610

- Check software version *#22#

I-mobile J101, J102

- Test Mode *23638777*783781#

I-mobile 502, 502i, 505, k9, 802

- Check software version *201206*4636#

Samsung

Samsung Programmers code!(Secret code)

All Samsung Hard Reset Codes

- 1.)*2767*3855#
- 2.)*7465625*638*00000000*00000000#
- 3.)#7465625*638*00000000#

Following is the list of code for SIM issue:

*7465625*746*code# Enables SIM lock
#7465625*746*code# disables SIM lock
*7465625*28746# Auto SIM lock On
#7465625*28746# Auto SIM lock Off
*#0778# Sim Serv, Table.
*#0638# SIM Network ID.
*#0746# SIM info.
*#2576# SIM error.
*#0778# To see what your SIM supports.
*#0746# Your sim type.
#9998 NET# SIM NEtwork ID
*#9998*778# SIM Serv. Table.
*#9998*2576# Forces SIM Error.

To remove sim locks:

#0111*0000000#
*2767*66335#
*2767*3700#
*2767*7100#
*2767*8200#
*2767*7300#
*2767*2877368#
*2767*33927#
*2767*85927#
*2767*48927#
*2767*37927#
*2767*28927#
*2767*65927#
*2767*29927#
*2767*78927#
*2767*79928#
*2767*79928#
*2767*82927#
*2767*787927#
*2767*73738927#
*2767*33667#
*2767*85667#
PROGRAMMER CODES!

*#06#=Displays IMEI NO.
*#9999#=SW Version.
*#8888#=HW Version.
*#0842#=Vibrator.
*#0289#=Buzzer.
*#0228#=Battery Stat.
*#0782#=RTC Display
*#0523#= LCD Contrast.
*#0377#=NVM error log
*#5646#=GSM Logo Set.
*#0076#=Production No.
*#3323#=Forced Crash
*#9324#=Netmon <> press the hung
up key to exit.
*#32439483 =Digital Audio Interference
off.
*#32436837#=Digital Audio Interference
on.

*#9998*JAVA# =Edit GPRS/CSD settings
*#9998*Help# =Screen / List of codes.
#9998=RTC# =RTC Display.
*#9998*bat#=Battery Status.
*#9998*buz#=Turns Buzzer On.
*#9998*vub# =Turns Vibator On.
*#9998*LCD#=LCD Contrast.
*#9998*9999#=Software Version.
*#9998*8888#=Hardware Version.
*#9998*377#=Non Volatile Memory Error Log
*#9998*968#=Reminder Tune.
*#9998*NVM#=Displays Non-Volatile Memory Status.
*#9999*C#=Netmon.
*#9998*DEAD# =Forces Phone Crash.
*#9998*533# =(LED).
*#999# =Show date and alarm clock.
*#8999*638# =show network information.
*#9998*5646# =change operator logo at startup

*#9998*968# =View melody alarm.
*2767*MEDIA# =Resets the media on phone
*2767*FULL# =Resets the EEPROM*
*2767*CUST# =Resets the custom EEPROM.
*2767*JAVA# = Resets JAV downloads
*2767*STACKREST# =RESETS STACK.
*2767*225RESET# * =VERY Dangerous.
*2767*688# = Unlocking code
*#8999*8378# = All in one code
*#4777*8665# = GPSR Tool
*#8999*3825583# = External Display
*#8999*377# = Errors
*#2255# = call list
*#5737425# = JAVA Something choose 2 and it crashed.
*#536961# = Java Status Code
*#536962# = Java Status Code
*#536963# = Java Status Code
*#53696# = Java Status Code
*#1200# = AFC DAC Val
*#1300# =IMEI
*#2562# = white for 15 sec then restarts.
*#2565# =Check Blocking
*#3353# =check code
*#3837# = White for 15 secs then restarts.
*#3849# = white for 15 secs then restarts.
*#7222# = Operation Type
*#7224# = I got ERROR !
*#7252# = Operation Type
*#7271# =Multi Slot
*#7271# =Multi Slot
*#7337# = EPROM Reset (unlock and resets Wap settings)
*#2787# =CRTP ON/OFF
*#3737# = L1 Dbg Data
*#5133# =L1 Dbg Data
*#7288# =GPRS Attached
*#7287# =GPRS Detached
*#7666# =SrCell Data
*#7693# =Sleep Act/Deact
*#7284# =Class B/C
*#2256# =Calibration Info
*#2286# =Battery Data
*#2679# =Copycat Feature
*#3940# =External loop 9600 bps
*#8462# =sleep time
*#5176# =L1 Sleep
*#5187# = L1C2G Trace

#*3877# = Dump Of spy trace
*#8999*8376263# =HW Ver SW Ver and build date
*#746565# =Checks the locks
*7465625*638*Code# =Enables Network lock
#7465625*638*Code# = Disables Network lock
#7465625*782*code# =Disables Subset lock
*7465625*782*code# =Enables subset lock

Known Unlock CODES
S500/ P400/ E500/ E700/ X100/ X600/
E100/
Enter *2767*3855# with and accepted SIM
card If this codes fails,

For accepted sim card insert below code:
Enter *2767*688# or #*7337#
A300/ A400 / A800
*2767*637#
S100 / S300 / V200 / V205 / E710 / E715
/ D410 / X426/
*2767*7822573738#

Try this if above code fails:

- 1.) Insert sim card
- 2.) type #9998*3323# if it display wrong card
- 3.) Press exit and select 7.
- 4) Phone will reboot.
- 5.) SIM should work.
- 6.) Type *0141# and press call.
- 7.) Power off the phone and insert another sim card
- 8.) If a code is requested, Enter 00000000.

NOTE : CELLCOMTRONIC.COM ARE NOT RESPONSIBLE FOR ANY PROBLEM OCCURS WHILE USING THESE CODE. ITS ALL DOWN TO THE USER WHO IS USING THESE CODE.

*#9998*289# : Change Alarm Buzzer Frequency
*#9998*364# : Watchdog
*#9998*523# : Change LCD contrast - Only with version G60RL01W
*#9998*746# : SIM File Size
*#9998*862# : Vocoder Reg - Normal, Earphone or carkit can be selected
*#9998*786# : Run, Last UP, Last DOWN
If the up Codes doesn't work, you should change *#9998* to *#0. i.e. *#9998*523# change to *#0523#. An other thing that will help is to remove your SIM card. *0001*s*f*t# : Changes serial parameters (s=?, f=0,1, t=0,1) (incomplete)
0003?# : unknown
0003?# : unknown
*#9998*377# : EEPROM Error Stack - Use side keys to select values. Cancel and ok
*#9998*427# : Trace Watchdog
*#9998*785# : RTK (Run Time Kernel) errors - if ok then phn is reset, info is put in memory error.
*#9998*778# : SIM Service Table
*#9998*947# : Reset On Fatal Error
*#9998*872# : Diag
*#9998*999# : Last/Chk
*#9998*324# : Debug screens
*#9998*636# : Memory status
*#9998*544# : Jig detect
*#9998*842# : Test Vibrator - Flash the screenlighth during 10 seconds and vibration activated

*#9998*837# : Software Version
 *#9998*228# : Battery status (capacity, voltage, temperature)
 *#9998*246# : Program status
 *#9998*9266# : Yann debug screen (=Debug Screens?)
 *#9998*9999# : Software version

SP-unlock SGH-600 (and also SGH-Sgh-600)

*2767*3855# : Full EEPROM Reset (THIS CODE REMOVES SP-LOCK!!)

But also changes IMEI to 447967-89-400044-0. (Doing this is illegal)

*2767*2878# : Custom EEPROM Reset

*These codes have been tested with version FLD_2C6 G60SB03X of Samsung SGH-600

Samsung SGH-600 Unlock Codes

*#9999# : Show Software Version
 *#9125# : Activates the smiley when charging.
 *#0001# : Show Serial Parameters
 *#0837# : Show Software Version (instructions)

- **Sony ericson**

<*<	Use to display the information about mobile network
< 0 0 0 0 >	Use to reset Sony Ericsson mobile default language
>*<*<*	Use to display the mobile software version
<0000>	Use to reset Sony Ericsson mobile default theme
#	To display the SIM Number of the mobile
**04*0000*0000*0000#	You can access you mobile settings without SIM card
*#0000#	Use to reset Sony Ericsson mobile English menu
904060 + >	Use to reset mobile phone settings
904093 + menu	Use to display the CDMA Mode
On/off button	Press and release quickly on/off button to verify the battery
status. > * > (>);	To display the text contained in the phone

Nokia

Code Description

*3370# Activate Enhanced Full Rate Codec (EFR) - Your phone uses the best sound quality but talk time is reduced my approx. 5%

#3370# Deactivate Enhanced Full Rate Codec (EFR)

*4720# Activate Half Rate Codec - Your phone uses a lower quality sound but you should gain approx 30% more Talk Time.

#4720# Deactivate Half Rate Codec.

*#0000# Displays your phones software version, 1st Line : Software Version, 2nd Line : Software Release Date, 3rd Line : Compression Type.

*#9999# Phones software version if *#0000# does not work.

*#06# For checking the International Mobile Equipment Identity (IMEI Number).

#pw+1234567890+1# Provider Lock Status. (use the "*" button to obtain the "p,w" and "+" symbols).

#pw+1234567890+2# Network Lock Status. (use the "*" button to obtain the "p,w" and "+" symbols).

#pw+1234567890+3# Country Lock Status. (use the "*" button to obtain the "p,w" and "+" symbols).

#pw+1234567890+4# SIM Card Lock Status. (use the "*" button to obtain the "p,w" and "+" symbols).

*#147# (vodafone) this lets you know who called you last.

*#1471# Last call (Only vodafone).

*#21# Allows you to check the number that "All Calls" are diverted to.

*#2640# Displays security code in use.

*#30# Lets you see the private number.

*#43# Allows you to check the "Call Waiting" status of your phone.

*#61# Allows you to check the number that "On No Reply" calls are diverted to.

*#62# Allows you to check the number that "Divert If Unreachable (no service)" calls are diverted to.

*#67# Allows you to check the number that "On Busy Calls" are diverted to.

*#67705646# Removes operator logo on 3310 & 3330.

*#73# Reset phone timers and game scores.

*#746025625# Displays the SIM Clock status, if your phone supports this power saving feature "SIM Clock Stop Allowed", it means you will get the best standby time possible.

*#7760# Manufactures code.

*#7780# Restore factory settings.

*#8110# Software version for the nokia 8110.

*#92702689# Displays - 1.Serial Number, 2.Date Made, 3.Purchase Date, 4.Date of last repair (0000 for no repairs), 5.Transfer User Data. To exit this mode you need to switch your phone off then on again.

*#94870345123456789# Deactivate the PWM-Mem.

**21*number# Turn on "All Calls" diverting to the phone number entered.

**61*number# Turn on "No Reply" diverting to the phone number entered.

**67*number# Turn on "On Busy" diverting to the phone number entered.

12345 This is the default security code.

press and hold # Lets you switch between lines.

Apple iPhone's



3001#12345# and tap Call. Enter field mode

Field mode reveals many of the inner settings of your iPhone specially up-to-date network and cell information

*#06# Displays IMEI. No need to tap call

IMEI is the unique identifier for your cell phone hardware together with your SIM information it identifies you to the provider network

*777# and tap Call. Account balance for prepaid iPhone

*225# and tap Call. Bill Balance. (Postpaid only)

*646# and tap Call. Check minutes. (Postpaid only)

These three are pretty self explanatory

*#21# and tap call. Setting interrogation for call forwards.

Discover the settings for your call forwarding. You'll see whether you have voice, data, fax, sms, sync, async, packet access, and pad access call forwarding enabled or disabled.

*#30# and tap Call. Calling line presentation check.

This displays whether you have enabled or disabled the presentation of the calling line, presumably the number of the party placing the call.

*#76# and tap Call. Check whether the connected line presentation is enabled or not.

State whether the connected line presentation is enabled or disabled. Presumably similar to the calling line presentation.

*#43# and tap Call. Determine if call waiting is enabled

Displays call waiting status for voice, data, fax, sms, sync data, async data, packet access and pad access. Each item is either enabled or disabled.

*#61# and tap Call. Check the number for unanswered calls.

Show the number for voice call forwarding when a call is answered. Also show the options for data, fax, sms, sync, async, packet access and pad access

*#62# and tap Call. Check the number for call forwarding if no service is available.

Just like the previous, except for no-service rather than no-answer situations.

*#67# and tap Call. Check the number for call forwarding when the iPhone is busy.

And again, but for when the iPhone is busy.

*#33# and tap Call. Check for call control bars

Here you will find all GSM-Codes/Secret-Code, for the iPhone are relevant.

*#06# Displays your IMEI on your iPhone.

3001#12345# To get your access to the field test mode of iPhone.

*#30# Thus, you can check whether the caller identification (Clip-function) in the iPhone is active.

*#43# Call Waiting Status

*43# Activate a waiting

#43# Deactivate waiting

Change PIN1: **04* old PIN * new PIN * new PIN #

Change PIN2: **042*old PIN * new PIN * new PIN #

*#746025625# SIM Clock Stop Mode

Whether your SIM card the SIM Clock Stop mode supported, you can find out with this code. The iPhone will then idle at the SIM card, ie no calls, etc., all activities on the SIM card. This has a positive effect on power consumption and prolongs battery life.

*3370# EFR mode

Enhanced Full Rate improves voice quality, but slightly reduced battery life.

#3370# ERF OFF mode

*4720# Half Rate (HFR) on

Opposite of ERA.

#4720# Half Rate (HFR) off

*21# Call divert a

#21# Call divert from

**21* destination number # number programmed

###21 deletes the call transfer is complete.

*#21# Call Forwarding Overview

**61* destination number ** (Time 5 to 30 seconds) # divert after 5 to 30 seconds to ring

*61# Activate divert

#61# Call divert Disabled

##61# Deletes Diversion

*#61# Call divert status

**62* destination number # redirection in unattainability

*62# Turning

#62# Off

##62# Clear

*#62# Status

**67* destination number # for Divert if busy

*67# Turning

#67# Off

##67# Clear

*#67# Status

*31# phone number is transmitted

#31# phone number is not transmitted

*#5005*86# Are you the code, it displays the current mailbox settings.

*5005*86*# xxxxx Combox mail button on the available

(xxxxx = mailbox number)

*646# minutes consumption control

*135# Display Own Phone Number

33 barring code # Outgoing calls to block the lock code to inquire about her please contact your network operator.

*#33 Unlock

*#33# Status

331 barring code # Outgoing calls abroad to block the lock code to inquire about her please contact your network operator.

#331* barring code # lift blockade

*#331# status

*#5005*7672# SMS- center check

Current number of the SMS Center (SMSC) to find out. Each SMSC according to variable cost

*5005*7672*xxxxxxx # SMS Center reactivate

(xxxxxxx = SMS center number)

Lg Reset code

*6861# factory reset

*8375#

#668#

*#3646633#

*0#

*3241#

*3240#

*0008# language

*0009# language

*0000# language
*7674#
*76863#
*77463#
*72337#
*79763#
*7245786# check read FFS
*762442# GVCMMI Magic
###765*02#
###765*05#
###765*08#
###765*07#
###765*78#
1945#*5101# sim lock menu
2945#*5100#

LG all models test mode: Type 2945## on the main screen.

2945*#01## Secret menu for LG

IMEI (ALL): *#06#

IMEI and SW (LG 510): *#07#

Software version (LG B1200): *8375#

Recount checksum (LG B1200): *6861#

Factory test (B1200): #PWR 668

Simlock menu (LG B1200): 1945#*5101#

Simlock menu (LG 510W, 5200): 2945#*5101#

Simlock menu (LG 7020, 7010): 2945#*70001#

Simlock menu (LG 500, 600): 2947#*

LG-U81XX SPECIAL CODES

Code to read phone version :

- Phone without SIM
- Enter 277634## or 47328545454#
- Select 'SW Ver.info'

Code to reset phone :

- Phone without SIM
- Enter 277634## or 47328545454#
- Select 'Factory Reset'

Code to enter UNLOCK MENU :

- Phone wit SIM inside

- Enter 2945#*88110#

Test Menu 8330 : 637664#*#

Test Menu 8180 V10a: 49857465454#

Test Menu 8180 V11a: 492662464663#

Test Menu 8130-8138: 47328545454#

Test Menu 8110-8120: 277634#*#

Phone Service Menu Code

8110 277634#*#

8120 277634#*#

8130 47328545454#

8138 47328545454#

8180 v10A 49857465454#

8180 v11A 492662464663#

8330 637664#*#

8360 *6*41*12##

8380 525252#*#

8550 885508428679#*#

u900 082065#*#

u880 142358#*#

ku311/l600v/ku800 63342425#*#

Phone Unlock Menu Code

Older phones 2945#*88110#

ku990 Press and Hold Camera + Lock Button.

..then write3845#*990#

2945#*#

277634#*#

47328545454#

lg ku 380

code reset 3845#*380#

2945#*380# reset factory

some useful codes for u880

*854#46

277634#*# (TEST MENU)

*748#96 (DEBUG)

23#*#(SOME CRAP)

U880 * 5 Power ON

LG Chocolate =2945#*#

lg kf700 =3845#*700#

lg ku250 =26911147#*250#

LG 900 v09e
Citazione:
TEST MENU: 277634#*#

LG 900 v10b
Citazione:
TEST MENU: 082065#*#

LG U970 Shine
Citazione:
TEST MENU: 26911147#*970#

LG L600V
Citazione:
TEST MENU: 63342425#*#

LG KU310
Citazione:
TEST MENU: 63342425#*#
ENGINEER MODE: *72346#96

LG KU800
Citazione:
TEST MENU: 26911147#*#

LG KU830
Citazione:
TEST MENU: 26911147#*#

LG KU950
Citazione:
TEST MENU: 7973845#*#
ENGINEER MODE: 21738#96

LG KU990
Citazione:
TEST MENU: 3845#*990#
ENGINEER MODE: 364663#96
MENU NCK: 2945#*990#

F310 kF311 reset codes

Test menu: 3845#*310#
for kf311 3845#*311#
engineer mode: 364663#31
menu : 2945#*#

LG KE850 ***** security

without and with simcard: 1475369586#*# try this one too: 338464#*# ,then go Reset or restore default.

LG KU800 reset code = 277634#*#

kf311/310 =no sim inside
3845#*310#

KT520 user code reset =338464#*#

LG KF700 Security Cod

Tools:

Google Search

Procedure:

Power On Phone w/o sim card

Input 3845#*700#

Test Mode will pop up (Screen shot Below)

Just Hit Factory Reset

Wait Phone to Reboot

LG KG110 SECURITY CODE == 2945#*5101#

Kp500

For Factory Reset try this code 1809#*500# without SIM card.

LG U8110 277634#*#

LG U8120 277634#*#

LG U8120v105 47328545454#

LG U8130 47328545454#

LG U8138 47328545454#

LG U8180v10A 49857465454#

LG U8180v11A 492662464663#

LG U8330 637664#*#

LG U8360 *6*41*12##

LG U8360 V.10D & V.10E *5*33*62##

LG U8380 525252#*#

LG U8550 885508428679#*#

LG 8550 (italian Unlock Flash)v08j 2945#*#

LG U880 U890 142358#*#

LG U900 v09e 277634#*#

LG U900 v10b 082065#*#

LG U310 566366#*#

LG U310 menù NCK815118#*#

LG L600V 63342425#*#

LG 8150 277634#*#

الكودات يعطى وهذه

LG 8210

Citazione:

277634#*#

LG U250

Citazione:

TEST MENU: 26911147#*250#

MENU NCK: 2945#*250#

ENGINEER MODE: 3646633#96

LG U310

Citazione:

TEST MENU: 566366#*#

MENU NCK: 815118#*#

ENGINEER MODE: *72346#96

LG U450

Citazione:

MENU NCK: 2945#*450#

ENGINEER MODE: *72346#96

LG 880

Citazione:

TEST MENU: 142358#*#

ENG MENU: *854#46

LG 880 english version

Citazione:

*854#46

LG 890

Citazione:

TEST MENU: 142358#*#

LG 900 v09e

Citazione:

TEST MENU: 277634#*#

LG 900 v10b

Citazione:

TEST MENU: 082065#*#

LG U970 Shine

Citazione:

TEST MENU: 26911147#*970#

LG L600V

Citazione:

TEST MENU: 63342425#*#

LG KU310

Citazione:

TEST MENU: 63342425#*#

ENGINEER MODE: *72346#96

LG KU800

Citazione:

TEST MENU: 26911147#*#

LG KU830

Citazione:

TEST MENU: 26911147#*#

LG KU950

Citazione:

TEST MENU: 7973845#*#

ENGINEER MODE: 21738#96

LG KU990

Citazione:

TEST MENU: 3845#*990#

ENGINEER MODE: 364663#96

MENU NCK: 2945#*990#

8110 & 8120 : 277634#*#

U8130 & U8138 : 47328545454#

8180 old sw : 49857465454#

8180 new sw : 492662464663#

8330 : 637664#*#

8360 : *6*41*12##

8380 : 525252#*#

8550 : 885508428679#*# 2945#*# 8550 unlocked

885508428679#*# 8550 original

26911147#*250# and reset factory

LG C3100 press 2945#*3101#

LG C3380 press 2945#*7101#

LG F2300 press 2945#*7101#

LG KE260 press 2945#*2601#

LG KE970 press 2945#*9701#

LG KG120 press 2945#*1201#

LG KG220 press 2945#*1201#

LG KG240 press 2945#*3311#

LG KG280 press 2945#*7101#

LG KG290 press 2945#*7101#

LG KG800 press 2945#*7101#

LG KP500 press 2945#*71101#

LG KU250 press 2945#*250#

LG KU380 press 2945#*380#

LG KC910 press 2945#*910#

hi all

[reset code for Lg u250 / ku250]

it's only for who need it 26911147#* 250# and select factory reset (without sim)

ALL LG 2G : 2945#*#

LG U8110 277634#*#

LG U8120 277634#*#

LG U8120v105 47328545454#

LG U8130 47328545454#

LG U8138 47328545454#

LG U8180 v10A 49857465454#

LG U8180 v11A 492662464663#

LG U8330 637664#*#

LG U8360 *6*41*12##

LG U8360 V.10D & V.10E *5*33*62##

LG U8380 525252#*#

LG U8550 885508428679#*#

LG 8550 (italian Unlock Flash)v08j 2945#*#

LG U880 U890 142358#*#

LG U900 v09e 277634#*#

LG U900 v10b 082065##
LG U310 566366##
LG U310 menù NCK815118##
LG L600V 63342425##

8110 & 8120 : 277634##
U8130 & U8138 : 47328545454#
8180 old sw : 49857465454#
8180 new sw : 492662464663#
8330 : 637664##
8360 : *6*41*12##
8380 : 525252##
8550 : 885508428679##2945## 8550 unlocked
885508428679## 8550 original

26911147##250# and reset factory

LG C3100 press 2945##3101#
LG C3380 press 2945##7101#
LG F2300 press 2945##7101#
LG KE260 press 2945##2601#
LG KE970 press 2945##9701#
LG KG120 press 2945##1201#
LG KG220 press 2945##1201#
LG KG240 press 2945##3311#

LG KG280 press 2945##7101#
LG KG290 press 2945##7101#
LG KG800 press 2945##7101#
LG KP500 press 2945##71101#
LG KU250 press 2945##250#
LG KU380 press 2945##380#
LG KC910 press 2945##910#

[reset code for Lg u250 / ku250]

it's only for who need it 26911147##* 250# and select factory reset (without sim)

ALL LG 2G : 2945##
LG U8110 277634##
LG U8120 277634##
LG U8120v105 47328545454#
LG U8130 47328545454#
LG U8138 47328545454#
LG U8180 v10A 49857465454#
LG U8180 v11A 492662464663#
LG U8330 637664##
LG U8360 *6*41*12##
LG U8360 V.10D & V.10E *5*33*62##
LG U8380 525252##
LG U8550 885508428679##
LG 8550 (italian Unlock Flash)v08j 2945##
LG U880 U890 142358##
LG U900 v09e 277634##
LG U900 v10b 082065##
LG U310 566366##

LG U310 menù NCK815118##
LG L600V 63342425##

HTC Reset:

1. Power OFF the phone
2. Press & Hold the volume keys up & down together with the power keys until the display switch on and view the SPL.....>
3. APPSDL – with two option “IMAGE CBC” and “FACTORY RESET” > choose the factory reset by using volume control to scroll on the options.
4. Next option is restart the phone...

