

CLASS A	10,000 - 55.000	SPD UNLIMITED unless instructed by ATC within FIR
---------	-----------------	--

CLASS C	10,000 - GND	Departing using SID/arriving using STAR to/from runway MAX SPD 200 KTS
---------	--------------	--

ALL FLIGHTS ARE  
IFR

MAX SPD WHILE  
LANDING &  
TAKEOFF 200 KTS

ALT & ELV IN FT

## AERODROMES

### Kuwait International Airport(OKKK/KWI)

DEPARTING VIA RW15R TO KUA02	RW15R TO ARR4 ALT 4000 TO KUA02 ALT 6000
------------------------------	---

DEPARTING VIA RW15L TO KUA02	RW15L TO ARR3 ALT 4000 TO KUA02 ALT 6000
------------------------------	---

ARRIVING VIA KUA02 TO RW33R	KUA02 ALT 4000 TO ARR3 ALT 1000 RW33R ELV 203
-----------------------------	--

GO AROUND KUA02 TO RW33R	KUA02 ALT 4000 TO ARR3 ALT 1000
--------------------------	---------------------------------

	RW33R TO ARR2 ALT 4000 TO KUA01 ALT 4000 & follow ARRIVING VIA KUA02 TO RW33R
ARRIVING VIA KUA02 TO RW33L	KUA02 ALT 4000 TO ARR4 ALT 1000 RW33L ELV 165
GO AROUND KUA02 TO RW33L	KUA02 ALT 4000 TO ARR4 ALT 1000 RW33L TO ARR1 ALT 4000 TO KUA01 ALT 4000 & follow ARRIVING VIA KUA02 TO RW33L
DEPARTING VIA RW33R TO KUA01	RW33R TO ARR2 ALT 4000 TO KUA01 ALT 6000
DEPARTING VIA RW33L TO KUA01	RW33L TO ARR1 ALT 4000 TO KUA01 ALT 6000
ARRIVING VIA KUA01 TO RW15R	KUA01 ALT 4000 TO ARR1 ALT 1000 RW15R ELV 131
GO AROUND KUA01 TO RW15R	KUA01 ALT 4000 TO ARR1 ALT 1000 RW15R TO ARR4 ALT 4000 TO KUA02 ALT 4000 & follow ARRIVING VIA KUA01 TO RW15R
ARRIVING VIA KUA01 TO RW15L	KUA01 ALT 4000 TO ARR2 ALT 1000 RW15L ELV 155
GO AROUND KUA01 TO RW15L	KUA01 ALT 4000 TO ARR2 ALT 1000 RW15L TO ARR3 ALT 4000 TO KUA02 ALT 4000 & follow ARRIVING VIA KUA01 TO RW15L
RALKA SID KUA01	RALKA STAR KUA01

HOLD ALT 6000 KUA05 KUA06 KUA07  
ALT10000 RALKA ALT 10000

RALKA ALT 4000 KUA07 ALT 4000 KUA06  
KUA05 KUA01(refer to ARRIVING VIA  
KUA01 TO 15R/L

RALKA SID KUA02

RALKA STAR KUA02

HOLD ALT 6000 KUA03 KUA04 KUA07  
ALT 10000 RALKA 10000

RALKA ALT 4000 KUA07 ALT 4000 KUA04  
KUA03 KUA02(refer to ARRIVING VIA  
KUA02 TO 33R/L

ALVAX SID KUA01

ALVAX STAR KUA01

HOLD ALT 6000 KUA09 KUA10 KUA11  
ALT 10000 ALVAX ALT 10000

ALVAX ALT 4000 KUA11 ALT 4000  
KUA10 KUA09 KUA01(refer to ARRIVING  
VIA KUA01 TO 15R/L

ALVAX SID KUA02

ALVAX STAR KUA02

HOLD ALT 6000 KUA08 KUA11 ALT  
10000 ALVAX ALT 10000

ALVAX ALT 4000 KUA11 ALT 4000  
KUA08 KUA02(refer to ARRIVING VIA  
KUA02 TO 33R/L

SESRU SID KUA01

SESRU STAR KUA01

HOLD ALT 6000 KUA12 KUA13 KUA14 ALT 10000  
SESRU ALT 10000

SESRU ALT 4000 KUA14 ALT  
4000 KUA013 KUA12 KUA01(refer  
to ARRIVING VIA KUA01 TO  
15R/L

SESRU SID KUA02

SESRU STAR KUA02

HOLD ALT 6000 KUA14 ALT 10000  
SESRU ALT 10000

SESRU ALT 4000 KUA14 ALT 4000  
KUA02(refer to ARRIVING VIA KUA02 TO  
33R/L

BOXIK SID KUA01

BOXIK SID KUA02

HOLD ALT 6000 KUA15 KUA16 KUA17  
KUA02 KUA18 ALT 10000 BOXIK ALT  
10000

HOLD ALT 6000 KUA18 ALT 10000  
BOXIK ALT 10000

DEBTI STAR KUA01

DEBTI STAR KUA02

DEBTI ALT 4000 KUA22 ALT 4000 KUA02  
KUA21 KUA20 KUA19 KUA01(refer to  
ARRIVING VIA KUA01 TO 15R/L

DEBTI ALT 4000 KUA22 ALT 4000  
KUA02(refer to ARRIVING VIA KUA02 TO  
33R/L

ASVIR SID KUA01

ASVIR STAR KUA01

HOLD ALT 6000 KUA23 KUA24 KUA25  
KUA02 KUA26 ALT 10000 ASVIR ALT  
10000

ASVIR ALT 4000 KUA26 ALT 4000 KUA02  
KUA25 KUA24 KUA23 KUA01(refer to  
ARRIVING VIA KUA01 TO 15R/L

ASVIR SID KUA02

ASVIR STAR KUA02

HOLD ALT 6000 KUA26 ALT 10000  
ASVIR ALT 10000

ASVIR ALT 4000 KUA26 ALT 4000  
KUA02(refer to ARRIVING VIA KUA02 TO  
33R/L

KUNRU STAR KUA01

KUNRU STAR KUA02

KUNRU ALT 4000 KUA30 ALT 4000  
KUA02 KUA29 KUA28 KUA27 KUA01(refer  
to ARRIVING VIA KUA01 TO 15R/L

KUNRU ALT 4000 KUA30 ALT 4000  
KUA02(refer to ARRIVING VIA KUA02 TO  
33R/L

KFR SID KUA01

KFR STAR KUA01

HOLD ALT 6000 KUA32 KUA33 KUA34  
ALT 10000 KFR ALT 10000

KFR ALT 4000 KUA34 ALT 4000 KUA33  
KUA32 KUA01(refer to ARRIVING VIA  
KUA01 TO 15R/L

KFR SID KUA02

KFR STAR KUA02

HOLD ALT 6000 KUA31 KUA34 ALT  
10000 KFR ALT 10000

KFR ALT 4000 KUA34 ALT 4000 KUA31  
KUA02(refer to ARRIVING VIA KUA02 TO  
33R/L

BONIM SID KUA01

BONIM STAR KUA01

HOLD ALT 6000 KUA37 KUA38 KUA39  
ALT 10000 BONIM ALT 10000

BONIM ALT 4000 KUA39 ALT 4000  
KUA038 KUA37 KUA01(refer to ARRIVING  
VIA KUA01 TO 15R/L

BONIM SID KUA02

BONIM STAR KUA02

HOLD ALT 6000 KUA35 KUA36 KUA39  
ALT 10000 BONIM ALT 10000

BONIM ALT 4000 KUA39 ALT 4000  
KUA36 KUA35 KUA02(refer to ARRIVING  
VIA KUA02 TO 33R/L

BUMBER SID KUA01

BUMBER STAR KUA01

HOLD ALT 6000 KUA42 KUA43 KUA44  
ALT 10000 BUMBER ALT 10000

BUMBER ALT 4000 KUA44 ALT 4000  
KUA43 KUA42 KUA01(refer to ARRIVING  
VIA KUA01 TO 15R/L

BUMBER SID KUA02

BUMBER STAR KUA02

HOLD ALT 6000 KUA40 KUA41 KUA44  
ALT 10000 BUMBER ALT 10000

BUMBER ALT 4000 KUA44 ALT 4000  
KUA41 KUA40 KUA02(refer to ARRIVING  
VIA KUA02 TO 33R/L

ATS ROUTES

Notes

SIDAD R784 NANPI

FL 310(31,000FT) FL510(51,000FT) MAX

	SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
SIDAD P975 LONOS	FL 310(31,000FT) FL510(51,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
SIDAD P975 SESRU M677 RABAP	FL 310(31,000FT) FL510(51,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
DAVUS L602 TASMI	FL 300(30,000FT) FL500(50,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS
RALKA L602 TASMI	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS
DAVUS L602 RALKA	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS
ALVAX B417 TULAX	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
TULAX B417 ALVAX	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS
SIDAD N302 ALVAX	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS
ALVAX B417 DESLU R784 NANPI	FL 100(10,000FT) FL300(30,000FT) MAX

	SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
SESRU G669 NANPI	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
NANPI G669 SESRU	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS
BOXIK B416 IMDOX LONOS	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
BOXIK B416 AMBIK	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
BOXIK A788 PATIR	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT ODD LVLS
KUMBO A453 DEBTI	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS
KFR KATOD	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS
KFR DEKOB	FL 100(10,000FT) FL300(30,000FT) MAX SPD UNLIMITED (UNLESS INSTRUCTED BY ATC) ALT EVEN LVLS



SOROR KFR

FL 100(10,000FT) FL300(30,000FT) MAX  
SPD UNLIMITED (UNLESS INSTRUCTED  
BY ATC) ALT ODD LVLS

KFR NIDAP

FL 100(10,000FT) FL300(30,000FT) MAX  
SPD UNLIMITED (UNLESS INSTRUCTED  
BY ATC) ALT EVEN LVLS

NIDAP KFR

FL 100(10,000FT) FL300(30,000FT) MAX  
SPD UNLIMITED (UNLESS INSTRUCTED  
BY ATC) ALT ODD LVLS

BUBER G669 SOLAT

FL 100(10,000FT) FL300(30,000FT) MAX  
SPD UNLIMITED (UNLESS INSTRUCTED  
BY ATC) ALT EVEN LVLS

SOLAT G669 BUBER

FL 100(10,000FT) FL300(30,000FT) MAX  
SPD UNLIMITED (UNLESS INSTRUCTED  
BY ATC) ALT ODD LVLS