















| HW编码 | | 图标 | Context | 内容 |
|------|---|-----|--|---------------|
| 1 |  | 图标2 | Windscreen could become fogged | 挡风玻璃可能蒙上了雾 |
| 2 |  | 图标2 | Operating temperature not maintained | 未遵守工作温度 |
| 3 |  | 图标2 | No driver detected | 未识别到驾驶员 |
| 4 |  | 图标2 | Gearbox requires engine to be running. | 变速箱需要发动机运行 |
| 5 |  | 图标2 | Vehicle energy requirement is high. | 车辆能量需求高 |
| 6 |  | 图标2 | Starting start-stop system | 启动停止系统正在启动... |
| 7 |  | 图标2 | Engine must be running | 需要发动机运行. |
| 8 |  | 图标2 | Gradient too steep | 过于倾斜 |
| 9 |  | 图标2 | Start-stop system is currently not available | 起动停止系统目前不可用 |
| 0A |  | 图标2 | Emergency brake function intervention | 紧急制动功能干预. |
| 0B |  | 图标2 | Brake requires engine to be running | 制动器需要发动机运行. |
| 0C |  | 图标2 | Power consumption is high | 车辆能量需求高 |

| | | | | |
|----|---|-----|--|----------------|
| 0d |  | 图标2 | Start-stop system requires engine to be running. | 启动停止系统需要发动机运行. |
| 0f |  | 图标2 | Vehicle energy requirement is high. | 空调器需要发动机运行 |
| 10 |  | 图标2 | No driver detected | 未识别到驾驶员 |
| 11 |  | 图标2 | Driver door is open | 驾驶座侧门打开 |
| 12 |  | 图标2 | Bonnet has been opened | 安全带已打开 |
| 13 |  | 图标2 | System protection intervention. | 系统保护干预. |
| 14 |  | 图标2 | No engine start due to system requirement. | 因系统需求发动机不启动 |
| 15 |  | 图标2 | Trailer mode | 带挂车行驶 |
| 20 |  | 图标3 | Steering angle too wide. | 转向角度过大 |
| 21 |  | 图标3 | Manoeuvring mode | 调车模式 |
| 22 |  | 图标3 | Defrost function is switched on | 除霜功能已打开 |
| 23 |  | 图标3 | Driver seatbelt is not fastened | 驾驶员安全带锁未扣上 |

| | | | | |
|----|---|-----|---|-------------------|
| 24 |  | 图标3 | Driver door is open | 驾驶员侧车门敞开 |
| 25 |  | 图标3 | Accelerator is depressed | 已踩下油门踏板 |
| 26 |  | 图标3 | Windscreen heating is switched on | 挡风玻璃加热装置已接通 |
| 27 |  | 图标3 | Manximum air conditioning requires engine to be running | 空调满功率功能已打开 |
| 28 |  | 图标3 | Bonnet has been opened | 发动机舱盖已打开 |
| 29 |  | 图标3 | Engine stop currently not possible | 目前无法停止发动机 |
| 2A |  | 图标3 | Off-road mode is activated | 越野模式已激活 |
| 2B |  | 图标3 | System protection intervention. Button/lever activated too ofte | 系统保护干预. 操作/启动进程过多 |
| 2C |  | 图标3 | Gear is engaged | 已挂档 |
| 2D |  | 图标3 | Start-stop button pressed | 已按下自动起停按钮 |
| 2E |  | 图标3 | Air condition requires engine to be running | 空调器需要发动机运行 |
| 2F |  | 图标3 | ACC intervention | ACC干预 |

| | | | | |
|----|---|-----|--|-------------------|
| 30 |  | 图标3 | Park Assist is activated | 自动泊车系统已激活 |
| 31 |  | 图标3 | ESC is switched off | 车身稳定控制系统(ESC)已关闭 |
| 32 |  | 图标3 | Vehicle energy requirement is high. | 车辆能量需求高 |
| 33 |  | 图标3 | Driver seatbelt is not fastened | 驾驶员安全带锁未扣上 |
| 34 |  | 图标3 | No driver detected | 没有驾驶员 |
| 35 |  | 图标3 | Please start the engine manually. | 请手动启动发动机 |
| E0 |  | 图标1 | Start-stop system is activated | 自动起停系统已激活 |
| e1 |  | 图标1 | Start-stop system is available | 自动起停系统可用 |
| E2 |  | 图标1 | Engine stop active | 发动机停止已激活 |
| E4 |  | 图标2 | Start-stop system is not available. | 自动起停系统不可用 |
| E5 |  | 图标3 | Driver door opened.Driver not properly detected. | 驾驶员车门已打开. 未准确识别到驾 |
| E6 |  | 图标3 | Please press the brake pedal. | 请踩下制动踏板 |

| | | | | |
|----|---|-----|--|----------------|
| E7 |  | 图标3 | Release the clutch to stop the engine. | 要停止发动机. 请松开离合器 |
| E8 |  | 图标3 | Start-stop system deactivated. | 自动起停系统已关闭 |
| E9 |  | 图标1 | Error:start-stop system | 故障: 自动起停系统 |