

Energy Plus Settings Summary

General Settings

| Setting | Value |
|-------------------|--|
| Version | EnergyPlus Version 9.4.0.002 |
| RunPeriod | Location: 1 Start Date: 1 1, 2002.0 End Date: 12 31, 2002.0 use weather file rain indicators use weather file snow indicators Treat Weather as Actual |
| Timestep | 6 timesteps per hour |
| ConvergenceLimits | Min System Time Step: 1 Max HVAC Iterations: 25 |
| SimulationControl | Do the zone sizing calculation: No Do the system sizing calculation: No Do the plant sizing calculation: No Do the design day calculation: No Do the weather file calculation: Yes |

Location Settings

| Setting | Value |
|---------------|---|
| Site:Location | Location: 1 (01-01:31-12) (01-01:31-12) Latitude: 51.15° Longitude: -0.18° Time Zone: GMT0.0 Elevation: 62.0m |

Ground Temperature Settings

| Setting | Value |
|--|--|
| Site:GroundTemperature:BuildingSurface | Jan Feb Mar Apr 18.00 18.00 18.00 18.00 May Jun Jul Aug 18.00 18.00 18.00 18.00 Sep Oct Nov Dec 18.00 18.00 18.00 18.00 |

| Setting | Value |
|---------------------------------------|--|
| Site:GroundTemperature:Deep | Jan Feb Mar Apr 18.00 18.00 18.00 18.00 May Jun Jul Aug 18.00 18.00 18.00 18.00 Sep Oct Nov Dec 18.00 18.00 18.00 18.00 |
| Site:GroundTemperature:Shallow | Jan Feb Mar Apr 18.00 18.00 18.00 18.00 May Jun Jul Aug 18.00 18.00 18.00 18.00 Sep Oct Nov Dec 18.00 18.00 18.00 18.00 |
| Site:GroundTemperature:FCfactorMethod | Jan Feb Mar Apr 4.16 5.30 7.51 9.61 May Jun Jul Aug 13.58 15.67 16.24 15.18 Sep Oct Nov Dec 12.74 9.69 6.69 4.70 |

Ground Reflectance Settings

| Setting | Value |
|-------------------------------------|--|
| Site:GroundReflectance | Jan Feb Mar Apr 0.20 0.20 0.20 0.20 May Jun Jul Aug 0.20 0.20 0.20 0.20 Sep Oct Nov Dec 0.20 0.20 0.20 0.20 |
| Site:GroundReflectance:SnowModifier | Jan Feb 2.00 2.00 |