

AUSTRALIA HAM RADIO ALE SELCALL CHANNELS HFLINK V2019AUG25A2				
CHANNELNAME	FREQ	MODE	NETWORKNAME	
HF- 01ASEL	01838.0	USB	Ham Sel HFS Voice	
HF- 01BALE	01843.0	USB	Ham ALE HFL Voice	
HF- 03CSEL	03590.0	USB	Ham Sel HFR Text	
HF- 03DALE	03596.0	USB	Ham ALE HFN Text	
HF- 03EALE	03600.5	USB	Ham ALE HFL Voice	
HF- 03FSEL	03605.0	USB	Ham Sel HFS Voice	
HF- 07ASEL	07044.0	USB	Ham Sel HFR Text	
HF- 07DALE	07102.0	USB	Ham ALE HFN Text	
HF- 07EALE	07185.0	USB	Ham ALE HFL Voice	
HF- 07FSEL	07195.0	USB	Ham Sel HFS Voice	
HF- 10ASEL	10126.0	USB	Ham Sel HFS Voice	
HF- 10BALE	10131.0	USB	Ham ALE HFL Voice	
HF- 10CSEL	10144.0	USB	Ham Sel HFR Text	
HF- 10DALE	10145.5	USB	Ham ALE HFN Text	
HF- 14ASEL	14094.0	USB	Ham Sel HFR Text	
HF- 14BALE	14109.0	USB	Ham ALE HFN Text	
HF- 14DSEL	14343.0	USB	Ham Sel HFS Voice	
HF- 14EALE	14346.0	USB	Ham ALE HFL Voice	
HF- 18AALE	18106.0	USB	Ham ALE HFN Text	
HF- 18BSEL	18107.0	USB	Ham Sel HFR Text	
HF- 18DALE	18117.5	USB	Ham ALE HFL Voice	
HF- 18ESEL	18163.0	USB	Ham Sel HFS Voice	
HF- 28ASEL	28143.0	USB	Ham Sel HFR Text	
HF- 28BALE	28146.0	USB	Ham ALE HFN Text	
HF- 28CSEL	28305.0	USB	Ham Sel HFS Voice	
HF- 28DALE	28312.5	USB	Ham ALE HFL Voice	
<b>NETWORKS</b>				
<b>NETWORK NAME</b>	<b>SCAN</b>	<b>CALLSYS</b>	<b>DETECTTIME</b>	<b>SOUNDING</b>
Ham Sel HFS Voice	SCAN	OPENSEL	0.3	NONE
Ham ALE HFL Voice	SCAN	ALE	0.12	OFF
Ham ALE HFN Text	SCAN	ALE	0.12	1.0hr
Ham Sel HFR Text	DON'T	OPENSEL	0.3	NONE
<b>NETS ALE</b>				
<b>NETNAME</b>	<b>ADDRESS</b>		<b>NETWORK</b>	<b>OUTGOING</b>
Ham ALE HFNTTextSound	HFN		Ham ALE HFN Text	ENABLED
Ham ALE HFL Voice	HFL		Ham ALE HFL Voice	ENABLED
<b>MEMBERS FOR NET</b>	<b>SLOT</b>	<b>#</b>	<b>MEMBERS</b>	
<b>HFN</b>	<b>SLOT</b>	<b>#</b>	<b>ADDRESS</b>	

	SLOT	1	SELF CALLSIGN	
	SLOT	2	123456	
	SLOT	3	654321	
<b>MEMBERS FOR NET</b>	<b>SLOT</b>	<b>#</b>	<b>MEMBERS</b>	
<b>HFL</b>	<b>SLOT</b>	<b>#</b>	<b>ADDRESS</b>	
	SLOT	1	SELF CALLSIGN	
	SLOT	2	123456	
	SLOT	3	654321	
<b>NETWORKCHANNELS</b>				
<b>Ham ALE HFL Voice</b>				
<b>CHANNELNAME</b>	<b>FREQ</b>	<b>MODE</b>		
HF- 01BALE	01843.0	USB		
HF- 03EALE	03600.5	USB		
HF- 07EALE	07185.0	USB		
HF- 10BALE	10131.0	USB		
HF- 14EALE	14346.0	USB		
HF- 18DALE	18117.5	USB		
HF- 28DALE	28312.5	USB		
<b>NETWORKCHANNELS</b>				
<b>Ham ALE HFN Text</b>				
<b>CHANNELNAME</b>	<b>FREQ</b>	<b>MODE</b>		
HF- 03DALE	03596.0	USB		
HF- 07DALE	07102.0	USB		
HF- 10DALE	10145.5	USB		
HF- 14BALE	14109.0	USB		
HF- 18AALE	18106.0	USB		
HF- 28BALE	28146.0	USB		
<b>NETWORKCHANNELS</b>				
<b>Ham Sel HFR Text</b>				
<b>CHANNELNAME</b>	<b>FREQ</b>	<b>MODE</b>		
HF- 03CSEL	03590.0	USB		
HF- 07ASEL	07044.0	USB		
HF- 10CSEL	10144.0	USB		
HF- 14ASEL	14094.0	USB		
HF- 18BSEL	18107.0	USB		
HF- 28ASEL	28143.0	USB		
<b>NETWORKCHANNELS</b>				
<b>Ham Sel HFS Voice</b>				
<b>CHANNELNAME</b>	<b>FREQ</b>	<b>MODE</b>		
HF- 01ASEL	01838.0	USB		
HF- 03FSEL	03605.0	USB		
HF- 07FSEL	07195.0	USB		
HF- 10ASEL	10126.0	USB		
HF- 14DSEL	14343.0	USB		
HF- 18ESEL	18163.0	USB		
HF- 28CSEL	28305.0	USB		

[illegible]



