

# ëRadio - simple myoptions.h generator - v0.8.1

feel difference

## COMMANDMENTS

- Do not use 16-17 GPIOs on WROVER module.
- Do not pullup the 12th GPIO from the outside.
- Empty value = error.
- GPIOs 34 to 39 are GPIs – input only pins. These pins don't have internal pull-up or pull-down resistors. They can't be used as outputs, so use these pins only as inputs.
- Connect display and VS RST-pin to EN ESP32 pin (value -1).
- Try not to use GPIO 0 unnecessarily.
- Please check out this article: <https://randomnerdtutorials.com/esp32-pinout-reference-gpios/>
- Please check out this article: <https://randomnerdtutorials.com/esp32-spi-communication-arduino/>
- Please check out this article: <https://github.com/e2002/yoradio#hardware-setup>
- Please check out this article: <https://github.com/e2002/yoradio/wiki/How-to-flash>



## ESP32 MODULE



WROOM



WROVER

## I NEED TO SET UP



LANGUAGE



DISPLAY



BUTTONS



ENCODERS



TOUCHSCREEN



SD CARD



RTC



IR, LED, ETC.

## LANGUAGE

?

☒ EN☐ RU

## DISPLAY

?

- ☐ NO DISPLAY    ☐ ST7735    ☐ SSD1306    ☐ NOKIA 5110    ☐ ST7789
- ☐ SH1106    ☐ 1602 I2C    ☐ SSD1306X3    ☐ SSD1327    ☒ ILI9341
- ☐ SSD1305    ☐ SH1107    ☐ LCD 1602    ☐ GC9106    ☐ 2004 I2C
- ☐ LCD 2004    ☐ SSD1305 I2C    ☐ ILI9225    ☐ ST7789X24    ☐ ST7796
- ☐ GC9A01A    ☐ ILI9488    ☐ ILI9486    ☐ SSD1322    ☐ ST7920

☐ + NEXTION

Available display models

## DISPLAY PINS

?

## DISPLAY SPI BUS

- ☐ VSPI (MOSI-23, MISO-19, SCK-18)    ☒ HSPI (MOSI-13, MISO-12, SCK-14)

DC

2

CS

15

RST

-1

BACKLIGHT

21

.....

AUDIO

☒ I2S EXTERNAL

☐ VS1053

☐ INTERNAL

☐ MONO

AUDIO PINS

DIN | DOUT

BCLK

LRC | WSEL

22

27

35

.....

ENCODERS

☐ ENCODER #1

☐ ENCODER #2

.....

TOUCH SCREEN

☒ XPT2046

☐ GT911

TS SPI BUS

☒ VSPI (MOSI-23, MISO-19, SCK-18)

☐ HSPI (MOSI-13, MISO-12, SCK-14)

CS

33

.....

SD CARD

SD SPI BUS



☒ **VSPI (MOSI-23,  
MISO-19, SCK-18)**

☐ **HSPI (MOSI-13,  
MISO-12, SCK-14)**

☐ **CUSTOM**

CS

5

ETC.

?

☒ **LED  
PIN**

☐ **IR  
PIN**

☐ **MUTE  
PIN**

☐ **WAKE  
PIN**

☒ **LIGHT  
SENSOR**

LED INDICATOR

4

LIGHT SENSOR

34



RESET

GET MYOPTIONS.H

PREVIEW

COPY

>> **link to this configuration** <<

ēRadio - simple myoptions.h generator - v0.8.1

**project homepage**