


Open Source Rover: Rocker-Bogie Assembly Instructions

Authors: Michael Cox, Eric Junkins Olivia Lofaro



Jet Propulsion Laboratory
California Institute of Technology

Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not constitute or imply its endorsement by the United States Government or the Jet Propulsion Laboratory, California Institute of Technology. ©2018 California Institute of Technology. Government sponsorship acknowledged.

Contents

| | | |
|----------|---|----------|
| 1 | Machining/Fabrication Steps | 3 |
| 1.1 | Cutting the Aluminum Channels | 3 |
| 1.2 | Cutting the Aluminum Rod | 3 |
| 2 | Mechanical/Structural Assembly | 4 |

1 Machining/Fabrication Steps

Table 1: Parts/Tools Necessary

| Item | Ref | Qty | Image | Item | Ref | Qty | Image |
|------------|-----|-----|---|--------------------------|-----|-----|---|
| 3" Channel | S2 | 4 |  | Metal Hacksaw or Bandsaw | D4 | |  |

1.1 Cutting the Aluminum Channels

On piece **S2**, measure the distance shown in Figure 1 from the edge and mark a straight line from the opposite corner to that point. Cut off the corner along that line¹. In total, you will need 4 of these modified pieces. Cut those now.





Figure 1: Channel Cutting Dimensions

1.2 Cutting the Aluminum Rod

Take the 4 inch aluminum rod **S18** and cut it down to 3 inches long, indicated by Figure 2². In total, you will need 2 of these 3-inch aluminum rods. Cut those now.

¹We use this piece to make the geometry of the rocker-bogie more structurally reinforced across its lateral bending moment. However, these channels will need to have their corners cut out because of clearance issues further on.

²These cuts keep the rod from sticking out too far from either end of the rocker-bogie pivot joint




















Figure 2: Aluminum Rod cutting dimensions

2 Mechanical/Structural Assembly

The Rocker-Bogie assembly is what attaches your wheels to the rover's body and allows it to climb over obstacles.

Table 2: Parts/Tools Necessary

| Item | Ref | Qty | Image | Item | Ref | Qty | Image |
|---------------------------------------|------|-----|---|-----------------------------------|-----|-----|---|
| 3" Channel (Modified) | S2A | 4 |  | #6 Washer | W1 | 28 |  |
| 3.75" Channel | S3 | 4 |  | 0.5" Nylon Washer | W3 | 12 |  |
| 9" Channel | S5 | 2 |  | #6 x 1/4" Standoff | T1 | 32 |  |
| Pattern F Bracket | S7 | 8 |  | #6-32 x 3/8" Button Head Screw | B2 | 52 |  |
| 0.5" Pillow Block | S11 | 4 |  | #6-32 x 5/8" Button Head Screw | B4 | 32 |  |
| 0.5" Face Tapped Clamping Hub | S13 | 2 |  | #6-32 Locking Hex Nut | B11 | 60 |  |
| 0.5" x 3" Aluminum Tube (Modified) | S18A | 2 |  | Allen Key Set | D2 | |  |
| 0.5" Collar Clamp | S22 | 4 |  | 5/16 Wrench | D1 | |  |

1. **Begin the Rocker Attachment:** Attach 9 inch channel **S5** and the a modified 3 inch channel **S2A** to pattern F bracket **S7** using screws **B2** and hex nuts **B11** making sure to put a 6-32 washer **W1** in between the channels and the bracket. Make sure that the cut modification in **S2A** is angled towards the 9 inch channel as shown in Figure 4.




Figure 3: Begin the Rocker attachment

2. **Start the Bogie pivot joint:** Put rod **S18A** though the last hole in the pattern F bracket. Then, assemble the pivot joint by attaching another modified 3 inch channel **S2A** and another pattern F bracket using washers **W3**, collar clamp **S22**, standoffs **T1**, and screws **B4**. Make sure to use the 2nd from the bottom hole on the 2nd pattern F bracket. See Figure 4:




Figure 4: Start Rocker-Bogie pivot joint

3. **Attachment for Front Corner:** Attach 3.75 inch channel **S3** to the top hole of the

pattern F bracket using spacers **T1**, screws **B4**, and hex nuts **B11** as shown in Figure 5.




Figure 5: Attaching channel to corner steering

4. **Attachment for middle Wheel:** Attach another 3.75 inch channel **S3** to the bottom hole of the pattern F bracket using spacers **T1**, screws **B4**, and hex nuts **B11** as shown in Figure 6.




Figure 6: Attachment for middle wheel

5. **Opposite edge of Rocker-Bogie Joint:** Attach another Pattern F bracket **S7** to

the opposite side of the channels using washers **W1** and **W3**, screws **B4**, and hex nuts **B8** as shown in Figure 7.




Figure 7: Start the other side of Rocker-Bogie joint

6. **Other edge of Rocker-Bogie Joint Cont:** Using washers **W1**, collar clamp **S22**, spacers **T1**, and screws **B10** attach pattern F bracket to the final connecting channels as shown in Figure 8.




Figure 8: Other edge of Rocker-Bogie joint

7. **Checkpoint:** At this point your rocker bogie joint should look like Figure 9:




Figure 9: Rocker-Bogie Checkpoint

8. **Attach Bearing Blocks:** Attach two Pillow Bearing Blocks **S11** using screws **B2** and hex nuts **B11** as shown in Figure 10. The bearing blocks should be aligned with the 5th large hole back from the front of the 9-inch U channel.




Figure 10: Pillow bearing block attachment

9. **Attach Clamping Hub:** Attach the Clamping Hub **S13** using screws **B2** and hex nuts **B11** as shown in Figure 11. The clamping hub should be centered above where you just placed the pillow bearing blocks.




Figure 11: Clamping hub attachment

Your rocker-bogie suspension joint is now complete! Repeat all of section 2 in this document to create the suspension for the other side of the rover.