


13. Combination Meter System

A: WIRING DIAGRAM


a

a




Combination Meter System

WIRING SYSTEM



WI-44330




FA : ENGINE TYPE FA

EJ : ENGINE TYPE EJ

WI-44331

Combination Meter System

WIRING SYSTEM



WP : WITH PUSH BUTTON START

WE : WITH ELECTRIC POWER STEERING

EJ : ENGINE TYPE EJ

AL : WITH AUTO HEADLIGHT BEAM LEVELER


WI-44332

Combination Meter System

WIRING SYSTEM

e

e



- FA : ENGINE TYPE FA
- EJ : ENGINE TYPE EJ
- TI : WITH TIRE INFLATION PRESSURE


WI-44333

Combination Meter System

WIRING SYSTEM

f

f



EF : EXCEPT MT MODEL ENGINE TYPE FA

EJ : ENGINE TYPE EJ

WI-44334