


Electrical Component Location

AUTO HEADLIGHT BEAM LEVELER SYSTEM (DIAGNOSTICS)

4. Electrical Component Location

A: LOCATION



LI-01708

- | | | |
|---|---|------------------------------------|
| (1) Headlight ASSY
– Headlight beam leveler actuator | (4) Headlight relay (Hi) | (7) Auto headlight beam leveler CM |
| (2) Rear vehicle height sensor | (5) Fuse 10 A (auto headlight beam
leveler CM) | (8) Combination meter |
| (3) Headlight relay (Lo) | (6) Body integrated unit | (9) Data link connector |