

Copyright ©2019–2020 Ross Bamford and Contributors.  
Open Source Hardware licenced under CERN Open Hardware Licence.  
See [https://github.com/roscopeco/rosco\\_m68k/blob/master/LICENCE.hardware.txt](https://github.com/roscopeco/rosco_m68k/blob/master/LICENCE.hardware.txt)  
OSHW UK000006 (<https://certification.oshwa.org/uk000006.html>)

Sheet: /  
File: rosco\_m68k.sch


**Title:** ROSCO\_M68K GENERAL PURPOSE MC68000 COMPUTER



Size: A4 Date: 2020-02-25



**Rev:** 1

KiCad E.D.A. kicad (5.1.5-0-10\_14)



Id: 1/6






**Title:** DTACK & BOOT

Size: User	Date: 2020-02-25	Rev: 1
KiCad E.D.A. kicad (5.1.5-0-10_14)		Id: 4/6



Sheet: /Clock_Reset/ File: Clock_Reset.sch		
<b>Title:</b> CLOCK & RESET		
Size: User	Date: 2020-02-25	Rev: 1
KiCad E.D.A. kicad	(5.1.5-0-10.14)	Id: 5/6



Sheet: /Expansion/ File: Expansion.sch		
<b>Title:</b> EXPANSION CONNECTOR		
Size: User	Date: 2020-02-25	Rev: 1
KiCad E.D.A. kicad (5.1.5-0-10.14)		Id: 6/6