





RA121099A Wiring Harness Mech Drawings

6.0L CES ECM08 (LY6 8NH)

8-Pin Boat
Harness
Connector

Check Gauges Lamp (CGL) Circuit	TACH	Coolant Temperature Sender	Buzzer	Ignition Feed	Malfunction Indicator Lamp (MIL)	Starter Circuit	Oil Pressure Sender
1	2	3	4	5	6	7	8





Engine
Control
Module
(ECM)





2-Pin Boat
Harness
Connector


Power to Panel 1	Panel Ground 2
------------------------	----------------------


































Firing Order: 1 - 8 - 7 - 2 - 6 - 5 - 4 - 3

Ignition Control: A - B - C - D - E - F - G - H



Firing Order: 1 - 8 - 7 - 2 - 6 - 5 - 4 - 3

Ignition Control: A - B - C - D - E - F - G - H



Firing Order: 1 - 8 - 7 - 2 - 6 - 5 - 4 - 3

Ignition Control: A - B - C - D - E - F - G - H