




# **RA121107A Wiring Harness Mech Drawings**

**6.0L CES ECM08 (LY6 9NH)**

**Auto Crank**

8-Pin Boat  
Harness  
Connector

Check Gauges Lamp (CGL) Circuit	TACH	Coolant Temperature Sender	Buzzer	Ignition Feed	Malfunction Indicator Lamp (MIL)	Starter Circuit	Oil Pressure Sender
1	2	3	4	5	6	7	8




57	58	87	76	45	80	42	88
Check Gauges Lamp (CGL) Circuit	TACH	Coolant Temperature Sender	Buzzer	Ignition Feed	Malfunction Indicator Lamp (MIL) 1 Circuit	Starter Circuit	Oil Pressure Sender


Engine  
Control  
Module  
(ECM)





2-Pin Boat  
Harness  
Connector


Power to Panel	Panel Ground
1	2





































Firing Order: 1 - 8 - 7 - 2 - 6 - 5 - 4 - 3

Ignition Control: A - B - C - D - E - F - G - H



Firing Order: 1 - 8 - 7 - 2 - 6 - 5 - 4 - 3

Ignition Control: A - B - C - D - E - F - G - H

