




RA121089 Wiring Harness Mech Drawings

8.1L ECM07

8-Pin Boat
Harness
Connector

1	2	3	4	5	6	7	8
	TACH	Coolant Temperature Sender	Buzzer	Ignition Feed	Malfunction Indicator Lamp (MIL)	Starter Circuit	Oil Pressure Sender





Engine
Control
Module
(ECM)





2-Pin Boat
Harness
Connector


1	2
Power to Panel	Panel Ground




























8.1L Engine



Firing Order: 1 - 8 - 7 - 2 - 6 - 5 - 4 - 3

Ignition Control: A - B - C - D - E - F - G - H



Firing Order: 1 - 8 - 7 - 2 - 6 - 5 - 4 - 3

Ignition Control: A - B - C - D - E - F - G - H

