


ORBITER CLOCKWORK ASSEMBLY MANUAL

We build space shuttles with gardening tools
so anyone can have a space shuttle of their own.


HARDWARE



SOCKET HEAD CAP SCREW (SHCS)

Metric fastener with a cylindrical head and hex drive.


M3x8 Quantity 1



SOCKET HEAD CAP SCREW (SHCS)

Metric fastener with a cylindrical head and hex drive.


M3x16 Quantity 1



SOCKET HEAD CAP SCREW (SHCS)

Metric fastener with a cylindrical head and hex drive.

M3x20 Quantity 2



TAPERED HEAT-SET INSERTS FOR PLASTIC


The tapered shape makes it easier to guide these inserts into a hole during installation. Use a drill bit to create a straight hole, then taper the top half. Heat inserts with a soldering tip so that they melt the plastic when installed. As the plastic cools, it solidifies around the knurls and ridges on the insert for excellent resistance to both torque and pull-out.

M3 Brass Heat-Set Insert Quantity: 9

HARDWARE CONT.

PTFE Tube

The PTFE tube is used between the Orbiter extruder and the Toolhead. Specific hot end lengths are listed below:



Phaetus Dragon Hotend

PTFE Tube Length 45mm

E3D V6 Hot end

PTFE Tube Length ??mm (Not Tested Yet)

Slice Engineering Mosquito Hot end


PTFE Tube Length ??mm (Not Tested Yet)

PRINTED PARTS

Clockwork Adaptor Front



Clockwork Adaptor Back



Chain Anchor



Connector Cover




Filament Release Lever




ASSEMBLY GUIDE

Assembly A. Heat-Set Inserts


1




2



3




4




Assembly B. Orbiter Clockwork Adapter

5




6




Assembly C. Connector Cover and Chain Anchor


7



8




9




Assembly Tip
This screw isn't necessary, so
save it for future projects.

10




11




Assembly Tip
This screw isn't necessary, so
save it for future projects.

12




13




14

Assembly Tip


This screw needs to be angled to bypass the main body of the orbiter.



15




16



M3x20 SHCS


17




Assembly Tip

Thread these two screws into the motor and then directly into the Chain Anchor.

18




**Assembly Tip**


Thread this screw directly into the Chain Anchor.

Assembly D. Filament Quick Release Lever

20




21




Assembly Tip
Thread this screw into the slot on the Chain Anchor until its tight then loosen by a half-turn.

22




Assembly E. Final Assembly


23




24




25




26



27



28



M3x20 SHCS


Assembly Tip
 These two screws are not part of the BOM for the Orbiter Clockwork module, because they are from the Afterburner X-Carriage.

M3x30 SHCS


29

Assembly Tip


These four screws are not part of the BOM for the Orbiter Clockwork module, because they are from the Afterburner Fan Assembly.



30



Assembly Complete



Get the Latest Version of this document:

https://github.com/spacelab2021/Orbiter-Clockwork-Module/blob/main/docs/Orbiter_Clockwork_Manual.pdf

Version: OC-1001