

# Central Topic

## 1) Life Safety

NI-700



Settings:



232



IR



I/O



IR Rcvr



Connectivity



Ethernet

IS-SPX-1000

NXD-435P

Select preset

Display RMS schedule

Axlink



RMS

Monitor:

Display monitor status

Control:

Select preset

# Central Topic

## 2) Security/ Building Access

NI-700



Settings:



232



IR



I/O



IR Rcvr



Connectivity



Ethernet

Brivo ACS-5000

Card reader

Door sensor

NXD-1200VG

Display door status

Axlink



RMS

Monitor:

Door closure

Control:

None

# Central Topic

## 3) CCTV

NI-700

 **Settings:**

 232

 IR

1

Samsung SHR-3040

Camera 1

Camera 2

Camera 3

Camera 4

 I/O

IR Rcvr

Connectivity

 Ethernet

NXD-1500VG

Preview cameras

Select cameras

Axlink

 RMS

Monitor:

Current selected camera

Control:

Monitor on/off

# Central Topic

## 4) LEED Zone 4

DVX-2100HD

Settings:

232

1  
2  
3  
4

2  
3

Relay

IR

I/O

1 Occupancy Sensor  
2 Photo Sensor  
3  
4

A/V Switcher

Video  
Inputs  
1  
2  
3  
4  
5  
6  
Outputs  
1 (DVI)  
2 (VGA)  
3 (UDM)  
Audio  
Inputs  
1  
2  
3  
4  
5 (Mic 1)  
6 (Mic 2)  
Outputs  
Line  
Amp

Connectivity

Ethernet  
Destiny  
Modes (occupied/not occupied)  
Lighting settings  
HVAC settings  
Axlink

RMS

None

# Central Topic

## 5) Fire Safety

NI-700

 **Settings:**



 232



 IR



 I/O

1

Fire pull 1

2

Fire pull 2

3

Fire pull 3

4

Fire flasher

IR Rcvr



Connectivity



 RMS

Monitor:

Zone status 1/2/3

Control:

No control

# Central Topic

## 6) HVAC

NI-700

 **Settings:**

 232

 IR

 I/O

1

2

3

4

IR Rcvr

Connectivity

FieldServer  
BacNet Gateway  
(FSB-3510)

Stat 1

Stat 2

Stat 3

 Ethernet

Setpoints

Fan control

Temperature

i!-Weather

NXD-500i

Axlink

 RMS

Monitor:

Temperature

Fan status

Control:

Fan on/off

Temperature presets

## Central Topic

### 7) Lighting Management

NI-700

Settings:



232



IR



I/O



IR Rcvr



Connectivity

Ethernet

Axlink

RE-DC (96)

RE-DM6

1 Light 1

2 Light 2

3 Light 3

4 Sconce (zone 4)

5

6

1 HVAC fan 1

2 HVAC fan 2

3 HVAC fan 3

4

5

6

RDM-6EM

Lights Up/Down

Lights On/Off

SP-08-AX (101)

SP-08-AX (101)

SP-08-AX (101)

RMS

Monitor:

Light level

Status

Control:



Light presets

Light on/off

Central Topic

8) Power Management

NI-700

 **Settings:**  


 232

1

Dent PowerScout 3/18

2

Dent PowerScout 3/18

- Kiosk 1 (HVAC)
- Kiosk 2 (Lighting)
- Kiosk 3 (Power Management)
- Kiosk 4 (Security/Building Access)
- Kiosk 5 (Fire)
- Kiosk 6 (Life Safety)
- Kiosk 7 (CCTV)

Kiosk 8 (Zone 4)

 IR



 I/O



IR Rcvr



Connectivity

 Ethernet

NXD-1000Vi

Display: voltage, current, power

Axlink

 RMS

Monitor:

Voltage, current, power

Control:

Power on/off connected device