


REMOTE CONTROL MIRROR SWITCH



REMOTE CONTROL SWITCH				CHANGE OVER SWITCH			RETRACTION SWITCH		
L	R	DOWN	UP	L	N	R	S	N	OP
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>				<input type="radio"/>		<input type="radio"/>
						<input type="radio"/>			
	<input type="radio"/>	<input type="radio"/>							
<input type="radio"/>					<input type="radio"/>				
						<input type="radio"/>			
		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					
					<input type="radio"/>				
			</						