











We are using a pot instead – so no longer needed



/RD (9) and /WR (8) are tied to GND, assuming we are using 3-wire SPI



TR-9 Open Source Digital Radio

Sheet: /
File: HMI.sch

Title: HMI Board

Size: A4 Date: 2020-01-18

KiCad E.D.A. kicad (5.1.4)-1

Rev:
Id: 1/1