



R1 is a termination for the RS-485 bus. It must only be installed on the final feeder floor in the chain.

Sheet: /		D
File: feederFloor.sch		
<b>Title:</b>		
Size: A4	Date:	<b>Rev:</b>
KiCad E.D.A.	eeschema 5.1.9+dfsg1-1bpo10+1	Id: 1/1