



# NOTES: (UNLESS OTHERWISE SPECIFIED)

1)



## SPARKFUN PRO MICRO 5V/16Hz

NOTE: 1) In arduino code, use "SERIAL" for USB; "SERIAL1" for TX/RX pins.  
2) PRO MICRO gets added via 24-pin DIP socket




## CONNECTORS




## MOUNTING HOLES



## TEST POINTS



## PWR FLAGS



## LOGOS



**OPEN HORNET**  
www.openhornet.com

Sheet:  
File: ABSIS\_HID Bus Master.kicad\_sch

**Title: ABSIS HID Bus Master**

Size: A Date: 2023-02-10  
License: CC BY-NC-SA

Rev: 2  
Id: 1/1