


2

1

B


B



Exploded View

When the post is installed on the machine,  
use the top screw to fine-tune the height at  
the parking location.

Use the two screws in the pockets to set  
the parking position.



Assembled View

A

A

2

1

## Sheet4



Created by:  
Joshua Vasquez

last edited:  
2/15/2020

SCALE: 1:1

SHEET 5 OF 5