

1

Break all sharp edges.


Part Numbering Scheme:

031-CPP-01-<Material>-<Machinist Specified>

MM6: Machined MIC6

M61: Machined 6061

Example: 031-CPP-01-M61-MRW



These plates are used on both the left and right corner of the machine.

Machined Corner Pulley Plate



Created by:
Joshua Vasquez

last edited:	4/17/2020
--------------	-----------

SCALE: 1:1

SHEET 1 OF 1

1