

Rear Heater (From Aug. 2016 Production)

1

2

3

4

(BAT) 10A ECU-B

(IG) 15A GAUGE

100(A)100(B) No. 13 Junction Connector

100(A)100(B) No. 18 Junction Connector

RR HTR Relay

Rear Heater Blower Resistor

Rear Heater Blower Switch

100(A)100(B) No. 32 Junction Connector

Legend:

- * 1: Front Switch Type
- * 2: Rear Switch Type
- * 3: Pick-Up Body Type
- * 4: Except Pick-Up Body Type
- * 5: Before Jul. 2021 Production
- * 6: From Jul. 2021 Production
- * 7: Before Sep. 2022 Production
- * 8: From Sep. 2022 Production

Rear Heater (From Aug. 2016 Production)

1

2

3

4

(BAT) 10A ECU-B

(IG) 15A GAUGE

100(A)100(B) No. 13 Junction Connector

100(A)100(B) No. 18 Junction Connector

RR HTR Relay

Rear Heater Blower Resistor

Rear Heater Blower Switch

100(A)100(B) No. 32 Junction Connector

Legend:

- * 1: Front Switch Type
- * 2: Rear Switch Type
- * 3: Pick-Up Body Type
- * 4: Except Pick-Up Body Type
- * 5: Before Jul. 2021 Production
- * 6: From Jul. 2021 Production
- * 7: Before Sep. 2022 Production
- * 8: From Sep. 2022 Production