




Ground Point (LHD From Aug. 2016 Production)




- * 1 :1GR-FE
- * 2 :1HZ
- *35 :w/o ABS
- *49 :Before Sep. 2017 Production
- *50 :From Sep. 2017 Production
- *51 :*2 w/ SRS
- *54 :w/ Emission Control
- *55 :w/o Emission Control




Ground Point (LHD From Aug. 2016 Production)

* 2 :1HZ
 * 9 :2-Door Pick-Up Body Type
 *12 :Soft Top Body Type
 *13 :Except Soft Top Body Type
 *32 :w/ Headlight Beam Level Control
 *33 :w/o Power Window
 *38 :1VD-FTV
 *39 :w/ VSC
 *41 :w/ Tire Pressure Warning System


*49 :Before Sep. 2017 Production
 *50 :From Sep. 2017 Production
 *52 :Before Jul. 2021 Production
 *53 :From Jul. 2021 Production
 *58 :w/ DPF
 *59 :w/o DPF




Ground Point (LHD From Aug. 2016 Production)





Ground Point (LHD From Aug. 2016 Production)








- * 1 :1GR-FE
- * 2 :1HZ
- *21 :1HZ 12V Battery Type w/ Two Batteries
- *35 :w/o ABS
- *36 :w/ Air Conditioner
- *38 :1VD-FTV
- *39 :w/ VSC
- *40 :w/o VSC




Ground Point (LHD From Aug. 2016 Production)










Ground Point (LHD From Aug. 2016 Production)



Ground Point (LHD From Aug. 2016 Production)







This wiring diagram illustrates the electrical connections for the Rear Differential Lock Position Switch (V1) and associated components. The main power source is W-B (*6), which branches into W-B (*7) and W-B (*8). W-B (*8) provides power to V1 (RRE) and S10 (Rear Heater Blower Switch). W-B (*7) provides power to S2 (Front Seat Inner Belt Assembly LH). W-B (*6) also provides power to T8 (Fuel Pump Sub) and T10 (Trailer Socket). W-B (*8) provides power to T15 (License Plate Light Assembly LH), T13 (License Plate Light Assembly RH), T16 (License Plate Light Assembly LH), T12 (License Plate Light Assembly RH), T11 (Back Buzzer Assembly), T14 (Rear Combination Light Assembly RH), and T17 (Rear Combination Light Assembly LH). W-B (*8) also provides power to VT1 (Voltage Transformer 1) and ST2 (Switching Transistor 2). W-B (*8) provides ground for T10, T15, T16, T12, T11, T14, and T17. W-B (*8) provides ground for T8, T13, and T16. W-B (*8) provides ground for T15, T13, T16, T12, T11, T14, and T17. W-B (*8) provides ground for T8, T13, and T16. W-B (*8) provides ground for T15, T13, T16, T12, T11, T14, and T17.


Legend:

- * 6 :4-Door Except Pick-Up Body Type
- * 7 :2-Door Except Pick-Up Body Type
- * 8 :4-Door Pick-Up Body Type
- *24 :Back Door w/ Fuel Tank
- *25 :Back Door w/o Fuel Tank
- *28 :Algeria
- *29 :Except Algeria
- *37 :Rear Switch Type
- *48 :w/ Back Buzzer

Ground Point (LHD From Aug. 2016 Production)








L53


Black




90980-11542

AC1

Black




90980-11240




90980-11239

AC2

Black




90980-10897




90980-10896

AI3

White




90980-12501




90980-12514

AI7

White



90980-11542




90980-11541

BI2

Gray




90980-10891




90980-10890

CA3
Black




90980-11893




82824-30270

CA4
Gray



90980-11601



90980-11600

Ch1

Black Dark Gray



90980-10988




90980-10987

IA1

Black



90980-12380




90980-12379

IA3

Black



90980-12380



90980-12379

IB5

Gray



90980-10988



90980-10987

