




Injector Driver 1




Injector Driver 2



Ignition Driver 1



Ignition Driver 2



Sheet: /Fuel & Ignition/
File: Fuel_Ignition.sch

Title:


Size: A4

Date:


KiCad E.D.A. kicad (5.1.4-0-10_14)

Rev:

Id: 2/7




Power Regulator



Reset Protection

Refer AVR040 Application Note



Sheet: /Power/
File: power.sch


Title:

Size: A4


Date:

KiCad E.D.A. kicad (5.1.4-0-10_14)


Rev:
Id: 4/7




PWM Idle and Boost outputs



Fan and Optional Tacho output




HC-05 Bluetooth Connector



Fuel Pump

This is the primary (high side) fuel pump signal that goes out the ST-Sig pin



Sheet: /Outputs/
File: outputs.sch

Title:

Size: A4 Date:
KiCad E.D.A. kicad (5.1.4-0-10_14)

Rev:
Id: 6/7

