

Configuration of WIFI on Diet-pi

(USBridge/Digione/Boss player Images)

https://github.com/sparkysbc/sparky_linux_images/blob/master/Dietpi_ssh_access.pdf

login:root

password:dietpi

root@DietPi:~# dietpi-config

```
DietPi-Config
Hardware : Sparky SBC (armv7l)

1 Display Options
2 Audio Options
3 Performance Options
4 Advanced Options
5 Language/Regional Options
6 Security Options
7 Network Options: Adapters
8 Network Options: NAS/Misc
9 AutoStart Options
10 Tools

<Ok>          <Exit>
```

```
DietPi - Network Options: Adapters

Ethernet : Available | Enabled | Connected
Wifi      : Available | Enabled | Disconnected
IPv6      : Enabled
Internet  : Please run Internet Test
Proxy     : Disabled

Ethernet Change Wired Network Settings
Wifi      Change Wireless Network Settings
IPv6      Toggle IPv6 Support
Test      Run the Internet Connection Test
Proxy     Configure proxy settings

<Ok>          <Back>
```


```
WiFi is Disabled

WiFi must be enabled before settings can be changed.

Would you like to enable WiFi now?
- (NOTICE) Connections may drop!

<Ok>          <Back>
```

This will install required wifi packages and enables wifi



Select the SSID you want to connect from the listed networks , It will ask for the credentials for connecting to wifi

