

Title **Ravage - Analog Inputs 8-15**

Size: A4

Number: A


Revision: 0,2







Date: 20/09/2011 Time: 11:08:54 p.m. Sheet 6 of 13

File: C:\Users\el_presto\Desktop\WorkSpace\FreeEMS\Preston-Ravage\Ravage\Extra Analogue Inputs.SchDoc

Drawn By:
Dan Visser







A

B

C






D


A


B


C


D



Title <i>Ravage - Low Side Drivers</i>			Drawn By: <i>Dan Visser</i>		
Size: A4	Number: A	Revision: 0,2			
Date: 20/09/2011 Time: 11:08:55 p.m. Sheet 11 of 13					
File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Low Side Drivers.SchDoc					



Title <i>Ravage - 3-Wire ISCV Driver</i>			Drawn By: <i>Dan Visser</i>	
Size: A4	Number: A	Revision: 0.2		
Date: 20/09/2011 Time: 11:08:55 p.m. Sheet 12 of 13				
File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\3-Wire ISCV Driver.SchDoc				



Title

Size: A4

Date: 20/09/2011

Number: A

Time: 11:08:55 p.m.

File: C:\Users\EL_PRESTO\Desktop\WORKSPACE\FreeEMS\PRESTON-RAVAGE\Ravage\Connector.SchDoc

Revision:0,2

Sheet 13 of 13

Drawn By:

Dan Visser

Altium